

OWNER'S MANUAL


Terrace GAZEBO

Caution: Carefully Read Instructions and Procedures
for Safe Operation

KSN: 0-06298316-8

UPC Code: 846822013220

Date of Purchase: ____/____/____






















Warning:

1. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment. Please read all instructions before assembly and use.
2. Some parts may contain sharp edges, wear protective gloves if necessary. At least four or more people are recommended for safe assembly.
3. Keep all children and pets away from assembly area.
4. Begin assembly more than 6 feet from any obstruction such as fence, garage, house, overhanging branches, laundry line or electrical wires.
5. Install on level ground. This gazebo cannot be permanently staked or attached to a concrete floor or platform. The provided stakes are for soft ground use only. If assembling on a hard surface like a deck or concrete, other forms of attachment must be used such as expansion bolts that can be purchased locally.
6. This gazebo is intended for decorative and sunshade purposes only and is not meant to withstand inclement weather including high winds, rain and snow. Gazebo fabric is water resistant, not water proof and may leak during exposure to precipitation.
7. Please lay out all parts before assembling, checking to make sure all parts are there. If any parts are missing, please call 1-866-578-6569 and parts will be expedited to you.
8. **KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.** This Tent meets the flammability requirements of CPAI - 84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.




Assembly Tools Required: a ladder and a hammer (not provided)

TERRACE GAZEBO PARTS LIST

NO	PART	DESCRIPTION	QTY
A		Screen	4
B		Long Beam	2
C		Long Beam	2
D		Short Beam	2
E		Short Beam	2
F		Big Top Long Pole	2
G		Big Top Short Pole	2
H		Corner Connector	4
I		Corner Supporting Pole	8
J		Middle Supporting Pole	4
K		Small Top Connector	1
L		Top Beam	4
M		Top Hook	1
N		Long Mosquito Netting Pipe	4
O		Short Mosquito Netting Pipe	4
P		Screen Mosquito Netting Pipe	4
S		Big Canopy	1
T		Small Canopy	1
U		Mosquito Netting	1

TERRACE GAZEBO ASSEMBLY INSTRUCTION

TERRACE GAZEBO HARDWARE PACK 1

AA	M6X15 Bolt	44 PCS	
BB	M6 Flat Washer	44 PCS	
W	M6 Wrench	1 PC	









Fig.1: Connect Long Beam (B) and Long Beam (C) , Short Beam (D) and Short Beam (E) by using Bolt (AA) and Flat Washer (BB).

Fig.2: Tighten Long Mosquito Netting Pipe (N) to Long Beam (B)/(C), Short Mosquito Netting Pipe (O) to Short Beam (D)/(E) and Screen Mosquito Netting Pipe (P) to screen (A) by using Bolt (AA) and Flat Washer (BB).

Fig.3: Tighten the assembled triangle pieces of the beams onto Screen (A) by using Bolt (AA) and Flat Washer (BB). Then a frame is formed.

TERRACE GAZEBO ASSEMBLY INSTRUCTION

TERRACE GAZEBO HARDWARE PACK 2

AA	M6X15 bolt	12 PCS	
BB	M6 flat washer	12 PCS	







Fig.4: Insert Big Top Long Pole (F) and Big Top Short Pole (G) into Corner Connector (H) to form a frame.

Fig.5: Insert Corner Supporting Pole (I) into the assembled Corner Connector (H).

Fig.6: Connect the end of Corner Supporting Pole (I) and Screen (A) by using Bolt (AA) and Flat Washer (BB).






Fig.7: Insert Middle Supporting pole (J) into Big Top Pole (G/F).

Fig.8: Connect the end of Middle Supporting pole (J) and the middle of Beams (B/D & C/E) by using Bolt (AA) and Flat Washer (BB).

Fig.9: Attach Top Hook (M) to Small Top Connector (K).








Fig.10: Insert Top Beam (L) into Small Top Connector (K).

Fig.11: Attach Small Canopy (T) to small top.

Fig.12: Attach Big Canopy (S) to big top (Do not fully spread), then insert the assembled small top into big top frame.

TERRACE GAZEBO ASSEMBLY INSTRUCTION

TERRACE GAZEBO HARDWARE PACK 3

DD	plastic loop	52 PCS	
EE	Φ8*180 stake	8 PCS	






Fig.13: Spread Big Canopy (S) and attach the hook onto the beams, attach mosquito netting (U) with plastic loop (DD).

Fig.14: Fix the assembled gazebo on ground with stake (EE).

TERRACE GAZEBO ASSEMBLY INSTRUCTION

CARE & Maintenance

It is advised that the Canopy should be removed in the winter for best protection and length of use. Our steel components for garden accessories and furniture are treated with rust inhibiting paint that protects it from rusting. However, due to the nature of steel, surface oxidation (rusting) will occur once these protective coatings are scratched. This is a natural process and is not a defect! To minimize this condition, we recommend care when assembling & handling the product to prevent scratching the paint. Should any scratching or damage occur, it is strongly recommended that consumers buy touch up paint prior to the assembly process so that any parts they scratch during assembly are touched up. Surface rust can also be easily removed with a very light application of common cooking oil. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping on to deck or patio and cause damaging stains, which may be difficult to remove. This can be prevented if the measure is taken to keep the product from oxidizing. Also the use of wax candle to lubricate the zippers once a year will keep them running smoothly.

Limited Warranty

The item is warranted to be free from defects in material or workmanship for a period of 1 year. However, we don't reimburse for transportation or delivery costs, or compensate the individual or any outside party for assembling or disassembling the product.

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item, provided the item is maintained with care and used only for personal, residential purposes.

Exclusions

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

Important

Please do not return this product to the store. For technical assistance on assembly or replacement parts, call Sunjoy Industries at (866) 578-6569 from 8:30 AM to 5:30 PM EST Monday to Friday. For expedited replacement parts order, fax the attached completed customer service replacement form to 1-740-283-3549, or send an email to kmart@sunjoygroup.com for assistance.

Made in China



Please refer to part numbers when reordering

For questions or comments about product:

Email: kmart@sunjoygroup.com or Call toll-free: 866-578-6569

Made in / Hecho en CHINA for Kmart Corporation, Hoffman Estates , IL 60179

See our extensive assortment of outdoor living products

on-line at www.sears.com and www.kmart.com