



GAZEBO PENGUIN INC.

4660 Hickmore, St-Laurent
Quebec, Canada H4T 1K2

1-800-737-7174 / 514-276-3485


Fax : 1-514-276-4147

adlonco@hotmail.com

43204-32 10'x14' GAZEBO ASSEMBLY INSTRUCTIONS

*PLEASE.
READ
BEFORE INSTALLATION*

*PLEASE.
READ
BEFORE INSTALLATION*



Two or more adults required for assembly


Before you assemble the Gazebo

- It is important that this gazebo be anchored on a solid base with the provided screws. Otherwise, please ensure that you use anchors sufficient for your surface.
- The gazebo should not be installed adjacent to trees or a sloped roof. Snow and ice may slide onto the gazebo and cause it to collapse.


Step 1:

Assemble beams "A" and "B" using center plate "F", securing tightly with 8 bolts "Pp". Repeat with beams "C" and "D", also using center plate "F". Lay out the assembled beams in a rectangle and join at each corner with a corner plate "E", again securing tightly with 8 bolts "Pp".

SKETCH 1



SKETCH 2




Step 2:

For each leg "G", attach foot plate "H" using 3 bolts "Pp".

Step 3:


Have someone lift the beam assembly and attach each leg “G” into a corner, securing each using 4 bolts “Pp”. Repeat until all four legs are in place.



Step 4:

Install middle joint cover “J” at each of the 4 beam junctions, using 4 screws “Qq” each.

Install corner cover “I” at each of the corners, using 4 screws “Qq” each.




Step 5:

Attach mounting brackets "O" and "P" to rafters "M" and "N" respectively. Use threaded hole about 8" from end of rafter.

Lift central hub "L" to a height of about 110" (2.79m) at the center of the gazebo. (Caution: this part may be heavy, use support as needed)


Attach one end of rafter "M" to the hub using 1 bolt "Pp". Attach other end with mounting bracket to the corner of the beam assembly with 2 bolts "Pp". Use the set of holes closest to the inside. Repeat with remaining "M" rafters.

Similarly, attach one end of rafter "N" to the hub using 1 bolt "Pp". Attach other end with mounting bracket to the beam assembly with 2 screws "Qq". Use the set of holes closest to the inside. Repeat with remaining "N" rafters.



Step 6:


Once all rafters are in place, install top cap "K" over central hub "L". Use flat washers and acorn nuts "Vv" to secure tightly.



Step 7:


Install the flashings “Q”, “R”, and “S” onto the beam assembly, using screws “Qq” on the inside. The notched end of a flashing will always go in a corner of the gazebo.

SKETCH 7



Step 8:


Install the curtain rails “T” and “U” on the inside of the beam assembly using bolts “Pp”.



SKETCH 8


Step 9:

Slide the indicated polycarbonate panels into the spaces between the rafters, using the top groove of each rafter. Ensure the side meant to face the sun is on the outside. Use a rubber hammer to carefully tap each panel into the grooves.




Step 10:

Insert the middle roof joints in between the rafters and slide them up under the polycarbonate panels. Tap lightly to ensure the panel is fully in the slot. Seen from above, most of the joint as well as the drain holes should be beneath the roof panels.




Step 11:

Slide the remaining polycarbonate roof panels in the lower groove of the rafters and into the lower slot of the roof joints. Tap to make sure panels fit securely and do not extend past the ends of the rafters.




Step 12:

Starting from any end, install all edgings, with end caps “Gg” or “Hh” at each junction or corner respectively. Use bolts “Pp” to secure.




Step 13:

Install the upper crossbars on the interior of the roof using bolts "Pp", following the shaped ends and letters. Do not tighten bolts immediately; install loose and tighten once all crossbars are in place. Repeat this step with the lower crossbars.




Step 14:

- Secure each foot plate into the ground using screws "Rr" and washers "Tt".
- Use lag shields (Ss) if needed for harder surfaces.



Step 15:


Install the screen curtains “Ww” in the interior groove of the curtain rails, using the provided hooks. Install the privacy curtains “Xx” in the exterior groove of the rails. Once the hooks are in, use curtain rail caps “Uu” to close ends of curtain rails.























































Note that both curtains are packaged and ordered in sets of 2 panels, each set covering half the gazebo.


IMPORTANT NOTES:

Make sure all screws and bolts are tight.
If conditions are windy, you may have to add cable guides at the corners.



PART	QTY	DIAGRAM	PART	QTY	DIAGRAM
(11-624-32) 52 3/4" TOP LEFT BEAM A	2		(11-637-32) 60 3/8" ROOF RAFTER N	8	
(11-625-32) 52 3/4" TOP RIGHT BEAM B	2		(12-030-32) RAFTER M MOUNTING BRACKET O	4	
(11-662-32) 78 1/4" TOP LEFT BEAM C	2		(12-031-32) RAFTER N MOUNTING BRACKET P	8	
(11-663-32) 78 1/4" TOP RIGHT BEAM D	2		(11-638-32) 55 1/4" RIGHT FLASHING Q	4	
(11-628-32) CORNER PLATE E	4		(11-639-32) 55 1/4" LEFT FLASHING R	4	
(11-629-32) CENTER PLATE F	4		(11-709-32) 51" CENTER FLASHING S	2	
(11-630-32) 81 1/2" LEG G	4		(11-666-32) 73 1/4" CURTAIN RAIL, 14' SIDE T	4	
(11-631-32) FOOT PLATE H	4		(11-642-32) 47 3/4" CURTAIN RAIL, 10' SIDE U	4	
(11-632-32) CORNER COVER I	4		(11-643) 30"x30" LEFT UPPER ROOF PANEL V	4	
(11-633-32) MIDDLE COVER J	4		(11-644) 29 1/2"x25 1/2" MIDDLE UPPER ROOF PANEL W	4	
(11-664-32) 63" TOP CAP K	1		(11-645) 30"x30" RIGHT UPPER ROOF PANEL X	4	
(11-665-32) 60" CENTRAL HUB L	1		(11-646-32) 30 3/4" LEFT MIDDLE ROOF JOINT Y	4	
(11-636-32) 83" ROOF RAFTER M	4		(11-647-32) 25 1/2" CENTER MIDDLE ROOF JOINT Z	4	

PART	QTY	DIAGRAM	PART	QTY	DIAGRAM
(11-648-32) 30 ¾" RIGHT MIDDLE ROOF JOINT Aa	4		(11-661-32) 17 ½" RIGHT UPPER CROSSBAR Nn	4	
(11-649) 33"x58 1/8" LEFT LOWER ROOF PANEL Bb	4		(08-158-32) BOLT Pp	196	 (M6x16mm)
(11-650) 33"x58 1/8" RIGHT LOWER ROOF PANEL Cc	4		(08-156-32) SCREW Qq	100	 (M4x16mm)
(11-651-32) 58 7/8" LEFT EDGING Dd	4		(08-167-32) SCREW Rr	12	 (M6x100mm)
(11-652-32) 26 ¾" CENTER EDGING Ee	4		(08-193) PLASTIC PLUG Ss	12	
(11-653-32) 58 7/8" RIGHT EDGING Ff	4		(08-187) WASHER Tt	16	 (M6)
(11-654-32) RAFTER CAP Gg	8		(11-697) CURTAIN RAIL CAP Uu	8	
(11-655-32) CORNER END BRACKET Hh	4		(08-189-32) ACORN NUT Vv	4	
(11-656-32) 44" LEFT LOWER CROSSBAR Ii	4		(11-667) SCREEN CURTAIN (set of 2 panels) Ww	2	
(11-657-32) 26 ¾" MIDDLE LOWER CROSSBAR Jj	4		(11-668) PRIVACY CURTAIN (set of 2 panels) Xx	2	
(11-658-32) 44" RIGHT LOWER CROSSBAR Kk	4		(11-706) 33"x25 ½" MIDDLE LOWER ROOF PANEL Yy	4	
(11-659-32) 17 ½" LEFT UPPER CROSSBAR Ll	4		(11-705) CURTAIN HOOKS	96	
(11-660-32) 26 ¾" MIDDLE UPPER CROSSBAR Mm	4		10 mm KEY	1	



GAZEBO PENGUIN INC.
2255 DANDURAND ST.
MONTREAL, QUEBEC
H2G 1Z3
e-mail: gazebopenguin@hotmail.com

43204 GAZEBO
PLAN A LA BASE DES PATTES
PLAN AT BASE OF LEGS

43204 GAZEBO
REBORD DU TOIT
ROOF OVERHANG

Drafted by JUDSON	Checked by	Approved by	File path L:\z\Autocad_Work\Stationn\	Date OCT 04, 2011	Scale 1/4" = 1'-0"
43204 GAZEBO			110" HIGH	Revision 1	Sheet 2 of 4

MAINTENANCE NOTES

1. In case of a defective or damaged part, or for any other questions concerning the product, please contact the manufacturer directly.
2. Please have the parts list and part numbers on hand when ordering or requesting replacement parts.
3. The product should not be installed adjacent to trees or a sloped roof. Snow and ice may slide onto the roof and cause it to collapse.
4. While the product is designed for 4 seasons use, the roof must be kept free of accumulation of snow.



ONE YEAR LIMITED WARRANTY

This product has been designed and manufactured to meet the highest standards of quality and durability. Subject to the Conditions for Exercising the Warranty and the Limitations on the Warranty set forth below, it is warranted to be free of material and manufacturing defects for a period of **one year** from the date of purchase. Should the product become damaged, or the warranty period has expired, please contact Gazebo Penguin Customer Service Department for a complete schedule of replacement parts and prices.

CONDITIONS FOR EXERCISING THE WARRANTY

In order to properly exercise your warranty, please comply with the following:

Carefully inspect the contents of the carton for missing or damaged components. Should you discover damaged or missing parts, **do not return the product to the place of purchase**, but contact Gazebo Penguin Customer Service Department at the numbers listed below:

Montreal: (514) 276-3485

Elsewhere: 1-800-737-7174

NOTE: Damages/missing parts must be reported within 30 days of delivery.

LIMITATIONS ON THE WARRANTY

1. The product is not warranted against damages due to vandalism, abuse, falling or thrown objects, or accumulation of snow.
2. The product is not warranted against damages due to extreme weather conditions, such as thunderstorms, hail, strong wind or snow storms, or any other acts of God.
3. The product is only warranted in the event it is installed in accordance with the Gazebo Penguin's written instructions enclosed with the product.
4. The product is not warranted in the event it has been improperly anchored.
5. We reserve the right to replace or repair any defective product or parts at our discretion.