USER MANUAL

KBU-50S / 120S / 170S SINGLE ZONE MODELS

LAE controller from Italy



COMPRESSOR WINE CELLAR



CONTENTS

CONGRATULATIONS

Congratulations and thank you for choosing our KingsBottle Wine Cellars. We are sure you will find your new appliance a pleasure to use. Before you installing and operating the wine cellar, we recommend that you read through the relevant sections of this manual, which provides a description of your wine cellar and its functions.

To avoid the risks that are always present when you use an electric appliance, it is important that the appliance is installed correctly and that you read the safety instructions carefully to avoid misuse and bazards.

We recommend that you keep this instruction booklet for future reference and pass it on to any future owners.

After unpacking the appliance, please check it is not damaged. If in doubt, do not use the appliance but contact us or your local customer care centre

TABLE OF CONTENTS			
CHAPTER	CONTENTS	PAGE	
Part I	Important Safety & Pre-Use Instructions	3	
Part II	Diagram & Description of Wine Cellar	4	
Part III	Installation Instructions	5-10	
Part IV	Operating Your Wine Cellar	11-14	
Part V	Temperature Settings	15	
Part VI	Layout & Storage	16	
Part VII	Removing the Rolling Shelf	17	
Part VIII	Technical Data	18	
Part IX	Warranty Information	20	



PART I IMPORTANT SAFETY INSTRUCTIONS

Please read the user manual carefully and store in a handy place for later reference . The symbols you will see in this booklet have these meanings:



WARNING

This symbol indicates information concerning your personal safety



**** CAUTION

This symbol indicates information on how to avoid damaging the appliance



TIPS & INFORMATION

This symbol indicates tips and information about use of the appliance



ENVIRONMENTAL TIPS

This symbol indicates tips and information about economical and ecological use of the appliance



TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, OR INJURY WHEN USING YOUR APPLIANCE, FOLLOW THESE BASIC PRECAUTIONS:

- Read all instructions before using the wine cellar.
- DANGER or WARNING: Risk of child entrapment.

Child entrapment and suffocation are not only problems of the past. Junked or abandoned appliances are still dangerous... even if they will "just sit in the garage for a few days".

- Before you throw away your old wine cellar:
 - Take off the door.
 - · Leave the Shelves in pieces so that children may not climb inside easily.
- 4. Never allow children to operate, play with, or crawl inside the appliance.
- Never clean appliance parts with flammable fluids. The fumes can create a fire hazard or explosion.
- Do not store in the vicinity of any other appliance. Do not store near gasoline or any other flammable vapors. The fumes can create a fire hazard or explosion.



WARNING

- The cellar must be plugged into its own dedicated 110-115V, 50/60Hz AC electrical outlet.
- The plug must be accessible when the cellar is in position.
- It is essential the power point is properly earthed to ground. Consult a qualified electrician if you are unsure.

- Don't use extension cords or adapter plugs with this
- If the power cord is damaged, have it replaced by a qualified service technician.
- Unplug the cellar before cleaning it, or changing the light bulb to avoid electric shock.
- Never unplug the cellar by pulling the electrical cord as this may damage it. Grip the plug firmly and pull straight
- 8 Choose a location for your cellar that isn't too cold . The ambient room temperature should be above 50°F.
- Stand your cellar in a dry place avoid areas of high moisture or humidity.
- 10. Don't put the cellar in frosty or unprotected areas like a garage or on the verandah.
- 11. Keep the cellar out of direct sunlight.
- Don't locate the cellar near stoves, fires or heaters.
- 13. When installed correctly, your cellar should:
 - Have adequate space at the back and sides for air circulation.
 - Be aligned to the surrounding cupboards .
 - Have doors that will self-close from a partially open position

BEFORE USING YOUR WINE CELLAR

- Remove the exterior and interior packing.
- Before connecting the wine cellar to the power source, let it stand upright for approximately 24 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation.
- Clean the interior surface with lukewarm water using a soft cloth.


COMPRESSOR WINE CELLAR





PART II DIAGRAM & DESCRIPTION OF WINE CELLAR

SINGLE ZONE WINE CELLAR MODELS: KBU-50S, KBU-120S, KBU-170S SERIES



- 1 Control board
- 2 Housing
- 3 Ventilation DC Fan
- 4 Sliding shelf
- 5 Front grill
- 6 Door hinge

- 7 Controller
- 8 Glass Door
- 9 Adjustable stand feet


YOUR WINE CELLAR ALSO INCLUDES THE FOLLOWING:


- Instruction manual
- Two keys
- Top and bottom hinges, also screws for changing the door hinge

Note: Above diagram and description is for SINGLE ZONE WINE CELLAR MODELS: KBU-50S, KBU-120S, KBU-170S series

PART III INSTALLATION INSTRUCTIONS

CUTOUT DIMENSION ILLUSTRATED







KBU-170S SERIES

23.54"W x 26.97"D x 71.69"H (598W x 685D x 1821H mm) Included stand height 0.98"(25mm)

KBU-120S SERIES

23.54"W x 26.97"D x 55.43"H (598W x 685D x 1408H mm) Included stand height 0.98"(25mm)

KBU-50S SERIES

23.42"W x 23.62"D x 33.86"H (595W x 600D x 860H mm) Included stand height 0.79" (20mm)

MODEL	WIDTH	DEPTH	HEIGHT	INCLUDED STAND HEIGHT	NOTE
KBU-170S	23.54" 598mm	26.97" 685mm	71.69" 1821mm	0.98" 25mm	
KBU-120S	23.54" 598mm	26.97" 685mm	55.43" 1408mm	0.98" 25mm	For BUILT-IN installation, recommend to leave1/2" for each side
KBU-50S	23.42" 595mm	23.62" 600mm	33.86" 860mm	0.79" 20mm	

COMPRESSOR WINE CELLAR



PART III INSTALLATION INSTRUCTIONS


A. GENERAL INSTALLATION INSTRUCTIONS


- 1. This appliance is designed for both free standing and built-in (fully recessed) installation.
- 2. Place your wine cellar on a flat, solid floor that is strong enough to support it when it is fully loaded. To level your wine cellar, adjust the leveling leg at the bottom of the wine cellar
- 3. When moving your wine cellar, please do not incline it more than 45 degrees.
- 4. Locate the wine cellar away from direct sunlight and sources of heat (stove, heater, radiator, etc.). Direct sunlight and heat sources may increase electrical consumption. Extreme cold ambient temperatures may also cause the unit to perform improperly.
- 5. Avoid locating the unit in damp areas.
- 6. Plug the wine cellar into an exclusive, properly installed and grounded wall outlet. Do not under any circumstances cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or electrical grounding should be directed to a certified electrician or authorized products service center.

B. HANDLE INSTALLATION

Step 1 Take out the handle from the cellar and remove the plastic bag, also remember 2pcs of screw are packed inside.


Step 2 Pull out a bit of rubber gasket from the back side of the hole.





PART III INSTALLATION INSTRUCTIONS


C. INSTALLATION OF FRONT GRILL



D. INSTALLATION OF BUILT-IN CELLAR (MINIMUM CAVITY SPACE REQUIRED)

The cutout dimension illustrated in figure (D) allows for door swing and access to the pull-out shelves when installed as a built-in appliance. If installing between frameless cabinets, a 1/2" wide filler strip or side panel may be needed on hinge side.

The filler strip will act as a spacer between the appliance case and adjacent cabinet door swing.



Note:

It's necessary to consider leaving 1/2" for each side, that will be more convenient and easy for BUILT-IN installation. Also need to consider door swing, etc. Failure to allow minimum clearance will void all warranties.

Failure to allow minimum clearances will void all warranties

COMPRESSOR WINE CELLAR





PART III INSTALLATION INSTRUCTIONS


E. REVERSING THE DOOR SWING OF YOUR APPLIANCE

- The unit is delivered to you with the door opening from the left side (hinge on right side)
- The door of this appliance is capable of opening from either the left or right side. To reverse the door swing of your cooler and open from the right side, please follow the instructions and diagram as follows
- There is a extra set of hinges in the plastic bag which contains instruction manual


INSTRUCTION OF REVERSING DOOR FOR KBU-120 /170 SERIES

























- · Before you begin to reverse the door, it is recommended to tape down shelves to avoid movement during the process
- It is recommended to take out the wine bottles from the cellar before reversing the door

PART III INSTALLATION INSTRUCTIONS


INSTRUCTION OF REVERSING DOOR FOR KBU-50 SERIES

















































- Before you begin to reverse the door, it is recommended to tape down shelves to avoid movement during the process
- It is recommended to take out the wine bottles from the cellar before reversing the door


COMPRESSOR WINE CELLAR



PART III INSTALLATION INSTRUCTIONS

F. INSTALLING YOUR WINE COOLER

- 1. Move the appliance into its final position.
- 2. If the appliance is not tilting back as described earlier, minor adjustments can be made to the leveling legs.
- 3. Compare the alignment of the appliance to the surrounding cupboard. The top of the appliance should be level from side to side (see diagram below).



- 4. If the appliance now rocks from one corner to the opposite rear corner, this means that the floor is uneven. You may need to put some packing under the ridge to the rear of the appliance. You could use thin pieces of solid material such as thin board, vinyl floor tiles or laminate.
- 5. You may now need to fine tune the installation by repeating steps 2, 3 and 4.
- 6. Wipe off any dust that has accumulated during shipping and clean following the directions in Part VIII (Care & Maintenance)
- 7. Plug the appliance into the power point. Don't use a double adaptor or extension cord .
- 8. It is recommended that you let the appliance for an hour or two before you put any wine in it. This will confirm that it is operating correctly and make the conditions appropriate for wine storage.

Congratulations! You have successfully installed your cellar/refrigerator/freezer

DOOR LOCK

This unit comes with an optional key lock. The keys are located inside the plastic bag that contains the user manual. To unlock the door, insert the key into the lock and turn counterclockwise. To lock the door, simply reverse the operation making sure the metal pin is engaged completely. Then remove the key and place it is a secure place for safekeeping.

PART IV OPERATING YOUR WINE CELLAR

This wine cellar series comes with LAE controller from Italy, one of the best quality supplier of controllers. Before using your wine cellar, please read this instruction carefully.



Auxiliary output

Fan output

Activation of 2nd parameter set

Thermostat output

Alarm



i **♦** Info / Setpoint button.

Manual defrost / Decrease button.

▲ 🗑 Increase / light activation button. **≭** U Exit / Stand-by button.

DISPLAY

OPERATION

During normal operation, the display shows either the temperature measured or one of the following indications:

DEF	Defrost in progress	НІ	Room high temperature alarm
REC	Recovery after defrost	LO	Room low temperature alarm
OFF	Controller in stand-by	E1	Probe T1 failure
CL	Condenser clean warning	E2	Probe T2 failure
DO	Door open alarm		

INFO MENU

The information available in this menu is:

T1	Instant probe 1 temperature	TLO	Minimum probe 1 temperature recorded
T2	Instant probe 2 temperature	CND	Compressor working weeks
THI	Maximum probe 1 temperature recorded	LOC	Keypad state lock

COMPRESSOR WINE CELLAR



Access to menu and information displayed. Press and immediately release button i 🗘 With button or select the data to be displayed. Press button i to display value. To exit from the menu, press button or wait for 10 seconds. Reset of THI, TLO, CND recordings With button or select the data to be reset. Display the value with <u>button</u> i . While keeping button i pressed, use button x SETPOINT (display and modification of desired temperature value) Press button i for at least half second to display the setpoint value. By keeping button i pressed, use button or When button **i** ◆ is released, the new value is stored.

to set the desired value (adjustment is within the minimum SPL and the maximum

STAND-BY

Button (with SB=YES only).

KEYPAD LOCK

The keypad lock avoids undesired, potentially dangerous operations, which might be attempted when the controllers is operating in a public place. In the INFO menu, set parameter LOC=YES to inhibit all functions of the buttons. To resume normal operation of keypad, adjust setting so that LOC=NO.

SELECTION OF SECOND PARAMETER GROUP

It's possible to select control parameters between two different pre-programmed groups, in order for the fundamental control parameters to be adapted quickly to

changing needs. With IISM=MAN, changeover from Group I to Group II takes place manually by pressing button for 2 seconds. The activation of Group Il is signalled by the lighting up of the relevant LED on the controller display. If IISM=NON, switchover to group II is inhibited.

DEFROST

Timed defrost. Defrosting starts automatically when necessary time has elapsed to obtain the defrosting frequency set with DFR (IIDF). For example, with DFR=4 defrosting occurs once every 6 hours. The internal timer is set to zero when power is applied to the controller and at each subsequent defrost start. When the controller is put on a standby, the accumulated time count is "frozen" (is not incremented).

Manual defrost. Defrosting may also be induced manually by keeping the button pressed for 2 seconds.

Defrost type. Once defrost has started, Compressor and Defrost outputs are controlled according to the parameters DTY and OAU. The AUX output is associated to defrost function with **OAU=DEF** exclusively.

If FID=YES the evaporator fans are active all through defrost.

Defrost termination. Defrost lasts as long as time DTO but, if the evaporator probe has been enabled (T2=YES) and temperature DLI is achieved before this time elapses, defrost will be terminated in advance.

Resuming thermostatic cycle. When defrost is over, if DRN is greater than 0, all outputs will remain off for DRN minutes, in order for the ice to melt completely and the resulting water to drain. Moreover, if probe T2 is active (T2=YES), the fans will re-start when the evaporator gets to a temperature lower than FDD; Vice versa, if such condition does not occur after 4 minutes following defrost termination, the fans will be switched on anyway.

Caution: if C-H=HEA all defrost functions are inhibited; if DFR=0 the timed defrost function is excluded; during defrost, the high temperature alarm is inhibited.

CONFIGURATION PARAMETERS

To get access to the parameter configuration menu, press button + i \$\displays \text{ for 5 seconds.} With button or select the parameter to be modified.

Press button i to display the value.

By keeping button i pressed, use button or to set the desired value.

When button is released, the newly programmed value is stored and the following parameter is displayed.

To exit from the setup, press button x or wait for 30 seconds.

OPERATION

PAR	RANGE	DESCRIPTION	Preset Value
SCL	1°C; 2°C; °F	Readout scale. 1°C (with INP=SN4 only): measuring range -50/-9.9 19.9/80°C 2°C: measuring range -50 120°C °F: measuring range -55 240°F Caution: upon changing the SCL value, it is then absolutely necessary to re-configure the parameters relevant to the absolute and relative temperatures (SPL, SPH, SP, ALA, AHA, etc).	°F
SPL	-50SPH	Minimum limit for SP setting.	44
SPH	SPL.120°	Maximum limit for SP setting.	41
SP	SPL SPH	Setpoint (value to be maintained in the room).	64 59
C-H	REF; HEA	Refrigerating (REF) or Heating (HEA) control mode.	
HYS	110°	OFF/ON thermostat differential	REF
	110	OFF SP SP+HYS T[°] OFF SP-HYS SP T[°] Refrigerating control (C-H=REF) Heating control (C-H=HEA)	5
CRT	030min	Compressor rest time. The output is switched on again after CRT minutes have elapsed since the previous switchover. We recommend to set CRT =03 with HYS <2.0°.	6
CT1	030min	Thermostat output run when probe T1 is faulty. With CT1=0 the output will always remain OFF.	3
CT2	030min	Thermostat output stop when probe T1 is faulty. With CT2=0 and CT1>0 the output will always be ON. Example: CT1=4, CT2= 6: In case of probe T1 failure, the compressor will cycle 4 minutes ON and 6 minutes OFF.	6
CSD	030min	Compressor stop delay after the door has been opened (active only if DS =YES).	6
DFR	0 24(1/24h)	Defrost frequency expressed in cycles/24 hours.	3
DLI	-50120°	Defrost end temperature.	39
DTO	1120min	Maximum defrost duration.	20
DTY	OFF; ELE; GAS	Defrost type OFF: off cycle defrost (Compressor and Heater OFF). ELE: electric defrost* (Compressor OFF and Heater ON). GAS: hot gas defrost* (Compressor and Heater ON). * The defrost output is active if only OAU =DEF.	OFF
DRN	030min	Pause after defrost (evaporator drain down time).	0
DDY	060min	Display during defrost. If DDY =0 during defrost the temperature continues to be displayed. If DDY > 0, during defrost the display shows DEF, and at the end of defrost it shows REC for DDY minutes.	1
FID	NO/YES -50120°	Fans active during defrost.	YES
FDD	NO/YES	Evaporator fan re-start temperature after defrost. Optimised fan control enabling. With FTC = NO the fans remain on all the time.	32
FTC	NO/TES	Fig. 2 Optimised fan control (FTC=YES)	YES
FT1	0180sec	Fan stop delay after compressor stop. See Fig. 2.	180
FT2	030min	Timed fan stop. With FT2 =0 the fans remain on all the time.	1
FT3	030min	Timed fan run. With FT3=0, and FT2 > 0, the fans remain off all the time.	1

COMPRESSOR WINE CELLAR



OPERATION

PAR	RANGE	DESCRIPTION	Preset Value
	ABS; REL	Alarm threshold management. NON: all temperature alarms are inhibited (the following parameter will be ADO). ABS: the values programmed in ALA and AHA represent the real alarm thresholds. REL: the values programmed in ALR and AHR are alarm differentials referred to SP and SP+HY.	
		T[°] SP-ALR SP SP+HYS+AHR Temperature alarm with relative thresholds, refrigerating control (ATM=REL, CH=REF).	ABS
ı		OFF TO TO TO THE SP-HYS-ALR SP SP+AHR	
ALA	-50 120°	Temperature alarm with relative thresholds, heating control (ATM=REL, CH=HEA).	
		Low temperature alarm threshold.	37
AHA	-50 120°	High temperature alarm threshold.	68
ALR	-12 0°	Low temperature alarm differential. With ALR=0 the low temperature alarm is excluded.	
AHR	0 12°	High temperature alarm differential. With AHR =0 the high temperature alarm is excluded.	
ATD	0 120min	Delay before alarm temperature warning.	120
ADO	0 30min	Delay before door open alarm warning.	10
ACC		Condenser periodic cleaning. When the compressor operation time, expressed in weeks, matches the ACC value programmed, "CL" flashes in the display. With ACC =0 the condenser cleaning warning is disabled.	0
		Switchover mode to second parameter set NON: inhibition to use the second parameter group (the following parameter will be SB). MAN: button switches the two parameter groups over.	NON
IISL	-50IISH	Minimum limit for IISP setting.	41
IISH	IISL120°C	Maximum limit for IISP setting.	64
IISP	IISL IISH	Setpoint in mode 2.	59
IIHY	110°	OFF/ON differential in mode 2.	5
		Optimised fan control enabling in mode 2.	YES
		Defrost frequency expressed in cycles/24 hours in mode 2.	3
		Stand-by button enabling.	YES
DS	NO/YES	Door switch input enabling (closed when door is closed).	NO
	NON; MAN; DOR	Light control mode NON : light output not controlled. MAN : light ouput controlled through button (if OAU=LGT).	MAN
	NON; 0-1; DEF; LGT; AL0; AL1	DOR: light ouput switched on when door is opened (if OAU=LGT). AUX output operation. NON: output disabled (always off). 0-1: the relay contacts follow the on/standby state of controller. DEF: output programmed for defrost control. LGT: output enabled for light control. AL0: contacts open when an alarm condition occurs. AL1: contacts make when an alarm condition occurs.	LGT
INP	SN4; ST1	Temperature sensor selection. With $INP = SN4$, the probes must be the LAE models SN4; with $INP = ST1$, the probes must be the LAE models ST1	SN4
OS1	-12.512.5°C	Probe T1 offset.	0
T2	NO/YES	Probe T2 enabling (evaporator).	YES
OS2	-12.512.5°C	Probe T2 offset.	0
TLD		Delay for minimum temperature (TLO) and maximum temperature (THI) logging.	5
	0100	Display slowdown.	3
		AD3-5 address for PC communication.	
~PN	1200	ADO O AGGICOS IOFF O CONTINUINGALION.	1

OPERATION

PART V

TEMPERATURE SETTINGS FOR WINE SERVICE

- 1. Different varietals of wine require different temperature settings. The recommended temperature ranges for serving different varietals of wine are listed below.
 - Red Wines: 52-64°F (15-18°C)
 - White Wines: 44-51°F (9-15°C)
 - Sparkle Wines: 41-43°F (5-9°C)



CAUTION:

- In the event of a power interruption, all previous temperature settings will be automatically saved and each compartment will return to the
 previous temperature setting.
- 2. If the unit is unplugged, loses power, or is turned off, you must wait over 6 minutes before restarting. Within this 6 minutes, compressor protect itself and will not start even power ON again
- 3. When you use the wine cellar for the first time or restart the wine cellar after having been shut off for a long time, there will be a few degrees variance between the temperature you select and the one indicated on the LED readout for the first few hours of operation. After a few hours of operation, the temperature will normalize to the displayed temperature.

COMPRESSOR WINE CELLAR




STORAGE

PART VI LAYOUT AND STORAGE


YOUR CABINET WAS DESIGNED TO STORE A MAXIMUM NUMBER OF BOTTLES SECURELY. WE RECOMMEND THAT YOU OBSERVE THE TIPS BELOW TO OPTIMIZE LOADING.

- 1. Disperse your bottles even so as not to concentrate weight in any one area. Also, be careful that your bottles do not touch either the back of the cabinet or the step at the bottom.
- 2. Also make sure that bottles are not all grouped together either at the top or bottom of the cabinet.
- 3. Never try to pull out more than one rolling shelf at a time.
- 4. Maximum capacity per shelf is 55 lbs
- 5. Storage in details for different models (see diagram below):



KBU-50 storage

• Each rolling shelf is designed to hold one row of 8 bottles. The bottom small shelf can hold 6 bottles.



• Each rolling shelf is designed to hold one row of 11 bottles. You can also fit 5 bottles on the bottom of the cabinet itself.



Before modifying your cabinet's original configuration in any way, be sure to ask your dealer for advice.

REMOVING SHELF

PART VII REMOVING THE ROLLING SHELF

TO REMOVE A ROLLING SHELF:

- 1. Remove all bottles
- 2. Pull the shelf out as far as possible
- Push the LEFT side lever downward but RIGHT side lever upward (as illustrated below)
- 4. Remove the shelf



CLEANING YOUR WINE CELLAR



WARNING

BEFORE CLEANING: Turn off the power, unplug the appliance, and remove all items including all shelves.



- Wash the shelves with a mild detergent solution.
- Wring excess water out of the sponge or cloth when cleaning area of the controls, or any electrical parts.
- Wash the outside cabinet with warm water and mild liquid detergent. Rinse well and wipe dry with a clean soft cloth.
- Dust the front grill and back of the unit twice yearly. Make sure the power is off before cleaning.
- It is recommended to clean the unit completely inside and out once a year to maximize the longevity of the wine cellar.

POWER FAILURE

Most power failures are corrected within a few hours and should not affect the temperature of your appliance if you minimize the number of times the door is opened. If the power is going to be off for a longer period of time, you need to take the proper steps to protect your contents.

VACATION TIME

Short vacations: You may leave the Wine Cellar operating during vacations of less than three weeks.

Long vacations: If the appliance will not be used for several months, remove all items and turn off the appliance. Clean and dry the interior thoroughly. To prevent mold growth, leave the door open slightly, blocking it open if necessary.

MOVING YOUR WINE CELLAR

- 1. Remove all items.
- 2. Securely tape down all loose items (shelves) inside your appliance.
- 3. Turn the adjustable leg up to the base to avoid damage.
- 4. Tape the door shut.
- 5. Be sure the appliance stays secure in the upright position during transportation. Also protect the outside of the appliance with a blanket or similar item.

ENERGY SAVING TIPS

The wine cellar should be located in the coolest area of the room, away from heat producing appliances, and away from direct sunlight.

COMPRESSOR WINE CELLAR



TECHNICAL DATA

PART X TECHNICAL DATA

MODEL NO.	KBU-170S	KBU-120S	KBU-50S
ACCOMMODATION (BOTTLES)	170	120	50
TYPE OF COOLING	compressor with air-circulated fan cooling	compressor with air-circulated fan cooling	compressor with air-circulated fan cooling
CLIMATE TYPE	N	N	N
ELECTRICITY PROTECTION GRADE	I	I	I
NOMINAL VOLTAGE/ FREQUENCY	110-115V/50-60HZ	110-115V/50-60HZ	110-115V/50-60HZ
RATED POWER(W)	200W	190W	140W
AMBIENT TEMPERATURE	32 - 100 °F	32 - 100 °F	32 - 100 °F
TEMPERATURE RANGE	41-64 °F	41-64 °F	41-64 °F
NET WEIGHT	286.60 lbs (130 KGS)	198.41 lbs (90 KGS)	112.43 lbs (51 KGS)
GROSS WEIGHT	310.85 lbs (141 KGS)	224.87 lbs (102 KGS)	121.25 lbs (55 KGS)
DIMENSION	23.54"W x 26.97"D x 71.69"H (598W x 685D x 1821H mm) Included stand height 0.98" (25mm)	23.54"W x 26.97"D x 55.43"H (598W x 685D x 1408H mm) Included stand height 0.98" (25mm)	23.42"W x 23.62"D x 33.86"H; 595W x 600D x 860H mm) Note: Included stand height 0.79" (20mm)



COMPRESSOR WINE CELLAR





PART XI WARRANTY INFORMATION

Please speak to your Retailer before calling **BTO AMERICA LIMITED** if you did not purchase your Wine Cellar directly from **BTO AMERICA LIMITED**

Limited warranty – 90 day replacement plan with a free 9 months upgrade, totaling 1 year, on parts and labor from the date of shipment. For customer service, please contact **BTO AMERICA LIMITED** by e-mail (service@kingsbottle.com).

The limited warranty does not cover: Damage due to such things as accident, misuse, abuse, mishandling, neglect, unauthorized repair or any other cause beyond the control of the seller whether similar or dissimilar to the foregoing. Purchaser understands and acknowledges that the goods sold here are wine cellars, which house wine. Purchaser assumes all the risk of using these units, including risk of spoilage, humidity variations, temperature variations, leaks, fires, water damage, mold, mildew, dryness and similar perils that may occur.



