
30" Electric Downdraft Slide-In

MODELS:

664.42793710 (Stainless)

© 2017 Sears Brands, LLC


COOKTOP PARTS



COOKTOP PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W11024189	Instructions, Installation
	W11024197	Sheet, Tech
	W10400065	Guide, Quick Start (French)
	W10750127	Wiring Diagram
	W10817089	Template, Downdraft
2	W10225448	Spring, Element
3	3196178	Screw
4		Cooktop
	W11041760	Stainless
5	W10275048	Element (3000/1400W)
		(Left Front)
6	8273994	Element (1200W)
		(Right Rear)
7	W10251108	Element (3200W)
		(Right Front)
8	W10342780	Element (1300W)
		(Left Rear)
9	W10575593	Air Grill
10	W10613286	Bracket, Radiant
11	W10561812	Pan, Radiant
12	W10162253	Brace, Corner (Left)
	W10162252	Brace, Corner (Right)
13	W10289169	Support, Cooktop (Right)
	W10289170	Support, Cooktop (Left)
14	3196173	Screw
15		Endcap
	W10555937	Stainless (Left)
	W10555940	Stainless (Right)
16		Console
	W11033397	Stainless
17	W10578768	Switch, Infinite (Right Rear)
18	W10437094	Switch, Infinite (Right Front and Left Rear)
19		Knob
	W10921930	Stainless (Right Rear)
	W11022665	Stainless (Left Rear)
	W10911318	Stainless (Right Front)
	W10921932	Stainless (Left Front)
20	W10598048	Bracket, Console (Center)
21	W10919899	Control MRC2
22	W10645947	Grommet
23		Vent, Trim Top
	W10636529	Stainless
24	3196068	Lens, Indicator
25	W10555923	Bracket, User Interface
26	7101P485-60	Screw, Anti-Tip Kit
27	W10606241	Bracket, Anti-Tip
28	W10664705	Bumper
29	W10759325	Assembly, Display
30	7201P077-60	Gasket, Infinite Switch
31		Console, Lower Panel
	W10743276	Stainless
32		Bezel
	W10915432	Stainless
33	W10558372	Bracket, Control
34	W10437092	Switch, Infinite
35	W10757531	Keypad, Shield
		FOLLOWING PARTS NOT ILLUSTRATED
	W10908775	Harness, Main
	W10575120	Harness, Keypad
	W10598170	Harness, Display
	W10580264	Harness, Console
	W10580253	Harness, Cooktop
	W10812964	Harness, Jumper
	W10664316	Clip, Harness


CHASSIS PARTS



CHASSIS PARTS

Illus. No.	Part No.	Description
1	W10289077	Receiver, Hinge
2	3196560	Screw
3		Panel, Side
	W10162245	Black
4	3400029	Nut
5	W10162385	Gasket, Door
6	W10544952	Element, Broil
7	W10774342	Element, Bake
8	W10362924	Screw
9	W10613792	Assembly, Flue
10	W10289168	Box, Burner Sl
11	W10341186	Assembly, Front Foot
12	W10067840	Screw
13	W10541959	Shield, Bake
14	W10137382	Clip, Panel
15	W10390008	Assembly, Base Rail (Left)
	W10390007	Assembly, Base Rail (Right)
16	W10058460	Foot, Leveling
17	3196548	Fuse, Thermal
18	3196172	Screw
19	W10035900	Support, Oven Bottom
20	3186034	Bracket, Service
21	W10246624	Block, Terminal
22	W10828883	Bracket, Panel (Left)
	W10828882	Bracket, Panel (Right)
23	3196178	Screw
24	W10454648	Assembly, Light
25	311255	Bulb, Oven Light
26	3400016	Screw
27	W10586204	Sensor
28	3196169	Screw
29	W10655441	Shield, Power Cord
30	W10031780	Screw
31	W10273192	Rod, Door Switch
32	9758701	Spacer, Door
33	W10774446	Bottom, Oven
34	W10627802	Switch, Door
35	W10281322	Kit, Bare Wire Adapter Block
36	W10603482	Rack, Ladder
37	W10874472	Assembly, Convection
38	W10554262	Baffle, Full Convection
39	W10273002	Bracket, Oven Support
40	W10346147	Pan, Bake
41	W10162255	Duct, Cover
42	W10162254	Duct, Cooling
43	W10877642	Assembly, Cooling Fan
44	W10813366	Shield, Wire
45	W10162241	Channel, Rear
46	W10162248	Cover, Wire
47	W10289172	Cover, Back
48	W11033103	Kit, Reservoir (Steam Rack)
49	W10554007	Rack, Steam
50	W10554006	Rack, Maximum Capacity
51	W10911366	Rack, Sliding
52	W10624592	Cord, Power
		FOLLOWING PARTS NOT ILLUSTRATED
	W10289173	Insulation, Wrap
	W10575374	Insulation, Bottom
	4820F015-59	Insulation, Strap
	W10162240	Insulation, Back
	7111P017-60	Clamp, Wire


BLOWER PARTS



BLOWER PARTS

Illus. No.	Part No.	Description
1	W10661156	Enclosure, Blower
2	W10572224	Plenum, Intake
3	W10572145	Plenum, Upper
4	W10575379	Grease, Filter
5	W10575393	Guard, Filter
6	W10789431	Kit, Plenum Transition
7	W10789391	Kit, Blower Installation
8	W10810492	Kit, Blower
9	W10788527	Assembly, Capacitor
10	W10787917	Cover, Capicator
11	W10661835	Plenum, Side
12	W10702071	Retainer
13	W10759311	Gasket, Blower
14	W10642096	Adaptor, Exhaust
15	W10789390	Assembly, Plenum Support Bracket


DOOR PARTS



DOOR PARTS

Illus. No.	Part No.	Description
1		Assembly, Door Handle
	W10917609	Stainless
2	9780274	Screw
3		Badge
	W10403224	Stainless
4	W10826568	Liner, Door
5	W10031790	Screw
6	W10813616	Glass, Inner
7	W10885517	Hinge, Slow Close
8		Assembly, Outer Door
	W10921447	Stainless
9	W10541911	Bracket, Glass Upper Handle
10	W10327235	Screw
11	W10813140	Rail, Horizontal Support
12	W10031780	Screw
13	W10296816	Screw
14	W10813139	Rail, Vertical Support
15		Scoop, Door
	W10613791	Black
16	W10319024	Washer, Door
17	W10813142	Spacer, Glass
18	W10917611	Handle, Standoff

DRAWER PARTS



DRAWER PARTS

Illus. No.	Part No.	Description
1	3196169	Screw
2		Panel, Drawer Front
	W10602484	Stainless
3	W10318026	Bracket, Mounting
4	8004P024-60	Spacer, Side Panel
5	W10798390	Baffle, Drawer Panel

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

Illus. No.	Part No.	Description
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus. No.	Part No.	Description
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

Illus. No.	Part No.	Description
	799344	White (Uncut)

REFINISHING MATERIAL

Illus. No.	Part No.	Description
	242756	Oven Liner Touch Up Paint

INSULATION

Illus. No.	Part No.	Description
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

ACCESSORY PARTS

Illus. No.	Part No.	Description
		CLEANERS / POLISHES
	31605	Kit, Cooktop Care
	31463A	Protectant, Cooktop
	W10355051	Cleaner, Cooktop
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10355049	Wipes, Stainless Steel Cleaning
	W10355010	Cleaner, Kitchen & Appliance
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	W10432019	Alt Cleaning Kit
	W10391473	Pad, Cooktop Cleaning
		MISCELLANEOUS
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting
	W10432539	Griddle
	W10432545	Kit, Grill
	242905	Kit, Canning Unit
		TRIM KITS
	W10675026	Black
	W10675027	White
	W10675028	Stainless
		BACKSPLASH ASSEMBLY
	W10655449	Black
	W10655448	White
	W10655450	Stainless