



Step 1

24 hours before the application of your wallpaper or mural, applied a premixed, clear wallpaper primer to your wall of choice. This will prepare the wall and ensure that future removal is easy and effortless.



Step 2

Once your primer is in place, you're ready to go! If you are applying wallpaper, measure your wall from top to bottom to determine how tall your pieces must be. Cut the individual panels or pieces apart from the roll. Then loosely roll up your first section with the prepasted side facing out.



Step 3

Dip the rolled paper into clean, lukewarm water and roll it over a few times. This process is called booking. Don't worry about the water causing any damage: our wallpaper products are all water resistant.



Step 4

Remove the rolled panel and allow the excess water to drip away. The panel may uncurl slightly in your hands, which is just fine. Ensure that all of the adhesive is moistened before proceeding.



Step 5

Unroll the paper and bring it to the wall. Press it firmly to the surface and smooth with your hands from top to bottom. If you need to move it, slide the section carefully on the wall until it is in place.



Step 6

After smoothing the paper with your hands, use a slightly damp sponge or soft brush to flatten it completely to the wall. Work out any air bubbles or pockets by pushing them carefully to the side. If any paste appears on the panel, paper, or wall, just wipe it away with your sponge. Trim any excess paper away with a sharp knife.



Step 7

Cut your next panel or piece off of the strip and follow steps 2-6. When you apply the next panel, do not overlap or leave gaps between the seams. Our SureStrip™ technology ensures that panels and seams do not shrink application, so no overlap is needed.