



PART#: 86611 Installation Instructions

Rampage Hitch for Recovery Bumper 2 & 4-door 2007-2014

PARTS LIST

2- 12mm x 30mm Flanged bolts 2- 12mm Lock Washers 2- 12mm Flat Washers

PROCEDURE:

1. **REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY.**
2. Remove two 114.6 MM bolts from center inside mount position of bumper. If mounting in conjunction with Rear bumper 86605 place hitch on at step # 3d.
3. Hold hitch in place and replace long bolts and washers
4. Place two 12mm bolts and washers up through the bottom of the hitch into the bumpers pre-threaded holes.
5. Tighten all bolts to 45-foot pounds torque.

This hitch is not rated for towing

For Technical Support, please call (951) 277-4949

This product is guaranteed to be free of defects in materials and workmanship for a period of 12 months

Rampage Products Corona Ca.

Made In China

Part # 86611

Page

1

of

1

05-06-13