

8.2
Megapixels

3X
Optical Zoom

2.4"
LCD Screen

Kodak EasyShare C813

Zoom Digital Camera

Great shots. Exceptional price.

The KODAK EASYSHARE C813 Zoom Digital Camera takes such beautiful pictures, you'll want to keep them all. With 8.2 MP, 3X zoom and digital image stabilization, you get striking, accurate shots time after time. But the pictures aren't all you'll keep. The C813 Zoom Digital Camera comes at a price that lets you keep money right where you like it—in your pocket.

Steady it. Reduce blur caused by camera shake or subject movement with digital image stabilization

Get it. Capture the details in low-light conditions and fast-action situations with high ISO (up to 1250)

Sharpen it. HD still capture lets you view your pictures in high definition on an HDTV or other HD device

Direct it. Record life in motion with continuous VGA video featuring audio capture, playback, on-camera editing and prints from video (1, 4, 9 and 16-up)

Choose it. Get great shots time after time with 16 programmed scene and 3 color modes

Improve it. Achieve your perfect shot with on-camera picture-enhancing features: cropping, blurry picture alert, red-eye reduction and undo-delete

Dock it. Works with optional KODAK EASYSHARE Printer Docks, Photo Printer and Camera Docks

Digital image stabilization

Reduce blur caused by camera shake or subject movement.

Shoot video with ease
Featuring on-camera editing and prints from video (1, 4, 9, 16-up).



KODAK PERFECT TOUCH Technology
Create better, brighter, more vivid pictures and clear up dark shadows right on the camera.

Capture it. **Kodak**

Kodak EasyShare C813

Zoom Digital Camera

Standard features

Sensor type	1/2.5" CCD
CCD total pixels	8.3 MP (3320x2496)
Effective pixels	8.2 MP (3312x2488)
Lens	36-108 mm (35 mm equiv.) f/2.7-4.8, 2 step aperture
Lens barrier	built-in lens barrier
Zoom	3X optical; 5X continuous digital with LCD preview, 0.2X increments starting at 3X optical zoom
Image stabilizer	digital
Shutter speed	1/2-1/1400 second
LCD	6.1 cm (2.4") indoor/outdoor color display, 480x240 (115K pixels)
Storage	16 MB* internal memory, SD/MMC Card expansion slot

Auto focus

Type	TTL-AF
Focus modes	normal, landscape, macro
Focus range	normal: 0.6 m (2.0')-infinity; macro, wide: 0.13-0.7 m (5.1"-2.3'); macro, tele: 0.22-0.7 m (8.7"-2.3'); landscape 10 m (32.8')-infinity
Zones	Multi-zone and center-zone

Exposure control

ISO sensitivity	auto 80-200, manual 80, 100, 200, 400, 800, 1250
Metering	TTL-AE, multi-pattern, center-weighted, center spot
Compensation	±2.0 EV with 0.5 EV steps
AE lock	when S1 locked
White balance	auto, daylight, tungsten, fluorescent, open shade

Flash

Range	0.6-3.6 m (2'-11.8') at wide, ISO 200; 0.6-2.1 m (2'-6.9') at tele, ISO 200
Modes	auto, fill, red-eye reduction, off

Shooting specifications

Drive modes	self-timer, 2-sec., 10-sec., 2-shot
Shooting modes	auto, SCN, video, digital IS, close-up, Favorites
Scene modes	portrait, night portrait, landscape, night landscape, sports, snow, beach, text/document, backlight, museum/manner, fireworks, high ISO, children, flower, self-portrait, sunset
Click to capture	<0.3 sec. (wide, preview off, flash off)
Shot to shot	<1.5 sec. until buffer full

Still capture

Still format	JPEG/EXIF v 2.21
Picture size	8.1 MP - (3296x2472)
(recorded pixels)	7.3 MP (3:2) - (3296x2196)
	6.1 MP (16:9) - (3296x1854)
	5.0 MP - (2592x1944)
	3.1 MP - (2048x1536)
	2.2 MP (3:2) - (1800x1200)
	2.1 MP (16:9) - (1920x1080)
	1.2 MP - (1280x960)

Compression	JPEG standard
Color modes	color, sepia, black and white
Review options	album, edit picture, slide show, multi-up, copy, protect, image storage, set-up menu, view by, undo-delete
Editing	crop, KODAK PERFECT TOUCH Technology

Video capture

Format	QUICKTIME Motion JPEG with audio recording
Quality	VGA (640x480 pixels) at 15 fps, QVGA (320x240 pixels) at 30 fps
Length	continuous based on memory capacity up to 80 min.
Review options	view by, protect, album, copy, slide show, multi-up, image storage, set-up menu
Editing	trim, make picture, action print (1, 4, 9, 16-up)

Customization

Custom settings	camera sounds, LCD brightness, auto power off, date & time, date stamp, video date display, blur warning, language, format, about
-----------------	---

Favorites

Favorites	slide show, multi-up, remove Favorites, set-up menu
-----------	---

Physical specifications

I/O interface	KODAK Camera Dock/Printer Dock interface, digital (USB 2.0) connection
---------------	--

Power	2 AA Ni-MH batteries, 2 AA Lithium batteries, KODAK Ni-MH 2100 mAh Battery Pack, KODAK Digital Camera Battery AA (ZR6), 2 AA alkaline batteries, optional KODAK EASYSHARE Docks
Dedicated buttons	menu, review, Share, delete, display/info, zoom, 5-way control, (top) power, flash setting, shutter, mode dial
Tripod mount	1/4" standard
Dimensions	WxHxD: 91x65.7x37.25 mm (3.6"x2.6"x1.5")
Weight	without batteries: 137 g (4.8 oz.)
Compatibility	
Dock compatibility	works with KODAK EASYSHARE G610 Printer Dock, KODAK EASYSHARE G600 Printer Dock, KODAK EASYSHARE Camera Dock Series 3
Direct print	KODAK EASYSHARE Photo Printer 500, IMAGELINK Print System compatible, PICTBRIDGE enabled
Software	works with KODAK EASYSHARE Software

Service and support

Warranty	one year
----------	----------

Minimum system requirements

WINDOWS	WINDOWS XP OS or later, 600 MHz processor or greater; 128 MB RAM; INTERNET EXPLORER 6.0 or higher
MACINTOSH	MACINTOSH OS X 10.3 or higher

Minimum hardware requirements

128 MB RAM; 200 MB hard drive disk space available; CD-ROM drive, available USB port; color monitor, 800x600 display resolution, 16-bit minimum

Package contents

KODAK EASYSHARE C813 Zoom Digital Camera	
KODAK Alkaline AA Batteries or equivalent	
USB cable	
Wrist strap	
Getting started guide	
KODAK EASYSHARE Software	
Custom camera insert for optional KODAK EASYSHARE Camera and Printer Docks	

Ordering information

KODAK EASYSHARE C813 Zoom Digital Camera (U.S. and Canada) 123 3238

Recommended accessories

KODAK EASYSHARE G610 Printer Dock	881 1507
KODAK Color Cartridge & Photo Paper Kit/G-200	191 2070
KODAK EASYSHARE Camera Dock Series 3	188 6597
KODAK SD High Performance Memory Card, 1 GB	188 5862
KODAK Ni-MH 2100 mAh Rechargeable Digital Camera Battery	815 6572
KODAK Ni-MH Rapid Battery Charger Kit	105 3701
KODAK Cobalt Blue Camera Bag/mini	866 2660
KODAK Small Camera Bag	133 7443
KODAK Travel Kit	103 6375
KODAK EASYSHARE Camera Dock Kit	106 5556
KODAK Fashion Jewelry Neck and Wrist Straps	
Silver	177 5089
Red	116 5042
Turquoise	832 6936
Pink	111 5427
Black	137 3737
Multicolored	888 9529

*16 MB internal memory/10 MB available for picture storage (1 MB equals one million bytes).

For more information on the KODAK EASYSHARE C813 Zoom Digital Camera, visit www.kodak.com/go/easyshare



Product specifications subject to change without prior notice. Simulated screen images.

© Kodak, 2007. KODAK, EASYSHARE, PERFECT TOUCH, IMAGELINK and the IMAGELINK Print System logo are trademarks of Kodak. QUICKTIME and the QUICKTIME logo are trademarks of Apple Inc, registered in the U.S. and other countries. USB-IF logos are trademarks of Universal Serial Bus Implementers Forum, Inc. IC-1351 CAT No. 812 0149