



48" 13-in-1 Combo Table



Please keep this instruction manual for future reference

**If you have any problems with your new product,
please contact Triumph Sports USA at 1-866-815-4173,
or e-mail us at csr@triumphsportsusa.com
for any technical support or warranty issues.**

Limited 90-Day Triumph Sports USA, Inc. Warranty

All Triumph Sports USA, Inc. (TSU) games have a limited 90-day from date of purchase warranty. This warrants the retail purchaser for any TSU game purchased to be free from any defect in materials and construction for 90 days from the date of purchase. The only exceptions to the warranty include main frames, tabletops, playing surfaces, batteries or tools. Damaged main frames, tabletops, playing surfaces need to be returned to the store as we are unable to replace these parts. Normal play wear and usage is not covered under the warranty, nor is wear or damage due to improper use of the TSU game. This will void any and all TSU warranties.

A PURCHASE RECEIPT (or other proof of purchase date) will be required before any warranty service is initiated. All requests for warranty service can be submitted by email, in writing or by contacting our Customer Service Department at: 1-866-815-4173 or email us at csr@triumphsportsusa.com.

IMPORTANT NOTICE! Please contact us before returning the product to the store.

Warnings



WARNING: Choking Hazard—Product contains small balls and/or small parts.
Not for children under 3 years of age.

Be sure to check out all the exciting games  **has to offer.**

Visit our web site at:

www.triumphsportsusa.com



BILLIARDS



DARTS



GAME TABLES



CASINO



OUTDOOR GAMES



































DARTBOARDS

Triumph Sports USA
11327 W Lincoln Ave.
West Allis, WI 53227

www.triumphsportsusa.com

©2014 Triumph Sports USA. All Rights Reserved.

<p>1</p>  <p>Billiard Cabinet 1PC</p>	<p>2</p>  <p>Hockey Table With Table Tennis 1PC</p>	<p>3</p>  <p>Chess With Backgammon Checker 1PC</p>	<p>4</p>  <p>Left Leg-A 1PC</p>
<p>5</p>  <p>Right Leg-A 1PC</p>	<p>6</p>  <p>End Leg Brace-A 1PC</p>	<p>7</p>  <p>Baseball With Football Board 1PC</p>	<p>8</p>  <p>Basketball Board With Darts 1PC</p>
<p>9</p>  <p>Bean Bag With Tic-Tac-Toe 1PC</p>	<p>10</p>  <p>Leg Leveler 4PCS</p>	<p>11</p>  <p>Table tennis Post 2PCS</p>	<p>12</p>  <p>Rivet Plug 4PCS</p>
<p>13</p>  <p>Basketball Net 1PC</p>	<p>14</p>  <p>Rim 1PC</p>	<p>15</p>  <p>Basketball Return Net 1PC</p>	<p>16</p>  <p>Felt Pad 2PCS</p>
<p>17</p>  <p>Hockey Pusher 2PCS</p>	<p>18</p>  <p>Hockey Puck 2PCS</p>	<p>19</p>  <p>Chalk 2PCS</p>	<p>20</p>  <p>Billiard Ball 1PC</p>
<p>21</p>  <p>Triangle 1PC</p>	<p>22</p>  <p>Cues 2PCS</p>	<p>23</p>  <p>Table Tennis Net 1PC</p>	<p>24</p>  <p>Table Tennis Ball 2PCS</p>
<p>25</p>  <p>Table Tennis Bat 2PCS</p>	<p>26</p>  <p>Baseball 1PC</p>	<p>27</p>  <p>Air Pump 1PC</p>	<p>28</p>  <p>Storage Bag 1PC</p>
<p>29</p>  <p>Soccer Net 1PC</p>	<p>30</p>  <p>Bean Bag – Red 4PCS</p>	<p>31</p>  <p>Bean Bag – Blue 4PCS</p>	<p>32</p>  <p>Chess Set 1PC</p>




























<p>33</p>  <p>Backgammon Checker Set 1PC</p>	<p>34</p>  <p>Soccer ball 1PC</p>	<p>35</p>  <p>Brush 1PC</p>	<p>36</p>  <p>Launcher 1PC</p>
<p>37</p>  <p>Dice Box 1PC</p>	<p>38</p>  <p>Dice 5PCS</p>	<p>39</p>  <p>Bracket 2PCS</p>	<p>40</p>  <p>Darts 6PCS</p>
<p>41</p>  <p>Basketball 1PC</p>	<p>42</p>  <p>Dart Board Guide Bracket 2PC</p>	<p>43</p>  <p>Hook 5PCS</p>	<p>44</p>  <p>Basketball hook 2PCS</p>
<p>45</p>  <p>Football 1PC</p>	<p>46</p>  <p>6x33mm Bolt 24PCS</p>	<p>47</p>  <p>6mm washer 48PCS</p>	<p>48</p>  <p>6mm Nut 24PCS</p>
<p>49</p>  <p>4 x 15mm Flat Head Screw 8PCS</p>	<p>50</p>  <p>4 x6mm Round Head Screw 6PCS</p>	<p>51</p>  <p>4 x12mm Round Head Screw 6PCS</p>	<p>52</p>  <p>4 x18mm Flat Head Screw 10PCS</p>
<p>53</p>  <p>Bean bag cup-large 1PC</p>	<p>54</p>  <p>Bean bag cup-medium 1PC</p>	<p>55</p>  <p>Bean bag cup-small 1PC</p>	<p>56</p>  <p>Wrench 1PC</p>
<p>57</p>  <p>Left Leg-B 1PC</p>	<p>58</p>  <p>Right Leg-B 1PC</p>	<p>59</p>  <p>End Leg Brace-B 1PC</p>	

FIG. 1




FIG.1

1. Attach the Legs (#4#5#57#58) to the Billiard Cabinet (#1) using four Bolts (#46), four Nuts (#48) and eight Washers (#47) per leg.
2. Attach the End Leg Braces(#6#59)to the Legs Using four Bolts(#46),four Nuts (#48)and eight Washers(#47) per End Leg Brace.

FIG. 2






FIG.2


3. Attach the Soccer Net(#29)to the Legs using four Leg Leveler(#10).two screw(#51).

FIG. 3**FIG. 3****FIG.3**

4. Remove the paper from the Felt Pads(#16)and stick them to the bottom of the Pushers(#17).

5. Place the Hockey Table with Table Tennis(#2)on the Billiard Cabinet to Play Glide Hockey using the Pushers(#17)and Puck(#18).

6. Turn the Hockey Table Top over to the Table Tennis Top (#2) on the Billiard Cabinet. Then insert the Net Posts (#11) and Net (#23) to play Table Tennis.

FIG. 4**FIG.4**

7. Attach the Brackets (#39)to the Leg using two Screws(#52). Attach per Leg one Hook (#43)to the Leg and End apron using two Screws (#52). At the opposite end of the table attach the Hooks (#43) to the End Leg Brace using two screws (#49).

8. Attach the Dart Board Guide Brackets (#42)to the end panel using two Screw(#51).

FIG. 5




FIG.5

9. To play the Baseball/Football game lean the Game Board (#7) against the Hockey Table/TableTennis Board (#2) as shown. Put game Board (#3) (Chess,Backgammon,Checkers) in front of Board (#7) to prevent it from sliding down.

FIG. 6




FIG.6

10. Attach the Basketball Rim (#14) to the Backboard (#8) using four Screws (#49). Install the Basketball Net (#13) to the Rim (#14).

11 . Attach the Basketball hooks(#44)to the Backboard(#8).

FIG. 7




FIG. 7

12. Attach the Bean Bag Cups (#53,#54,#55)to the Bean Bag Board(#9)using two screws (#50) per cup.

FIG. 8




FIG. 8

FIG. 8

13. Hang the Backboard(#8) onto the Table Tennis Board(#2) using Basketball Hooks (#44).

14. To play Bean Bag Toss hang the Bean Bag Board(#9)onto the hooks(#43) as shown in Fig. 8. To play Tick Tack Toe Bag Toss, game board (#9) must be removed from the hooks and laid flat on the floor.

FIG. 9




FIG.9

15. Attach the Basketball Return Net(#15)to the Table Tennis(#2)and Billiard Cabinet(#1)using the fastener straps and four Rivet Plugs(#12).

FIG.10




FIG.10

Stow away Instructions

16. Fold the rim (#14) against the Basketball Board (#8). Please follow the diagram for the proper order to stow the game boards. Make sure the Game Board (#9) with the cups facing outward is the last game stored in the brackets.

17. Hang the storage Bag (#28) on the Rivet Plug (#12).