
SEARS
Parts & Repair Services

REPAIR PARTS LIST

253.76120410
253.76120411
253.76120412
253.76120413



ROOM AIR CONDITIONER

In all orders or correspondence, avoid delays and misunderstandings by always giving the complete model number shown on the front of the base, behind the plastic front cover.

All repair parts listed are available for immediate purchase or special order when you visit your nearest Sears Parts & Repair Center, or the Service Department at most Sears stores. To order parts by phone, call the toll-free number listed to the left or visit sears.com.

When requesting service or ordering parts, always provide the following information:

- **Product Type**
- **Model Number**
- **Part Number**
- **Part Description**


For Parts or Service:
Call
1-800-4-MY-HOME®
(1-800-469-4663)

Or Visit
www.sears.com

Sears Brands Management Corporation, Hoffman Estates, IL 60179
Publication number 5995642971

RECOMMENDED SPARE PARTS

CAUTION: Use the Kenmore part number to order part, not the illustration number.



25386100410-spares

RECOMMENDED SPARE PARTS

CAUTION: Use the Kenmore part number to order part, not the illustration number.


Model Index: A 253.76120 (253.76120410)
B 253.76120 (253.76120411)
C 253.76120 (253.76120412)
D 253.76120 (253.76120413)

POS. NO	PART NO.					DESCRIPTION
1 #	5304495109	A	B	C	D	Front Assembly, complete panel
2	5304476174	A	B	C	D	• Panel, front grille, tilt-out
3 #	5304476175	A	B	C	D	• Filter, air, plastic frame
4 #	5304495110	A	B	C	D	• Panel, frame, front, with louvers
5 #	5304476177	A	B	C	D	PC Board, display/input
6 #	5304482356	A	B	C	D	• Wire, connecting
7 #	5304476178	A	B	C	D	Door, vent control, with lever
8 #	5304476179	A	B	C	D	Sleeve, vent door assy, guide
9 #	5304476180	A	B	C	D	Power Cord, electric, LCDI
10 #	5304495111	A	B	C	D	Remote Control, transmitter
11	5304476182	A	B	C	D	Cover, control box
12 #	5304471275	A	B	C	D	Sensor, evap temp, thermistor
13 #	5304487548	A	B	C	D	Sensor, ambient temp, thermistor
14 #	5304495095	A	B	C	D	PC Board, control/power, main
15	5304471203	A	B	C	D	Strap, capacitor clamp
16 #	5304495126	A	B	-	-	Capacitor
16 #	5304495136	-	-	C	D	Capacitor
17	5304492004	A	B	C	D	Control Box
18 #	5304495127	A	B	C	D	Evaporator, with, capillary tube
19 #	5304495128	A	B	C	D	• Tube, capillary
20 #	5304495129	A	B	-	-	Compressor, with overload
20 #	5304495137	-	-	C	D	Compressor, with overload
21 #	5304495138	-	-	C	D	• Overload Protector, compressor
22 #	5304495130	A	B	-	-	Tube, suction
22 #	5304495139	-	-	C	D	Tube, suction
23 #	5304495131	A	B	-	-	Tube, discharge
23 #	5304495140	-	-	C	D	Tube, discharge
24 #	5304495132	A	B	C	D	Condenser
25 #	5304476201	A	B	C	D	Filter-drier
26	5304495101	A	B	C	D	Base, unit chassis
27	5304485967	A	B	C	D	Scroll, blower housing, bottom
28	5304495102	A	B	C	D	Scroll, blower housing, middle
29	5304495103	A	B	C	D	Enclosure, air duct
30	5304485969	A	B	C	D	Scroll, blower housing, top
31 #	5304485443	A	B	C	D	Blower Wheel, centrifugal fan
32 #	5304495133	A	B	C	D	Motor, fan
33 #	5304476059	A	B	C	D	Fan Blade, axial
34	5304495104	A	B	C	D	Shroud, condenser/fan
35	5304476197	A	B	C	D	Retainer, shutter, cabinet sides
36	5304476198	A	B	C	D	Cabinet, wrapper/sleeve
37	5304476199	A	B	C	D	Rail, shutter track, top angle
38	5304472191	A	B	C	D	Screw Kit, top rail mount
39	5304476200	A	B	C	D	Window Filler Kit, slider panels, accordion
40	5304491953	A	B	C	D	Hardware, mounting, screws/locks
41	5304472211	A	B	C	D	Seal Kit, foam, sash filler
*	5304495118	A	B	C	D	Use & Care Guide
*	5304495106	A	B	C	D	Installation Instructions
*	5304495135	A	B	-	-	Tech Data Sheet/Wiring Diagram
*	5304495141	-	-	C	D	Tech Data Sheet/Wiring Diagram
*	5995642971	A	B	C	D	Repair Parts List
*	5304495134	A	B	C	D	Energy Guide

Functional Parts
* Non-Illustrated Parts

WIRING DIAGRAM

OPP/MSII/COMI/COMII Electronic without Ionizer --- 202021190003



Get it fixed, at your home or ours!

Your Home

For troubleshooting, product manuals and home solutions advice:

manage my home

www.managemyhome.com

For repair – **in your home** – of **all** major brand appliances, lawn and garden equipment, or heating and cooling systems, **no matter who made it, no matter who sold it!**

For the replacement parts, accessories and owner's manuals that you need to do-it-yourself.

For Sears professional installation of home appliances and items like garage door openers and water heaters.

1-800-4-MY-HOME® **(1-800-469-4663)**

Call anytime, day or night (U.S.A. and Canada)

www.sears.com **www.sears.ca**

Our Home

For repair of carry-in items like vacuums, lawn equipment, and electronics, call anytime for the location of your nearest

Sears Parts & Repair Service Center

1-800-488-1222 (U.S.A.) **www.sears.com**

1-800-469-4663 (Canada) **www.sears.ca**

To purchase a protection agreement on a product serviced by Sears:

1-800-827-6655 (U.S.A.) **1-800-361-6665** (Canada)

Para pedir servicio de reparación a domicilio, y para ordenar piezas:

1-888-SU-HOGAR®

(1-888-784-6427)

www.sears.com

Au Canada pour service en français:

1-800-LE-FOYER^MC

(1-800-533-6937)

www.sears.ca

Sears

® Registered Trademark / ™ Trademark of KCD IP, LLC in the United States, or Sears Brands, LLC in other countries
® Marca Registrada / ™ Marca de Fábrica de KCD IP, LLC en Estados Unidos, o Sears Brands, LLC in otros países
^MC Marque de commerce / ^MD Marque déposée de Sears Brands, LLC