



**REPAIR
PARTS
LIST**

253.77125410


For Parts or Service:

Call

**1-800-4-MY-HOME®
(1-800-469-4663)**

Or Visit

www.sears.com



ROOM AIR CONDITIONER

In all orders or correspondence, avoid delays and misunderstandings by always giving the complete model number shown on the front of the base, behind the plastic front cover.

All repair parts listed are available for immediate purchase or special order when you visit your nearest Sears Parts & Repair Center, or the Service Department at most Sears stores. To order parts by phone, call the toll-free number listed to the left or visit sears.com.

When requesting service or ordering parts, always provide the following information:


- | | |
|----------------|--------------------|
| • Product Type | • Part Number |
| • Model Number | • Part Description |

Sears Brands Management Corporation, Hoffman Estates, IL 60179

Publication number 5995659140

RECOMMENDED SPARE PARTS

CAUTION: Use the Kenmore part number to order part, not the illustration number.




25377125410-Spares

RECOMMENDED SPARE PARTSCAUTION: Use the Kenmore part number to order part, not the illustration number.

POS. NO	PART NO.	DESCRIPTION
1 #	5304476381	Front Assembly, complete panel
2	5304476382	• Panel, front grille, tilt-out
3 #	5304476383	• Filter, air
4	5304476384	• Frame, front assembly
5 #	5304476385	• Louver, horizontal
6 #	5304476386	• Louver, vertical
7 #	5304501056	Display Assembly, with pc board
8 #	5304501057	• Control Panel, with overlay
9 #	5304501058	• PC Board, display/input
10	5304501059	• Cover, display board
11 #	5304501060	• Wire, connector, pc boards
12	5304501061	Cover, blower scroll, top
13 #	5304476623	Blower Wheel, centrifugal fan
14 #	5304499948	Motor, fan
15 #	5304499949	Fan Blade, propeller
16	5304501062	Bulkhead, partition, rear
17	5304501063	Bulkhead, partition, front
18	5304501064	Bulkhead, partition, front/left
19	5304501065	Cover, blower scroll, front
20	5304501066	Scroll, blower housing, rear
21	5304501067	Scroll, blower housing, front
22 #	5304476390	Heater, electric
23	5304501068	Tray, drip pan
24 #	5304476316	Sensor, temperature, discharge air, DAHT
25 #	5304491883	Thermistor, temp sensor, indoor
26 #	5304471383	Sensor, temperature, evaporator
27 #	5304500875	Power Cord, electric, LCDI
28 #	5304495591	Remote Control, transmitter
29 #	5304471077	Capacitor, fan motor
30 #	5304471063	Transformer
31	5304501069	Clamp, capacitor
32 #	5304493239	Capacitor, compressor
33 #	5304495590	PC Board, control/power, main
34	5304495029	Holder, mounting plate, control
35	5304501070	Control Box
36 #	5304501071	Evaporator, +capillary tube
37 #	5304501072	• Tube, capillary
38 #	5304499947	Compressor, w/b-i overload
40	5304476393	Window Filler Kit, slider panels, accordion
41	5304487606	Cabinet, wrapper/sleeve
42	5304476391	Rail, shutter, top channel
43 #	5304501055	Condenser
44 #	5304501073	Tube, discharge
45 #	5304501074	Tube, suction
46 #	5304476323	Valve, drain
47	5304501075	Base, unit chassis
48 #	5304476367	Filter-drier
49	5304471258	Seal Kit, window, foam strips
50	5304491884	Hardware Kit, installation
51	5304471256	Screw Kit, top rail mount
*	5304501076	Use & Care Guide
*	5304495597	Installation Instructions
*	5304499950	Tech Data Sheet/Wiring Diagram
*	5995659140	Repair Parts List
*	5304501077	Energy Guide

WIRING DIAGRAM



202021390263

NOTE:

1. The wiring diagram is for explanation purpose only. The actual shape of the components may be different.
2. Symbol 1 indicates optional components

Get it fixed, at your home or ours!

Your Home

For troubleshooting, product manuals and expert advice:



www.managemylife.com

For repair – **in your home** – of **all** major brand appliances, lawn and garden equipment, or heating and cooling systems, **no matter who made it, no matter who sold it!**

For the replacement parts, accessories and owner's manuals that you need to do-it-yourself.

For Sears professional installation of home appliances and items like garage door openers and water heaters.

1-800-4-MY-HOME[®] (1-800-469-4663)

Call anytime, day or night (U.S.A. and Canada)

www.sears.com www.sears.ca

Our Home

For repair of "carry-ins" like handheld lawn equipment or home electronics items, call anytime for the location of your nearest

Sears Parts & Repair Service Center

1-800-488-1222 (U.S.A.)

www.sears.com

1-800-469-4663 (Canada)

www.sears.ca

To purchase a protection agreement on a product serviced by Sears:

1-800-827-6655 (U.S.A.)

1-800-361-6665 (Canada)

Para pedir servicio de reparación a domicilio, y para ordenar piezas:

1-888-SU-HOGAR[®]

(1-888-784-6427)

www.sears.com

Au Canada pour service en français:

1-800-LE-FOYER^{MC}

(1-800-533-6937)

www.sears.ca

The Sears logo, consisting of the word "sears" in a lowercase, serif font.

® Registered Trademark / TM Trademark of KCD IP, LLC in the United States, or Sears Brands, LLC in other countries

® Marca Registrada / TM Marca de Fábrica de KCD IP, LLC en Estados Unidos, o Sears Brands, LLC in otros países

^{MC} Marque de commerce / ^{MD} Marque déposée de Sears Brands, LLC