

Part Number	Part Name	Reference Number
1000350488	Connect Tube Set;Semi-Assy;;;TM438E-1US	1
1000350489	Motor set;Semi-Assy;;;TM438E-1US;;	3
1000346317	Handle set;Semi-Assy;left;;;S-TM439E;;	4
1000346319	Handle set;Semi-Assy;right;;;S-TM439E;;	5
1000350490	Console set;Semi-Assy;;;TM438E-1US;;	6
1000350491	Side Rail Set;Semi-Assy;left;;;TM438E-1U	7
1000350492	Side Rail Set;Semi-Assy;right;;;TM438E-1	8
1000343686	Console Mast-Extrawork;;left;Screen prin	AC1
1000343688	Console Mast-Extrawork;;right;Screen pri	AC2
1000346320	Sensor set;Semi-Assy;right;;;S-TM439E;;	AC3
1000346318	Sensor set;Semi-Assy;left;;;S-TM439E;;	AC4
1000226898	TUBE;#19.0x19.0x1.5Tx282L;TM439	AH2
1000343694	Sleeve Tube Set;;;painting;DM362;Black2;	AH3
1000227065	LOCK LATCH;WELDING;TM439	AH4
1000223546	CONSOLE BASE FRAME SET;-;-;PAT;DM362	AN1
1000230645	HANDLEBAR SET;L;PAINTING;DM362;TM439;	AN3
1000228346	SAFETY KEY SET;-;LS13.0T-2;CS;	AN4
1000230646	HANDLEBAR SET;R;PAINTING;DM362;TM439;	AN5
1000108436	Roller Set;Front;Texture;TM115	AR1
1000108437	Roller Set;Rear;TM116	AR2
1000232699	FIXING PLATE;TRUCKLE;R;PAINTING;DM362;TE	B15
1000232700	Fixing Plate;Roller;L;painting;DM362;San	B16
039400-BA	Transport Wheel;Nylon	B25
1000223521	TM DECK;-;-;670x1220x20T;-;-;TM438	B27
004571-00	Screw;Hex Socket;Sink;M8x1.25Px28L;Adher	B28
004979-00	Insert Nut;Hex;NHS-8125-3.0(M8x1.25P)	B39
004941-00	Nut;Nylon;M10x1.5P	B40
1000300664	Air Stick,Slow-Drop,50kg,521.5X212.5,Ste	B41
1000228077	CUSHION;;;OR;;Diam.30X20L;TM439;	B47
1000228051	CUSHION;;;BL;;Diam.30X20L;TM439;	B48
1000228052	CUSHION;;;BU;;Diam.30X20L;TM439;	B49
004730-00	Screw;Oval Hex Socket;M8X1.25PX50L	B50
004768-00	Screw;Oval;Hex Socket;BH;M8X1.25PX15L	B51
005005-00	Washer;Spring;Lock;8.2x15.4x2.0t	B53
005145-A	Washer;Flat;8.2x19.0x2.0T;Black Zinc	B54
004926-00	Nut;Nylon;M8x1.25P	B55
1000300260	Plastic Cover,Left-Rear,ABS/PA757K,Q520-	C13
1000300259	Handle set;Semi-Assy;left;;;LS10.0T-02;;	C15
1000300261	Handle set;Semi-Assy;right;;English;LS13	C19
020210-AC	Screw;Round;Tapping;3x20L	C22
1000300263	Plastic Cover,Right-Rear,ABS/PA757K,Q520	C23
004926-00	Nut;Nylon;M8x1.25P	H05
005049-00	Washer;Flat;8.2x18.0x1.0T;Black Zinc	H09
1000232619	SUPPORT LOCK,INSERT TUBE,BLACK,PP,TM439	H10
000977-00	Sleeve;Outer	H14
005196-00	Washer;Teflon;10.5x20.0x1.0T	H17

1000094874	Connecting Axle;Elevation Shock	H19
1000094875	Spring	H20
1000094932	C Clip;Combined With 6mm Axle	H21
1000230888	SCREW;BH;M10X1.5PX75L-15L;-;HS;-;BAN;	H22
1000230890	STICKER;TM439	H23
1000097464	Single Foam;One-Sided;27x20x1.5t;Black	H24
1000226906	END CAP;U;;;FLEXIBLE TUBE;;;	H25
1000226907	END CAP;D;;;FLEXIBLE TUBE;;;	H26
1000230889	SCREW;BH;M10X1.5PX80L-15L;-;HS;-;BAN;	H27
004941-00	Nut;Nylon;M10x1.5P	H28
1000229157	SCREW;NLK;M8x1.25P;;BZN;;	H29
1000229158	SCREW;NLK;M8x1.25P;;BZN;	H30
1000230286	WASHER,PP,BLACK,TM439	H31
020478-00	Washer;Flat;10.2x20.0x2.0T;Black Zinc	H32
1000223577	CAP;TM439-1US	K14
073633	Transport Wheel	K15
004759-00	Screw;Hex Socket;BH;M10x1.5Px45L(Tooth15	K16
004941-00	Nut;Nylon;M10x1.5P	K17
004623-00	Screw;Phillip;BH;Tapped;4x12L;BED;Gap;	K21
000522-D	Leveler	K50
1000101465	Incline Motor;AC Elevation;110V;80mm;225;JM14	M02
1000111476	Motor Control Board;110V	M03
000877-B	Rubber Pad;Motor;Anti-Shake	M05
003378-00	Ferrite Core	M06
004502-00	Screw;Hex Socket;Round;5/16-18UNCx16L;Ad	M07
005005-00	Washer;Spring;Lock;8.2x15.4x2.0t	M12
004592-00	Screw;Hex;3/8-16UNCx45L/Tooth15L;	M14
1000114107	Screw;Hex;M10x55L-14L;BED	M15
005165-00	Washer;Arc;8.2x18x1.5T	M16
004934-00	Nut;Nylon;3/8'-16UNC	M17
004941-00	Nut;Nylon;M10x1.5P	M18
082406	Speed Sensor	M26
020478-00	Washer;Flat;10.2x20.0x2.0T;Black Zinc	M33
1000223533	CONSOLE CRUST;ABS;Pantone Q520-7-3;TM439	N01
1000223535	CONSOLE Board;;ABS;Pantone Q520-7-3;;TM4	N02
1000223864	Console Faceplate;;;ABS/PA757;Q520-7-3;;	N03
1000343701	Net Cover;Speaker;L;;DM362;;TM438E;	N07
1000343702	Net Cover;Speaker;Rt;;DM362;;TM438E;	N08
1000343752	Decorate Plate;Console Overlay;;Silica;Q	N09
1000102735	CON Wire;hand pulse;250mm(SM-2A+XHS2.5-2	N100
1000230978	FIXING PLATE;FAN;;;PAINTING;DM362;BLACK	N20
1000223543	Cover;FAN;L;ABS;MM314;TM439-1US;	N21
1000223544	Cover;FAN;R;ABS;MM314;TM439-1US;	N22
1000229509	FAN;Painting;MM360	N23
1000228559	Speaker;Net;	N28
1000223528	PRESSER;ABS;TM439	N30
1000223545	PRESSURE PLATE;60Mn;TM439;	N31

1000106739	Screw;Phillip;BH;Tapped;4x16L;;Zn-BL	N32
102531	Cooling Fan;TM604-N33	N33
003721-00	Screw;Phillip;BH;Tapped;3x6L;Zn+3(White	N34
1000233252	SCREW;BH;Diam.3X35L;SM;PH;;;BZN;	N35
0000093244	Screw;Phillip;BH;Tapped;4x8L;Zn-BL;	N37
004633-00	Screw;Phillip;BH;Tapped;5x10L;;Zn-BL	N38
004619-AB	Screw;Phillip;BH;Oval Tapped;4x8L	N41
1000110297	Safety Key;assembly;TM637	N43
020201-A	SCREW;BH;Diam.3X8L;TC;PH;;BZN;;FLT	N50
1000343706	Control Board;Console;;HAPA;V2.002;;3.3A	N60
1000223385	KEYPAD;MEMBRANE;UP;CONSOLE;LS13.0T-2;	N61
1000228134	KEYPAD;MEMBRANE;MID;CONSOLE;LS10.0T-2;	N62
1000343708	Manipulate Overlay;;;middle;TM438E	N63
1000343709	Manipulate Overlay;;Left;English;Include	N64
1000343712	Manipulate Overlay;;Right;English;Includ	N65
1000343716	Manipulate Overlay;;Down;English;Include	N66
1000226874	WIRE;KEY BOARD;;;;900L(XHS_5P2);	N68
1000228009	CONTROL BOARD;USB BOARD;;;HAPA;;;	N69
1000227404	CONTROL BOARD;;3W;HEPD	N70
1000105102	Trumpet;3W8?;XHS-2Y;300MM	N71
1000103653	Speaker;3W8;XHS-2Y;650MM;TM381	N72
1000223942	MO;KEYPAD BOARD;LS13.0T-2;SOO1202;HCPD;	N73
1000228136	WIRE;400L(3P-110-HX30002-6P)	N74
1000101982	Console Cable;650L(CKM254301-8P+SM	N75
002671-A	Audio Wire;Three-D Earphone	N76
1000101409	CTL Board;Earphone;SOO0806A	N77
1000233280	WIRE;VF;;;120L(PHS2.0-4P XHS2.5-4P);	N78
094989	Connect Wire;IPOD-PCB;250(XHS-6Yx2)	N79
1000228137	WIRE;VF;;;;300L(2.0_3P??2);	N80
040614-A	Ground Wire;250	N81
1000343729	Manipulate Overlay;Incline Quick Key;Lef	N84
1000343733	Manipulate Overlay;Speed Quick Key;Right	N85
1000231500	WIRE;KEY;UP;700L(HX30002-6R-SM-2Y-XHS-4Y	N88
1000105188	Absorption Plate;;15X15;TM616	N90
097076	Earphone Jack;ABS;PA757S	N98
1000231347	MANUAL;TM SAFETY DIRECTION;EN/FR/SP;TM63	Not Shown
1000343730	Manual;Assembly/Manipulate;;;E/F/S;TM438	Not Shown
1000230289	HARDWARES;TM438-1US;	Not Shown
080869	Speed feedback system;Motor controller2.	Not Shown
1000231686	WIRE;CONSOLE;BLACK;850MM;CKM254301-8P	P01
061301-A	Power Switch;KCD3	P02
1000231682	WIRE;CONSOLE;1350L(SM-8Ax2)	P03
003337-00	Circuit Breaker;15A/125V	P04
101680	MCB POWER CABLE(L);14AWG;150;250##BLACK	P05
019354-A	Connecting Cable;Breaker/Switch;Black;120mm	P06
1000231681	WIRE;POWER SOCKET SET;;;;;;80,200,100,2	P07
019370-A	Power Cord;14 Guage/15 Amp	P09

002500-B	PWR Wire;CTL Board;250 14AWG(250 Negativ	P10
101681	MCB POWER CABLE(R);14AWG150;250##;WHITE	P11
1000318763	Filter;Power;16A;;BF1101-16A-02;120V/250	P12
003378-00	Ferrite Core	P13
004384-00	Screw;Phillip;BH;M5x0.8Px30L;Ni;Gap;	P14
004415-00	Screw;FH;M3X0.5PX10L;;PH;;ZN;;	P15
020192-A	Screw;Umbrella Cross Tapped;4X10L;Flat	P16
005177-00	Washer;Tooth;5.3X10.0X0.6T;BAN	P17
004889-00	Nut;Hex;M5x0.8P;Nickel	P19
1000216278	Static Wire;Deck;;;TM639-1US;	P20
080875	Screw;Phillip;Big Umbrella;Tapped;;4x10	P21
004404-00	Screw;Phillip;BH;M4x0.7Px8L;;Zn-BL	P22
1000090322	SCREW BH M5X15 CHM	P23
1000223413	COVER;MOTOR;U;ABS;Q758-3-1;TM439;	Q01
1000231275	MOTOR COVER;D;PP;Q758-3-1;-;-;TM444;	Q02
1000343713	Motor Cover-Exreawork;upper cover;;Scre	Q06
1000223896	END CAP;;;PP;;;TM439;;	Q10
1000223872	COVER;ARM REST;ABS;Pantone Q758-3-1	Q12
1000223873	COVER;ARM REST;R2;ABS;Pantone Q758--3-1	Q13
1000223874	COVER;ARM REST;L1;ABS;Pantone Q758--3-1;	Q14
1000223875	COVER;ARM REST;L2;ABS;Pantone Q758-3-1	Q15
022259-A	Screw;TRH;4X6L;SM;PH;;BZN;;FLT	Q31
1000233272	SCREW;RND;Diam.4X20L;SD;PH;CST;BAN;	Q32
004867-A	Screw;Phillip;Big BH;Tapped;4x15L	Q33
020186-00	Screw;Phillip;BH;Tapped;4x30L;	Q35
008196-B	Connecting Plate;Side Cover	Q36
005330-00	Tinnamen Nut	Q37
004865-00	Screw;Self Tapping;4x10L	Q38
1000223865	TM BELT;425C;LIVESRONG;-;-;-;-;	R02
1000228054	BELT;POLY-V;;8P 470;	R03
1000204234	Screw;Round;M8X1.25PX80L-75L;MT;HS;	R04
020425-00	Washer;Flat;8.4x15.5x1.6T	R08
020101-00	Screw;Hex Socket;Round;M8x1.25Px55L;Black Zinc	R09
1000343722	Direction Label;Accent Piece;;;Left;;TM	V04
1000343723	Direction Label;Accent Piece;TM438E;;;Ri	V05
1000217183	WARNING LABEL;#;WHITE WORD/BLACK#TM660;	V11
1000108149	Warning Sticker;Cover;behind;TM381	V14
1000210190	Warning Label;OVERLAY;WHITE WORD/BLACK B	V15
006069-AX	Sticker;Warning;; new code disc	V16
006078-00	Decal;Grounding;TM08	V18
1000230692	WARNING LABEL;CONSOLE WINDOW;WHITE WORD/	V21
1000229123	LOGO LABEL;AV/TV;-;PU;-;;	V25
1000217184	WARNING LABEL;#;WHITE WORD/BLACK#TM660;	V29
059929-B	Screw;Special;M8X1.25PX9L-D10X11.2L;;HE;45#;BOX	Z01
020283-00	Screw;Hex Socket;BH;M8x1.25Px70L-20L;Partial	Z04
020425-00	Washer;Flat;8.4x15.5x1.6T	Z05
005005-00	Washer;Spring;Lock;8.2x15.4x2.0t	Z06

072210	Screw; Hex Socket; BH; M8x1.25Px15L	Z07
004867-A	Screw;Phillip;Big BH;Tapped;4x15L	Z08
1000229460	PROTECTED PAD;IPOD;BL;170x24xT2.0;LS13.0	Z21
0000083278	USB Cover;USB-03	Z22