

COLOR SWITCH PLUS™



OWNER'S MANUAL

PRODUCT NAME

4.5FT VANCOUVER FIR

Product code:

0-07750231-8

UPC code:

810174021622

Date of purchase: ____/____/____

COLOR SWITCH PLUS™

4.5FT VANCOUVER FIR TREE ASSEMBLY INSTRUCTIONS


Congratulations on purchasing your new tree from **KMART**. Carefully follow the instructions below on how to quickly and easily set up your new tree.

1. Before you start to assemble your tree, choose an appropriate location near a wall outlet.
2. Assemble the tree stand and place on a level surface. (See Fig. A), slide 4 plastic legs upwards into base.

Fig.A-Tree Stand Assembly



Fig.B-Tree and Light Assembly



3. Assemble the tree from the bottom to the top. Start with the bottom section and insert into the assembled plastic stand.

Please note 8-functions control box is wrapped in the lowest layer, if the remote control disappears, you can control the light string here.

4. Continue by inserting the top tree section to the bottom section.
5. Plug top section's light string connector(A) into bottom section's light string connector (B). Then tighten the locking collar.
6. Finally shape the tree by arranging the tips on the branches to give the desired effect. Some tree styles have "side branches" attached to the main branch stem that require additional shaping as shown Fig.C. After shaping the complete tree the finished look should be natural and full.

Fig.C



MODEL #:W-464PB-46KH

7. Then insert the light string's adaptor into the wall outlet finally. Your entire tree should now be lit. If some bulbs do not light or flicker, search for any loose plugs and/or broken, loose or missing bulbs. Replace bulbs promptly in order to maintain the performance and life expectancy of your pre-lit tree.

STORAGE INSTRUCTIONS

1. Remove all ornaments and decorations. For pre-lit trees, first unplug the adaptor from the wall outlet, then disconnect top section tree's light string from bottom section's light string.
2. Gather the branches upwards and secure them in place. Then disassemble the tree from the top to the bottom section. Gently lift off the 2 sections and place them into box.
3. Then disassemble the tree stand and pack into box and tape it shut.
4. When not in use, please store your tree in a cool, dry place away from sunlight. Exposing your tree to excessive heat or humidity may damage your tree.

TROUBLE SHOOTING TIPS

For Pre-lit Trees, If The Tree Does Not Illuminate

1. Please check to make sure that all plugs are properly connected as shown in Fig.B and the power cord is plugged into the wall outlet. Refer to assembly guide for instructions.
2. Please check for loose, broken or missing light bulbs and replace as needed.

SPARE PARTS

For pre-lit trees spare bulbs are included. If extra parts are needed, please contact our customer service center.

HOW TO USE REMOTE CONTROL:

<p>Remote control Front</p>	<p>Remote control Back</p>	<p>1: Remote Control Operating Range: 5 meters</p> <p>2: Remote Control Functions: Button A: ON/OFF Button B: COLOR Button C: MODE</p> <p>1. STEADY ON 2. SLOW SPARKLING 3. QUICK SPARKLING 4. SLOW FADE 5. QUICK FADE 6. SLOW GLOW 7. FLASHING 8. COLOR SWITCHING</p> <p>3. Remote control includes 1 piece 23A battery packed separately with instruction manual.</p>
-----------------------------	----------------------------	--

▲ WARNING

1. Use only power adaptor supplied with this product, using a different adaptor will damage the lights and cause fire, electrical shock hazards.
2. FOR INDOOR USE ONLY.

CUSTOMER SERVICE FOR CHRISTMAS TREES

Do Not Return This Product To The Store.

For any questions, assistance, or missing parts, please contact us at 1-844 946 8733
 Or visit our website at www.winnerstree.com
 Welcome to email us: CUSTOMERSERVICE@WINNERSARTS.COM

Tree ID#: _____	Customer Name: _____
Tree UPC#: _____	Address: (No P.O. Boxes) _____
Store Purchased: _____	City & State: _____
Specify Problem: _____	Zip Code: _____
_____	Day Phone: _____
_____	Date Purchased: _____

TREE ID# IS LOCATED ON END PANEL OF BOX. TREE ID# IS REQUIRED WHEN REQUESTING REPLACEMENT PARTS.

MODEL #:W-464PB-46KH

ASSEMBLY INSTRUCTIONS

MADE IN CHINA

ASSEMBLY INSTRUCTIONS

MADE IN CHINA



Please refer to part numbers when reordering
 Made in / Hecho en CHINA. Distributed by Kmart Corporation
 Hoffman Estates, IL 60179 SHOP kmart.com