









## User Guide for Latte DeLite™

Thank you for choosing Latte LED Light Bluetooth Speaker, DeLite™. The DeLite™ is a portable LED powered light equipped with a Bluetooth sound speaker (2-in-1), which can be connected to your smart phone or any Bluetooth enabled device via the latest Bluetooth Technology and play music wirelessly.

The DeLite™ eliminates the need to carry a flashlight, Lantern, and Music Speaker separately and will make your camping or outdoor BBQ experience more enjoyable and relaxing. Besides outdoor uses, the DeLite™ can also be used as the perfect mood-light indoors.

Please read the manual carefully before use.


### 1. Main Key Operations

- Turn on (Bluetooth) - press and hold  for 2 seconds
- Turn off (Bluetooth) - press and hold  for 5 seconds
- Turn on (Light) - press  shortly
- Pairing (Bluetooth) - turn on Bluetooth and go to Setting>Bluetooth in your smart phone or Bluetooth enabled device, scan to find "DeLite" and pair. If asked for a passcode, enter "0000"
- Press and hold the volume buttons ( / ) to change songs (next/previous)
- Press the volume buttons ( / ) shortly to adjust the volume
- Press and hold  to adjust the brightness of the light.














### 2. Main features and Specifications

- Music Play via Bluetooth
- Handsfree Function (Built-in Microphone)
- $\Phi$ 3.5mm Audio Input Interface
- Audio Max Power : 5W\*1
- Frequency response: 20Hz-20kHz
- 8 LED lights with 150 Lumen
- Run Time (Music Play): 6+ hours
- Run time (Light): 10+ hours
- Max. Power Consumption: 1W
- Built-in 2200mAh Rechargeable Lithium Battery
- Power Source: Via Micro USB Cable. DC 5V Micro USB Power Adapter (sold separate)
- Charging time : around 3-4 hours
- LED Bluetooth/line in indicator and power charge indicator
- Water resistance level: IPX4









### 3. Main Keys



### 4. Key Functions

No	Current mode	How To	Button	Operation	Indicator
1	Power off	Power on		Press & hold for 2 seconds	Blue light ON
2	Power on	Power off		Press & hold for 5 seconds	Light Off
3	Power on	Bluetooth pairing		Manually establish connection in the setting of the Bluetooth enabled device	Blue light light will flash rapidly
4	Power on	Bluetooth connection established			Blue light will flash slowly
5	Power on	Call back		Press twice	
6	Call mode	Answer call		Press once shortly	
7	Call mode	Reject call		Press and hold	
8	Talk mode	End call		Press once shortly	
9	Bluetooth mode	Volume up		Press and hold	
10	Bluetooth mode	Volume down		Press and hold	
11	Bluetooth mode	Previous song		Press once shortly	
12	Bluetooth mode	Next song		Press once shortly	
13	Bluetooth mode	Play/Pause		Press once shortly	
14	Any mode	Charge			Red light ON
15	Any mode	Battery is full			Green light ON
16	Bluetooth mode	Audio input		The line-in audio cable is plugged into the audio input port	Green light ON
17	Audio mode	Bluetooth mode		Unplug the line-in audio cable	Blue light ON
18	Any mode	Night light ON/OFF		Press once shortly	
19	Light On Mode	Adjust Brightness		Press and hold	

### 5. Bluetooth Operations

- Press and hold  for 2 seconds to turn on the Bluetooth function. The blue LED status light will be ON and flashing rapidly. Please don't plug the audio cable (AUX cable) into the audio line-in jack when you want to use the Bluetooth function.
- Go to "Setting" on your cell phone or Bluetooth enabled device and activate "Bluetooth" function. Scan for available Bluetooth devices nearby.
- When "DeLite" appears on the available Bluetooth device list, select "DeLite" to establish connection ( if asked for a passcode, enter "0000"). When the connection is successfully established, it produces a connection tone, and Blue LED light changes to flash slowly. Now the speaker is ready for playing music. Press  shortly to play music.
- During the music play, the music play will stop when you receive a call. Press  shortly to answer the call, or press and hold  for 2 seconds to reject the call. Press and hold  /  to adjust the volume. Short press  to end the call. The music will resume automatically.
- Press  shortly twice to redial the last phone number.
- If the connection is lost or not established correctly, please repeat step 1 to 3 for re-connection. If the blue indicator light is not flashing, please charge the product fully and repeat steps 1 to 3.

## 6. Audio Input Mode

- When the Bluetooth mode is on, please insert the 3.5mm line-in audio cable into the audio input port of the product and your music player. Once connected, the indicator light will change from blue to green. Press and hold "⊕ / ⊖" to adjust the volume.
- When the volume is set to Max, you will hear "beep..beep..beep" sound.
- Press "⊕" shortly to mute the music. In the 'audio line-in' mode, the last song and the next song function will not work. Please control your music through your music device.
- Please pull out the audio cable to disconnect the device from the speaker. The speaker will switch back to the Bluetooth mode automatically and the blue LED light will start flashing again. The product will be automatically paired back with the last Bluetooth device.

## 7. Charging

Connect the included Micro USB Cable to your PC. Once it is connected, the RED LED light will be ON. Once the product is fully charged, the color will change to Green.

## 8. Night Light Operations

Please press "⊕" shortly to turn on/off the light. Press and hold "⊕" to adjust the brightness of the light.

## 9. Troubleshooting

Issue	Solution
Intermittence during music playback.	<ol style="list-style-type: none"> <li>1. Lower battery. Please charge the product fully before you start using the product again.</li> <li>2. Move the speaker closer to your phone or Bluetooth device.</li> </ol>
Cannot establish connection with your phone or Bluetooth device.	<ol style="list-style-type: none"> <li>1. Lower battery. Please charge</li> <li>2. Move the speaker closer to your phone or Bluetooth device.</li> <li>3. Try to turn off the speaker &amp; restart</li> <li>4. Please check if other phone or Bluetooth device is already paired and connected to the speaker. The speaker can only be connected to one Bluetooth device at a time. In this case, please disconnected the currently connected device and pair the device you are trying to connect again.</li> <li>5. Please check if your phone is connected to "DeLite" in your phone's Bluetooth setting.</li> </ol>
Weak sound	Press and hold "⊕" button

## 10. Accessories

- **Included in the box:** Micro USB Cable, Line-in Audio Cable, User Guide,
- **Available to purchase:** Wall Charger, Hanging Hook, Carrying Bag

## ❖ Contact Information

- **Technical Support:**  
Telephone: 408-946-8789 (M-F, 9 A.M - 5 P.M PST)  
Email: [support@latteglobal.com](mailto:support@latteglobal.com)  
Online: [support.lattezone.com](http://support.lattezone.com)  
Facebook Support: [www.facebook.com/lattestyle](http://www.facebook.com/lattestyle)
- **RMA inquiry:**  
[RMA@latteglobal.com](mailto:RMA@latteglobal.com) or visit [support.lattezone.com](http://support.lattezone.com)
- **Genuine Accessories Purchase:**  
Please visit [www.lattezone.com](http://www.lattezone.com)
- **Facebook:** [www.facebook.com/lattestyle](http://www.facebook.com/lattestyle)
- **Twitter:** [www.tritter.com/lattestyle](http://www.tritter.com/lattestyle)
- **Address:**  
Latte Communications Inc.  
1622 Centre Pointe Dr  
Milpitas CA 95035

## ❖ Caution

- Do not use the product in extremely hot, cold, dusty or damp environments.
- The product contains a lithium battery and should be kept away from fire or extremely high temperature environment to avoid explosion.
- Do not disassemble, repair, or modify the product arbitrarily. These actions will void the manufacturer's standard warranty.
- Please charge the unit fully before you start using the product for first time.
- If the product hasnot been in use for an extended time, please make sure you charge the unit fully before you start using it again.