# Record Model/Serial Numbers

#### **Product Record**

Bill of sale, sales slip, cancelled check or other purchase record should be kept to verify the original purchase date for warranty purposes.

Model Number: <u>*</u>	•
Serial Number:*-	
Purchase Date: .	

## **Table of Contents**

Record Model/Serial Numbers	2
Warranty Information	2
Important Safety Instructions	3
Removal of Old Disposer	4
Dishwasher Connection	5
Installation of Mounting Assembly.	5-7
Electrical Connections	8
Operating Instructions	8-9
Troubleshooting	10
Cleaning and Maintenance	11

# **Warranty Information**

### KENMORE LIMITED WARRANTY

FROM THE DATE OF SALE for the model numbers and time periods listed below, this product is warranted against defects in material or workmanship.

70235, 70211 - 2 YEARS, 70321 - 3 YEARS, 70351 - 5 YEARS, 70361 - 7 YEARS

WITH PROOF OF SALE, return a defective product to the retailer from which it was purchased for free replacement.

This warranty is void if this product is ever used for other than private household purposes.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sears Brands Management Corporation, Hoffman Estates, IL 60179 Sears Canada Inc., Toronto, Ontario, Canada M5B 2C3

## **Sears Installation Service**

To order and schedule professional installation of this disposer, call 1-800-4-MY-HOME (800-469-4663)

<sup>\*</sup>Above information appears on the label affixed to bottom of the disposer. For your convenience, write down the model and serial numbers prior to installation.