INSTRUCTION MANUAL

SOFA

Model No:

DA6863-SF

UPC CODE:

0-65857-16811-2



THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Lot number: (TAKEN FROM CARTON)
Date of purchase:
1



DO NOT RETURN PRODUCT TO THE STORE.

If a part is missing or damaged, contact our customer service department. We will replace the part **FREE** of charge.



Tel #: 1-800-295-1980 E-Mail: das@dorel.com Fax #: 514-353-7819

CUSTOMER SERVICE

If you are missing parts or have any questions about this product, contact our customer service representative first!

CALL 1-800-295-1980

You can also order parts by writing to the address listed below. Please include the product model number, color and a detailed description of the part.

Customer Service Department No. 413 12345 Albert-Hudon Boulevard, Suite 100 Montreal, Quebec Canada H1G 3L1

E-MAIL: das@dorel.com

NOTES

- * Ensure all parts and components are present before beginning assembly.
- * Assembly and handling will require two people.
- * Assemble on a soft, smooth surface to prevent damage to the product finish.
- * Read all instructions completely before assembly.
- * **DO NOT** use power tools.
- * CAUTION: Adult assembly required.
- * Estimated assembly time: 15 minutes.

CARE AND CLEANING

Dust regularly with a soft, dry cloth to prevent soil build-up. Keep away from heat to avoid glazing, melting or scorching. Use a professional cleaning service to clean the fabric.

MAINTENANCE

Check bolts/screws periodically and tighten them if necessary.


LIMITED WARRANTY

Dorel Asia warrants its product to be free from defects in material and workmanship and agrees to remedy any such defect. This warranty covers 1 year from the date of original purchase. This warranty is valid only upon presentation of proof of purchase. This is solely limited to the repair or replacement of defective furniture components and no assembly labor is included. This warranty does not apply to any product which has been improperly assembled, subjected to misuse or abuse or which has been altered or repaired in any way. Any wearing, tearing or fading of the fabric is not covered under the warranty. This warranty gives you specific legal rights and you may also have other rights which vary from State to State.



WARNING: Should this product become damaged, and/or components are broken or missing, DO NOT USE.

PARTS LIST




STEP 1:

Place all parts on a clean, smooth surface.


Attach front rail (G) to left and right arms (D) by inserting the metal brackets on front rail (G) into the metal glides on left and right arms (D).

Push the front rail (G) with a downward force to secure it into place.



STEP 2:


Attach the support leg w/flat washer (E) to the seat panel (F) by rotating clockwise.



STEP 3:

Attach seat panel (F) to left and right arms (D) by inserting the metal brackets on seat panel (F) into the metal glides on left and right arms (D).


Push the seat panel (F) with a downward force to secure it into place.



STEP 4:


Attach sofa back (C) to left and right arms (D) by inserting the metal brackets on sofa back (C) into the metal glides on left and right arms (D).

Push the sofa back (C) with a downward force to secure it into place.




STEP 5:

Place the seat cushions (A), back cushions (B) and pillows (H) on the sofa.



! CAUTION: This unit is intended for use only with the products and/or maximum weights indicated. Use with other products and/or products heavier than the maximum weights indicated may result in instability or cause possible injury.

Dust regularly with a soft, dry cloth to prevent soil build-up. Keep away from heat to avoid glazing, melting or scorching. Use a professional cleaning service to clean the fabric.



Recommended
Maximum Weight = 225 lbs per position

That's it! You've finished assembling your sofa.

DO NOT RETURN PRODUCT TO THE STORE.

If a part is missing or damaged, contact our customer service department. We will replace the part **FREE** of charge.



Tel #: 1-800-295-1980 E-Mail: das@dorel.com Fax #: 514-353-7819

Customer Service

PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE

PLEASE CONTACT CUSTOMER SERVICE REPRESENTATIVES AT THE FOLLOWING NUMBERS SHOULD THERE BE ANY MISSING OR DEFECTIVE PART(S).

Customer Service Phone Number 1-800-295-1980 Customer Service Fax Number 514-353-7819 Email: das@dorel.com	
Request Date:	
Name:	
Shipping Address:	
Simpping Address.	
Street & Number:	
City & State:	
Zip Code:	
Day Time Phone Number:	
(including area code)	
Date & Place of Purchase:	
Dute & Flace of Farenase.	
	Part(s) description and quantity (Please be sure to list model number or SKN number):