

ESPECIFICACIONES

1. Voltaje De Operación.....	12 Voltios cc (Nominal)
2. Amperio De Uso.....	4 Amp
3. Grado De Potencia	48 Vatios
4. Peso Neto (lb)	5 lbs 3 ozs.
5. Dimensiones (cm).....	16.8 cm (Ancho) X 32.3 cm (Prof) X 27.6 cm (Altura)
6. Capacidad Compartimiento	5.7 Litros
7. Rango De Temperatura	7.2°C - 65°C
8. Fusible.....	10 Amp

SOLUCIÓN DE PROBLEMAS

PROBLEMA	CAUSA	SOLUCIÓN
Unidad conectada a la salida de 12V cc no funciona.	1. No hay poder entrando a la unidad.	1. Revise el fusible del encendedor de cigarrillos o del zócalo de 12V cc. Reemplácelo si es necesario.
	2. El fusible está quemado.	2. Reemplace el fusible de 10A. (Consulte las instrucciones)
	3. El encendedor de cigarrillos o el zócalo de 12V cc está apagado.	3. Ponga la llave de arranque del vehículo en la posición de ACCESORIO ENCENDIDO.
	4. Mala conexión a la salida de 12 Voltios cc.	4. Inserte apropiadamente el enchufe de accesorio 12V cc en el zócalo de12V cc.

GARANTÍA LIMITADA POR 2 AÑOS

Rally Manufacturing, Inc. le garantiza al comprador original que este producto estará libre de defectos en materiales y manufactura bajo condiciones normales de uso por dos años. Si Rally Manufacturing, Inc. concluye que el producto presenta defectos durante este periodo de tiempo, lo reparará o reemplazará sin ningún costo. El comprador original es elegible para esta garantía, únicamente si pueden probar que el producto fue comprado durante el periodo cubierto por la garantía.

Para recibir servicio en los Estados Unidos, visite www.rallymfg.com o llame al 1-800-965-4407. Envíe el producto defectuoso con seguro de pérdida o daño a : Rally Manufacturing, 7600 Corporate Center Drive Suite 400, Miami, FL 33126 U.S.A. ATTN: Customer Service. (Servicio al Cliente). Adicione una carta con su información de contacto que incluya su dirección de correo electrónico (si posee alguno), nombre, dirección, número telefónico y el problema que presenta el producto. No envíe ningún producto a Rally Manufacturing, Inc. sin haberse contactado previamente el departamento de Servicio al Cliente.

LAS REPARACIONES O SUSTITUCIONES DE LOS PRODUCTOS O PARTES DEFECTUOSAS NO APLICAN SI EL PRODUCTO (a) ES USADO PARA PROPOSITOS COMERCIALES Y/O ES UTILIZADO INAPROPIADAMENTE EN UN AMBIENTE INAPROPIADO; (B) ES MODIFICADO O FORZADO INTERNA O EXTERNAMENTE; (c) ESTÁ DAÑADO COMO RESULTADO DE USO ERRONEO, NEGLIGENCIA, FALTA DE MANTENIMIENTO RAZONABLE Y CUIDADO, O POR OTRAS CAUSAS NO RELACIONADAS CON MATERIALES DEFECTUOSOS O MANUFACTURA; (d) SI EL PRODUCTO HA SIDO EXPUESTO AL AGUA, FUEGO O CORROSIÓN GENERAL.

Esta garantía le da derechos legales específicos, y usted puede tener otros derechos, que varían de Estado a Estado en los Estados Unidos o de Provincia a Provincia en Canadá

SERVICIO AL CLIENTE
Lunes a viernes 8:30 am - 5:30 pm Tiempo del Este
Para preguntas o comentarios, contáctenos: www.rallymfg.com o llame 1-800-965-4407

© 2012 RALLY MANUFACTURING, INC.
Hecho en China.

SPECIFICATIONS

1. Operating Voltage.....	12 Volt DC (NOMINAL)
2. Amperage Draw.....	4 Amp
3. Power Rating.	48 Watt
4. Net Weight (lb)	5 lbs. 3 ozs.
5. Dimensions (in)	6.62in (W) x 12.75in (D) x 10.87in(H)
6. Refrigeration Compartment	5.7 Liters
7. Temperature Range	45°F - 150°F
8. Fuse	10 Amp

TROUBLESHOOTING GUIDE

TROUBLE	CAUSE	SOLUTION
Unit connected to the 12 Volt DC outlet does NOT operate.	1. No input power to the unit.	1. Check vehicle cigarette lighter or 12V DC accessory Socket fuse. Replace fuse if required.
	2. Unit fuse blown.	2. Replace 10A fuse (See fuse replacement)
	3. Vehicle cigarette lighter or 12V DC Accessory socket is turned OFF.	3. Turn the vehicle Ignition Key to accessory ON Position.
	4. Bad connection to the12 Volt DC Power outlet.	4. Insert the power cable 12V DC accessory plug properly into the 12 Volt DC socket.

TWO YEAR LIMITED WARRANTY

Rally Manufacturing, Inc. warrants to the original purchaser that the consumer product shall be free from defects in material and workmanship under normal use for its lifetime or for the warranty period stated on each product. If Rally Manufacturing, Inc. concludes the product to be defective in material or workmanship during this warranty period, Rally Manufacturing, Inc. will repair or replace the defective product or component at no charge. The original purchaser is eligible for this warranty only if they can prove to Rally Manufacturing, Inc. that the product was purchased within the warranty period. To receive warranty service in the U.S.A., visit us at www.rallymfg.com or call 1-800-965-4407. You may ship your defective products, freight prepaid and insured for loss or damage, to:

Rally Manufacturing, 7600 Corporate Center Drive Suite 400, Miami, FL 33126 U.S.A. ATTN: Customer Service. Provide a letter stating your contact information which includes your email address (if applicable), name, address, phone number and the problem with the product. Do not send any products to Rally Manufacturing, Inc. without first contacting Rally Manufacturing Customer Service.REPAIR OR REPLACEMENT OF THE DEFECTIVE PRODUCT OR COMPONENT PROVIDED UNDER THIS WARRANTY SHALL NOT APPLY IF THE PRODUCT: (a) IS USED FOR COMMERCIAL PURPOSES AND/OR FROM IMPROPER USE IN AN UNSUITABLE ENVIRONMENT (b) IS MODIFIED OR TAMPERED WITH EITHER INTERNALLY OR EXTERNALLY; (c) IS DAMAGED RESULTING FROM MISUSE, NEGLIGENCE, LACK OF REASONABLE MAINTENANCE AND CARE, OR BY OTHER CAUSES UNRELATED TO DEFECTIVE MATERIAL OR WORKMANSHIP; (d) IF THE PRODUCT HAS BEEN SUBJECTED TO FIRE, WATER, OR GENERAL CORROSION.

This warranty gives you specific legal rights, and you may also have other rights which vary from State to State in the U.S.A. or province to province in Canada

WARNING: This product may contain chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm. Wash hands after handling!

CUSTOMER SERVICE
Monday-Friday 8:30am-5:30pm Eastern Standard Time
For questions or comments contact us at: www.rallymfg.com or call 1-800-965-4407

© 2012 RALLY MANUFACTURING, INC.
Made in China.

COOLER & WARMER

No. 7285

INSULATED LID WITH AIR SEAL

INTERNAL INSULATOR FOR MAXIMUM EFFICIENCY

MAGNETIC LOCK

HIGH FLOW COOLING FAN

COOL - WARM MULTI-FUNCTION SWITCH

12 VOLT CIGARETTE LIGHTER PLUG

RUST PROOF, IMPACT & WEATHER RESISTANT HOUSING

CARRY STRAP INCLUDED

12 VOLT DC ACCESSORY PLUG WITH LED INDICATOR

IMPORTANT: PRIOR TO USE, READ AND UNDERSTAND ALL WARNING, CAUTIONS & INSTRUCTIONS INCLUDED IN THIS INSTRUCTION SHEET. RETAIN THIS INSTRUCTION SHEET FOR FUTURE REFERENCE.

OPERATION INSTRUCTIONS

- Insert the power cable keyed plug fully into the unit power port. Make sure the groove on the plug is properly oriented and aligned with the power port. (Fig.1).
- Insert the power cable 12V DC accessory plug into the vehicle cigarette lighter or 12V DC accessory socket. The LED indicator will illuminate on the 12V DC accessory plug. *Note: before placing food/drinks turn “ON” the unit to the desired Cool or Warm position for at least 20 minutes.*
- Depending upon cooling or warming operation follow the instruction below:
A. COOL: Slide the power switch downward to the cool position. Green LED will illuminate.
B. WARM: Slide the power switch upward to the warm position. Red LED will illuminate.
- Open the magnetic cover and place food or drinks. Close the cover completely. Do Not over load the device with food or drinks. Cover must close without excessive force.

Fig.1

FUSE REPLACEMENT

To replace fuse unscrew retainer ring

NEVERA Y CALENTADOR

No. 7285

AISLANTE INTERNO PARA MÁXIMA EFICIENCIA

TAPA AISLADA CON SELLO DE AIRE

SEGURO MAGNÉTICO

VENTILADOR DE ALTO FLUJO

BOTÓN PARA FUNCIÓN MÚLTIPLE ENFRIA-CALIENTA

CUBIERTA RESISTENTE AL CLIMA, ÓXIDO E IMPACTOS

ENCHUFE PARA ENCENDEDOR DE CIGARRILLOS DE 12 VOLTIOS

CORREA PARA CARGAR INCLUIDA

ENCHUFE DE ACCESORIO 12V CC

IMPORTANTE: ANTES DE USAR, LEA Y ENTIENDA TODAS LAS ADVERTENCIAS, PRECAUCIONES E INSTRUCCIONES INCLUIDAS EN ESTE MANUAL. GUARDE ESTE MANUAL PARA REFERENCIA EN EL FUTURO.

INSTRUCCIONES DE OPERACIÓN

- Conecte el enchufe con ranura 12V cc del cable de poder en la unidad. Asegúrese que la ranura del enchufe 12V cc esté bien alineado con el puerto de poder. (Fig.1).
- Inserte el enchufe del accesorio 12V cc del cable de poder en el encendedor de cigarrillos o en el zócalo de 12V cc de su vehículo. El indicador LED se encenderá en el enchufe de accesorio 12V cc.
Nota: antes de poner adentro comida o bebida, encienda la unidad en Frio (COOLER) o Caliente (WARMER), según lo requiera, por al menos 20 minutos.
- Dependiendo de la operación requerida, siga estas instrucciones:
A. FRIO: Deslice el interruptor hacia abajo a la posición de FRÍO (COOLER). Una luz verde se encenderá.
B. CALIENTE: Deslice el interruptor hacia arriba a la posición de CALIENTE (WARMER). Una luz roja se encenderá.
- Abra la cubierta magnética e introduzca comida o bebidas. Cierre la cubierta completamente. No sobrecargue la unidad. La cubierta debe cerrar sin el uso de fuerza excesiva.

Fig.1

REEMPLAZAR FUSIBLE

Para reemplazar el fusible, desatornille el anillo retenedor.