

GRAND RESORT











Owner's Manual

Sunset Place Slat Top Dining Table

Product code: D71 M34427






UPC Code: 848306014990

Date of Purchase: ___/___/___

Item	Part Name	Photo	Qty
A	TABLE TOP		1
B	LGE CONNECTOR BRACKET		1
C	TABLE LEG		2
D	CENTER GLASS		1
E	HEX BOLT M6X15mm		12
F	PLASTIC BOLT CAP		12
G	METAL WASHER		12
H	ALLEN WRENCH		1

Step 1

- Attach the leg connector bracket (B) to the table legs (C) using four bolts (E) and metal washers (G).
- Do not tighten the bolts completely.

Item	Photo	Qty
B		1
C		2
E		4
F		4
G		4










Figure 1

Step 2

- Attach the table top (A) to the table legs (C) using eight bolts (E) and metal washers (G).
- Tighten all the bolts using the Allen wrench (H).
- Cover all the bolts with plastic bolt caps (F).

Item	Photo	Qty
A		1
B		1
C		2
E		8
F		8
G		8






Figure 2

Step 3

- Place the center glass (D) in the middle of the table top (A).

Item	Photo	Qty
A		1
D		1




Figure 3

sears

Please refer to part numbers when reordering

For questions or comments about product:

Email: custserv@huayueusa.net or Call toll-free: 1-877-931-7378


Made in / Hech en CHINA

Distributed by Sears, Roebuck and Co., Hoffman Estates, IL 60179

See our extensive assortment of outdoor living products
on-line at www.sears.com and www.kmart.com

2014

GRAND RESORT














Owner's Manual

Sunset Place Cushioned Dining Chair

Product code: D71 M34427







UPC Code: 848306014990

Date of Purchase: ___/___/___

Item	Part Name	Photo	Qty
A	CHAIR FRAME		1
B	CHAIR LEG 1 (left when sitting)		1
C	CHAIR LEG 2 (right when sitting)		1
D	BACK CUSHION		1
E	SEAT CUSHION		1
F	HEX BOLT M6x15mm		4
G	HEX BOLT M6x50mm		2
H	HEX BOLT M6x25mm		2
I	PLASTIC BOLT CAP		8
J	METAL WASHER		8
K	ALLEN WRENCH		1

Step 1

- Attach chair legs (B and C) to chair frame (A) seat using four bolts (F) and metal washers (J).
- Do not tighten the bolts completely.

Item	Photo	Qty
A		1
B		1
C		1
F		4
I		4
J		4










Figure 1

Step 2

- Attach the chair frame (A) seat front to the chair legs (B and C) using the two bolts (H) and metal washers (J).
- Tighten all the bolts with the Allen wrench (K).
- Cover all the bolts with plastic bolt covers (I).

Item	Photo	Qty
A		1
B		1
C		1
H		2
I		2
J		2










Figure 2

Step 3

- Attach chair legs (B and C) to chair frame (A) back using the two bolts (G) and metal washers (J).

Item	Photo	Qty
A		1
B		1
C		1
G		2
I		2
J		2









Figure 3

Step 4

- Place the seat and back cushions (E and D) on the chair frame.

Item	Photo	Qty
A		1
B		1
C		1
D		1
E		1




Figure 4

sears

Please refer to part numbers when reordering

For questions or comments about product:

Email: custserv@huayueusa.net or Call toll-free: 1-877-931-7378


Made in / Hech en CHINA

Distributed by Sears, Roebuck and Co., Hoffman Estates, IL 60179

See our extensive assortment of outdoor living products
on-line at www.sears.com and www.kmart.com

2014

GRAND RESORT













Owner's Manual










Sunset Place Cushioned Swivel Rocker









Product code: D71 M34427

UPC Code: 848306014990

Date of Purchase: ___/___/___

Item	Part Name	Photo	Qty
A	CHAIR BASE		1
B	CHAIR FRAME		1
C	ARM		2
D	BACK CUSHION		1
E	SEAT CUSHION		1
F	RECTANGULAR STEEL PLATE		2
G	LOCK WASHER		4
H	HEX BOLT M8x33mm		4
I	NUT M8		4
J	PLASTIC HEX BOLT CAP M8		4

Item	Part Name	Photo	Qty
K	PLASTIC NUT CAP M8		4
L	HEX WRENCH		2
M	T-ROCK		1
N	HEX BOLT M6x15mm		4
O	HEX BOLT M6x50mm		2
P	HEX BOLT M6x25mm		2
Q	PLASTIC BOLT CAP		8
R	METAL WASHER		8
S	ALLEN WRENCH		1

Item	Photo	Qty
B		1
F		2
G		4
H		4
I		4
J		4
K		4
M		1









Figure 1

Item	Photo	Qty
B		1
C		2
N		4
Q		4
R		4









Figure 2

Item	Photo	Qty
B		1
C		2
P		2
Q		2
R		2









Figure 3

Item	Photo	Qty
B		1
C		2
O		2
Q		2
R		2









Figure 4

Item	Photo	Qty
A		1
B		1
C		2
D		1
E		1




Figure 5

sears

Please refer to part numbers when reordering

For questions or comments about product:

Email: custserv@huayueusa.net or Call toll-free: 1-877-931-7378

Made in / Hech en CHINA

Distributed by Sears, Roebuck and Co., Hoffman Estates, IL 60179

See our extensive assortment of outdoor living products
on-line at www.sears.com and www.kmart.com

2014