
## **DOREL ASIA**

## STORAGE BENCH



### **Model No:**

DA6003M-BG (Beige)

DA6003M-BR (Brown)

DA6003F (Blue)

### **UPC CODE:**

0-65857-16383-4 (Beige)

0-65857-16485-5 (Brown)

0-65857-16486-2 (Blue)

### **NOTE:**

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Lot num (TAKEN FROM CAR	
Date of purch	ase:
/ /	

### DO NOT RETURN PRODUCT TO THE STORE.

If a part is missing or damaged, contact our customer service department. We will replace the part **FREE** of charge.



Tel #: 1-800-295-1980 E-Mail: das@dorel.com Fax #: 514-353-7819

#### **CUSTOMER SERVICE**

If you are missing parts or have any questions about this product, contact our customer service representative first!

### **CALL 1-800-295-1980**

You can also order parts by writing to the address listed below. Please include the product model number, color and a detailed description of the part.

Customer Service Department No. 413 12345 Albert-Hudon Boulevard, Suite 100 Montreal, Quebec Canada H1G 3L1

E-MAIL: das@dorel.com

## **NOTES**

- \* Ensure all parts and components are present before beginning assembly.
- \* Assembly and handling will require two people.
- \* Assemble on a soft, smooth surface to prevent damage to the product finish.
- \* Read all instructions completely before assembly.
- \* **DO NOT** use power tools.
- \* CAUTION: Adult assembly required.
- \* Estimated assembly time: 10 minutes.

#### CARE AND CLEANING

Dust regularly with a soft, dry cloth to prevent soil build-up. Wipe away spills immediately to prevent staining. Use a cloth dampened with water or a professional product to clean the fabric. Always test an inconspicuous area first. Allow upholstery to dry and brush lightly. Keep away from heat to avoid glazing, melting or scorching.

#### **MAINTENANCE**

Check bolts/screws periodically and tighten them if necessary.

#### LIMITED WARRANTY


Dorel Asia warrants its product to be free from defects in material and workmanship and agrees to remedy any such defect. This warranty covers 1 year from the date of original purchase. This warranty is valid only upon presentation of proof of purchase. This is solely limited to the repair or replacement of defective furniture components and no assembly labor is included. This warranty does not apply to any product which has been improperly assembled, subjected to misuse or abuse or which has been altered or repaired in any way. Any wearing, tearing or fading of the fabric is not covered under the warranty. This warranty gives you specific legal rights and you may also have other rights which vary from State to State.

WARNING: Should this product become damaged, and/or components are broken or missing, DO NOT USE.

## **HARDWARE LIST**


1	2	3
Ø5/16" X 60mm	Ø22 X 1.8mm	Ø12.5 X 1.2mm
HEX SOCKET HEAD BOLT	FLAT WASHER	SPRING WASHER
8 PCS	8 PCS	8 PCS
4	5	6
Ø5/16" X 90mm	Ø19 X 1.8mm	Ø5mm
		ATTENTION
HEX SOCKET HEAD BOLT	FLAT WASHER	ALLEN KEY

## **PARTS LIST**



## **STEP 1:**


Lift the lid of bench (A). Pull back the fabric lining on the sides of the interior of bench (A).




## STEP 2:

Attach the left arm (B) to the bench (A) using flat washers (2), spring washers (3) and hex socket head bolts (1). Use Allen Key (6) to tighten the bolts. Place the fabric lining back into place.

Repeat the step to attach right arm (C).







### **STEP 3:**

With the help of another person, place the unit upside down.

Attach feet (D) to the left and right arms (B & C) using flat washers (5) and hex socket head bolts (4). Use Allen Key (6) to tighten the bolts.

Turn the bench upright.








**CAUTION:** This unit is intended for use only with the products and/or maximum weights indicated. Use with other products and/or products heavier than the maximum weights indicated may result in instability or cause possible injury.

Dust regularly with a soft, dry cloth to prevent soil build-up. Wipe away spills immediately to prevent staining. Use a cloth dampened with water or a professional product to clean the fabric. Always test an inconspicuous area first. Allow upholstery to dry and brush lightly. Keep away from heat to avoid glazing, melting or scorching.



That's it! You've finished assembling your bench.

#### DO NOT RETURN PRODUCT TO THE STORE.

If a part is missing or damaged, contact our customer service department. We will replace the part **FREE** of charge.



Tel #: 1-800-295-1980 E-Mail: das@dorel.com Fax #: 514-353-7819

## **Customer Service**

## PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE

PLEASE CONTACT CUSTOMER SERVICE REPRESENTATIVES AT THE FOLLOWING NUMBERS SHOULD THERE BE ANY MISSING OR DEFECTIVE PART(S).

	ervice Phone Number 1-800-295-1980 ervice Fax Number 514-353-7819 Email: das@dorel.com
Request Date:	
Name:	
Shipping Address:	
Street & Number:	
City & State:	
Zip Code:	
Day Time Phone Number:	
(including area code)	
Date & Place of Purchase:	
	Part(s) description and quantity: (Please be sure to list model number or SKN number)