

Table of Contents

For Your Safety.....	2
Grill Information Center	2
Product Record Information	2
Safety Symbols.....	2
Installation Safety Precautions.....	2
BBQ Pro Grill Warranty	3
Grilling Guide.....	4-7
Use and Care.....	8-13
Parts List.....	14
Parts Diagram	15
Assembly	16-24
Troubleshooting.....	25-26

WARRANTY

BBQ-PRO GRILL WARRANTY

One Year Full Warranty

If this BBQ-Pro product fails due to a defect in material or workmanship within one year from the date of purchase, return it to any Sears or Kmart store or other BBQ-Pro outlet in the United States with your proof of purchase for free replacement.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**Sears Roebuck and Co.,
Hoffman Estates, IL 60179**



WARNING



- **Read and follow all Safety, Assembly, and Use and Care Instructions in this Guide before assembling and cooking with this grill.**
- **Failure to follow all instructions in this Use and Care Guide may lead to fire or explosion, which could result in property damage, personal injury or death.**

This Grill is for Outdoor Use Only

Tools needed for assembly:

Adjustable wrench (not provided)

Screwdriver (not provided)

7/16" Combination wrench (not provided)