

# CRAFTSMAN®

---

## PARTS LIST FOR 24 PC. SOCKET ACCESSORY SET #30024

---



Congratulations on your purchase of a quality CRAFTSMAN Tool Set.  
Should you have any questions about the tools you've just purchased, save some time and call our toll-free

Customer Service Number which is **1-800-832-7494**.

We are open Monday through Friday from 8:00 a.m. to 4:30 p.m. Eastern Standard-Time.

CAT. No.		DESCRIPTION	DRIVE SIZE
1762	3/16	BALL HEX BIT SOCKET LONG	1/4"
1836	7/32	BALL HEX BIT SOCKET LONG	1/4"
17520	5MM	BALL HEX BIT SOCKET LONG	1/4"
17529	6MM	BALL HEX BIT SOCKET LONG	1/4"
17436	T15	TORX BIT SOCKET LONG	1/4"
17448	T20	TORX BIT SOCKET LONG	1/4"
17458	T25	TORX BIT SOCKET LONG	1/4"
17489	T30	TORX BIT SOCKET LONG	1/4"
43177	1-1/2"	WOBBLE EXTENSION BAR	1/4"
43539	3"	EXTENSION BAR	1/4"
43531	6"	EXTENSION BAR	1/4"
4280		UNIVERSAL JOINT	1/4"
20066	1/4	BALL HEX BIT SOCKET LONG	3/8"
20213	5/16	BALL HEX BIT SOCKET LONG	3/8"
21032	3/8	BALL HEX BIT SOCKET LONG	3/8"
17535	7MM	BALL HEX BIT SOCKET LONG	3/8"
17573	8MM	BALL HEX BIT SOCKET LONG	3/8"
17577	10MM	BALL HEX BIT SOCKET LONG	3/8"
17471	T40	TORX BIT SOCKET LONG	3/8"
17483	T45	TORX BIT SOCKET LONG	3/8"
44283	3"	WOBBLE EXTENSION BAR	3/8"
44286	6"	WOBBLE EXTENSION BAR	3/8"
44287	10"	WOBBLE EXTENSION BAR	3/8"
4435		UNIVERSAL JOINT	3/8"

### FULL UNLIMITED WARRANTY ON CRAFTSMAN MECHANICS TOOLS

If any Craftsman Hand Tool ever fails to give complete satisfaction, return it to any Sears store or other Craftsman Outlet in the United States for free repair or replacement. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

SEARS, ROEBUCK AND COMPANY, HOFFMAN ESTATES, IL 60179