



**REPAIR
PARTS
LIST**

253.77185410


For Parts or Service:

Call

**1-800-4-MY-HOME®
(1-800-469-4663)**

Or Visit

www.sears.com



ROOM AIR CONDITIONER

In all orders or correspondence, avoid delays and misunderstandings by always giving the complete model number shown on the front of the base, behind the plastic front cover.

All repair parts listed are available for immediate purchase or special order when you visit your nearest Sears Parts & Repair Center, or the Service Department at most Sears stores. To order parts by phone, call the toll-free number listed to the left or visit sears.com.

When requesting service or ordering parts, always provide the following information:


- | | |
|----------------|--------------------|
| • Product Type | • Part Number |
| • Model Number | • Part Description |

Sears Brands Management Corporation, Hoffman Estates, IL 60179

Publication number 5995658910

RECOMMENDED SPARE PARTS

CAUTION: Use the Kenmore part number to order part, not the illustration number.




RECOMMENDED SPARE PARTSCAUTION: Use the Kenmore part number to order part, not the illustration number.

POS. NO	PART NO.	DESCRIPTION
1 #	5304476302	Front Assembly, complete panel
2	5304476303	• Panel, front grille, tilt-out
3 #	5304476304	• Filter, air
4	5304476305	• Panel, frame, front
5 #	5304476306	• Louver, horizontal
6 #	5304476307	• Louver, vertical
7 #	5304495010	Handle, vent control
8 #	5304476359	Link, lever/vent door, detente
9 #	5304495731	Lever, vent control
10 #	5304495732	Door, vent control
11 #	5304495733	Control Panel, with overlay
12 #	5304500900	PC Board, display/input
13 #	5304496251	• Wire, connector, pc boards
14 #	5304495591	Remote Control, transmitter
15 #	5304500901	Power Cord, electric, LCDI
16	5304495623	Control Box
17	5304495029	Holder, mounting plate, control
18 #	5304500902	PC Board, control/power, main
19 #	5304487548	Sensor, ambient temp, thermistor
20 #	5304471383	Sensor, temperature, evaporator
21 #	5304476316	Sensor, temperature, discharge air, DAHT
22 #	5304471063	Transformer
23 #	5304482883	Capacitor, fan motor
24 #	5304499940	Capacitor, compressor
25	5304500876	Strap, capacitor clamp
26 #	5304500890	Evaporator, +capillary tube
27 #	5304500891	• Tube, capillary
28 #	5304495654	Tube, suction
29 #	5304499938	Compressor, with overload
30 #	5304500892	Tube, discharge
31 #	5304495628	Tube, condensate evap, drain pan
32 #	5304500893	Condenser
33 #	5304476322	Drier-filter
34	5304495630	Bulkhead, partition, front/right
35 #	5304476323	Valve, drain
36	5304476324	Base, unit chassis
37	5304472530	Tray, drip pan
38 #	5304472338	Heater Assembly, electric
39	5304495739	Shield, heater housing
40	5304495740	Scroll, blower housing, bottom
41	5304500903	Scroll, blower housing, top
42	5304495632	Cover, blower scroll, front
43	5304495633	Bulkhead, partition, front/left
44 #	5304472346	Blower Wheel, centrifugal fan
45 #	5304495742	Scroll, blower housing, rear
46 #	5304499941	Motor, fan
47 #	5304472356	Fan Blade, axial flow
48	5304495634	Shroud, condenser/fan
49	5304487567	Retainer, shutter, cabinet sides
50	5304486026	Cabinet, wrapper/sleeve
51	5304476333	Rail, shutter track, top angle

RECOMMENDED SPARE PARTS

CAUTION: Use the Kenmore part number to order part, not the illustration number.




RECOMMENDED SPARE PARTS

CAUTION: Use the Kenmore part number to order part, not the illustration number.

POS. NO	PART NO.	DESCRIPTION
52	5304472546	Screw Kit, top rail mount
53	5304476266	Hardware, mounting, screws/locks
54	5304472548	Seal Kit, foam, top, bottom, sash
55	5304476334	Window Filler Kit, slider panel
56	5304472360	Bracket, sill angle
57	5304482508	Bracket, mounting, right window
58	5304482509	Bracket, mounting, left window
*	5304501076	Use & Care Guide
*	5304495042	Installation Instructions
*	5304493842	Tech Data Sheet/Wiring Diagram
*	5995658910	Repair Parts List
*	5304495743	Energy Guide

WIRING DIAGRAM



Get it fixed, at your home or ours!

Your Home

For troubleshooting, product manuals and expert advice:



www.managemylife.com

For repair – **in your home** – of **all** major brand appliances, lawn and garden equipment, or heating and cooling systems, **no matter who made it, no matter who sold it!**

For the replacement parts, accessories and owner's manuals that you need to do-it-yourself.

For Sears professional installation of home appliances and items like garage door openers and water heaters.

1-800-4-MY-HOME[®] (1-800-469-4663)

Call anytime, day or night (U.S.A. and Canada)

www.sears.com www.sears.ca

Our Home

For repair of "carry-ins" like handheld lawn equipment or home electronics items, call anytime for the location of your nearest

Sears Parts & Repair Service Center

1-800-488-1222 (U.S.A.)

www.sears.com

1-800-469-4663 (Canada)

www.sears.ca

To purchase a protection agreement on a product serviced by Sears:

1-800-827-6655 (U.S.A.)

1-800-361-6665 (Canada)

Para pedir servicio de reparación a domicilio, y para ordenar piezas:

1-888-SU-HOGAR[®]

(1-888-784-6427)

www.sears.com

Au Canada pour service en français:

1-800-LE-FOYER^{MC}

(1-800-533-6937)

www.sears.ca

The Sears logo, consisting of the word "sears" in a lowercase, serif font.

® Registered Trademark / TM Trademark of KCD IP, LLC in the United States, or Sears Brands, LLC in other countries

® Marca Registrada / TM Marca de Fábrica de KCD IP, LLC en Estados Unidos, o Sears Brands, LLC in otros países

^{MC} Marque de commerce / ^{MD} Marque déposée de Sears Brands, LLC