


REPAIR PARTS LIST

253.87050410 253.87050412 253.87050414 253.87050416



ROOM AIR CONDITIONER

In all orders or correspondence, avoid delays and misunderstandings by always giving the complete model number shown on the front of the base, behind the plastic front cover.

All repair parts listed are available for immediate purchase or special order when you visit your nearest Sears Parts & Repair Center, or the Service Department at most Sears stores. To order parts by phone, call the toll-free number listed to the left or visit sears.com.

When requesting service or ordering parts, always provide the following information:

For Parts or Service:

Call
1-800-4-MY-HOME®

(1-800-469-4663)

Or Visit www.sears.com

Product Type


Part Number

Model Number

Part Description

RECOMMENDED SPARE PARTS

CAUTION: Use the Kenmore part number to order <u>part</u>, not the illustration number.



04/15


RECOMMENDED SPARE PARTS

CAUTION: Use the Kenmore part number to order <u>part</u>, not the illustration number.

Model Index: A 253.87050 (253.87050410)
B 253.87050 (253.87050412)
C 253.87050 (253.87050414)
D 253.87050 (253.87050416)

POS. NO 1 # 3 # 5 6 7 8 9 10 11 #	PART NO. 5304500933 5304500934 5304500935 5304500936 5304500937 5304500939 5304500940 5304500941	A B C D A B C D A B C D A B C D A B C D A B C D A B C D A B C D A B C D A B C D A B C D A B C D	DESCRIPTION Front Assembly, complete panel Filter, air Window Filler Kit, slider panels Rail, shutter track, top Screw Kit, top rail mount Hardware, mounting, screws/locks Seal Kit, foam, sash filler Knob Assembly, control, w/spring Power Cord, electric, LCDI
* * * * * *	5304501750	A B C D	Use & Care Guide
	5304500943	A B C D	Installation Instructions
	5304501751	A - C -	Tech Data Sheet/Wiring Diagram
	5304501752	- B - D	Tech Data Sheet/Wiring Diagram
	5995659892	A B C D	Repair Parts List
	5304500944	A B C D	Energy Guide

WIRING DIAGRAM



04/15 4

Get it fixed, at your home or ours!

Your Home

For troubleshooting, product manuals and expert advice:



www.managemylife.com

For repair – in your home – of all major brand appliances, lawn and garden equipment, or heating and cooling systems, no matter who made it, no matter who sold it!

> For the replacement parts, accessories and owner's manuals that you need to do-it-yourself.

For Sears professional installation of home appliances and items like garage door openers and water heaters.

1-800-4-MY-HOME® (1-800-469-4663)

Call anytime, day or night (U.S.A. and Canada)

www.sears.com

www.sears.ca

Our Home

For repair of "carry-ins" like handheld lawn equipment or home electronics items, call anytime for the location of your nearest

Sears Parts & Repair Service Center

1-800-488-1222 (U.S.A.)

1-800-469-4663 (Canada)

www.sears.com

www.sears.ca

To purchase a protection agreement on a product serviced by Sears:

1-800-827-6655 (U.S.A.)

1-800-361-6665 (Canada)

Para pedir servicio de reparación a domicilio, y para ordenar piezas: Au Canada pour service en français:

1-888-SU-HOGAR®

1-800-LE-FOYERMC

(1-888-784-6427)

(1-800-533-6937)www.sears.ca

www sears com



[®] Registered Trademark / TM Trademark of KCD IP, LLC in the United States, or Sears Brands, LLC in other countries ® Marca Registrada / ™ Marca de Fábrica de KCD IP, LLC en Estados Unidos, o Sears Brands, LLC in otros países MC Marque de commerce / MD Marque déposée de Sears Brands, LLC