



UNDERCOUNTER DISHWASHER


MODELS:

WDT710PAHB0 (Black)

WDT710PAHW0 (White)

WDT710PAHZ0 (Stainless)

DOOR AND PANEL PARTS




Literature Parts

DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Access Panel	12		Handle Assembly
	W10806908	Installation Instructions		W10526114	Black		W11024062	Black
	W11046216	Energy Guide		W10526115	White		W11024063	White
	W11049299	Use & Care Guide	6	W10884775	Nameplate		W11090074	Stainless
	W10751166	Tech Sheet, English	7		Vent	13	W10518815	Insulation, Four Layer
	W10751168	Tech Sheet, French		W11105961	Black	14	W10693137	Screw, Set
2		Arm, Hinge		W11105960	White	15	W10316572	Screw
	W10274922	Left Hand		W11105958	Silver	16	W10195726	Stud, Mounting
	W10274921	Right Hand	8		Fastener	17	8268961	Sleeve, Friction
3	W10803537	Stiffener, Door		W10503548	Black			
4		Panel, Front (Includes 6, 7, 9, 15 & 16)		W10503549	White			
	W11049244	Black	9	W11036316	Light, Pipe			
	W11049245	White	10	489470	Screw			
	W11049227	Stainless	11	W10315897	Insulation, Front Panel			


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly	5	W10648588	Screw	8	W11082514	Control, Electronic
	W11045938	Black	6	W11049159	Housing Assembly, User Interface	9	W10194937	Brace, Connector
2	W10756253	Box, Connector				10	W10177098	Screw
3	W10195237	Clip, Control	7	W10574864	Latch Assembly (Includes Switch)			
4	W10566903	Jumper, 4-Wire						


INNER DOOR PARTS



INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348413	Screw	6	8269259	Gasket, Vent	12	W10462232	Bracket, Dispenser
2	W10524920	Cap, Rinse Aid	7	W10671926	Deflector, Vent	13	W10863679	Bracket, Control
3	W10713291	Inner Door Assembly (Also Order Item 6)			(Also Order Item 6)	14	8281217	Screw
4	W10482094	Cover, Dispenser	8	W10671905	Dispenser Assembly			
5	W10428211	Vent Assembly (Also Order Item 6)	9	W10868144	Wiring Harness			
			10	W10177098	Screw			
			11	W10274923	Seal, Console/Door			


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	370445	Clamp, Hose	6	371505	Clamp, Hose	10	304231	Screw
2	W10769066	Hose	7	W10327250	Fill Valve Assembly	11	W10195039	Switch, Overfill Control
3	W10195536	Inlet, Water (Also Order Item 4)	8	W10786175	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	12	W10316267	Standpipe, Overfill
4	8531323	Gasket				13	W10346525	Float & Retainer Assembly
5	W10508676	Nut, Inlet (Also Order Item 4)	9	W10545278	Drain Loop with Check Valve Assembly	14	W10195037	Lever, Overfill Switch


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10349289	Tub Assembly (Includes Heater Assembly)	11	3400892	Screw	21	W10732961	Bracket, Heater Support
2	W10321574	Shield, Thermostat	12	8268991	Cover, Terminal Box	22	W10441445	Heater Element Assembly
3	W10524469	Seal, Tub	13	W10866979	Shield, Tub Sound			(Includes Heater Washer & Nut)
4	W10341745	Screw	14	W10539489	Clip, Thermostat			NOTE: If heater element is removed, it must be replaced.
5	3367670	Screw	15	3371618	Thermostat			
6	8269145	Bracket, Undercounter	16	W10544004	Strike, Latch			
7	W10304231	Support, Bottom	17	3378128	Washer, Pronged Cup			
8	W10619352	Leveler, Leg	18	3400014	Screw, Grounding			
9	W10337934	Spring, Door Balance	19	W10819539	Sound Insulation, Bottom			
10	8575897	Wheel Assembly	20	8268990	Bushing, Door Spring			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	7	W10789806	Filter Cup Assembly	15	W10885542	Motor
2	W10455268	Sump With Seal (Also Order Items 12 & 16)	8	W10724439	Pump, Drain			(Also Order Items 12 & 16)
			9	8269144	Hose, Drain	16	W10445975	Hose Assembly (Includes 2 Clamps)
3	W10463906	Screen	10	370445	Clamp, Hose			
4	W10348407	Screw	11	W10723295	Indicator, Optical Wash	17	W10491331	Sprayarm
5	W10605057	Sump & Motor Assembly	12	W10538166	Grommet	18	W10849439	Motor, Diverter
6	W10372113	Tab, Sump	13	W10169167	Clamp, Hose	19	9741232	Screw
			14	W10195086	Motor, Isolator	20	W10476221	Disc, Diverter


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10340745	Feed Tube Assembly (Includes Items 2 & 3)	2	W10327455	Sprayarm, Third Level	4	W10340681	Manifold
			3	3400918	Retainer	5	W10498900	Sprayarm
						6	W10165274	Screw


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10826746	Dishrack, Upper	4	8565925	Stop, Track (Non-Removable)	6	W10306228	Track, Spacer
2	W10845762	Mount, Wheel Assembly	5	W10380410	Cupshelf, Small	7	W10082861	Stop, Track (Removable)
3	3385089	Track, Dishrack						

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10380384	Dishrack, Lower	3	W10629541	Silverware Basket Assembly	5	W10629537	Lid, Silverware Basket (Center)
2	W10082868	Wheel & Transport Assembly	4	W10629533	Lid, Silverware Basket (Side)	6	W10671904	Clip, Silverware Basket

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.
		Handle Assembly
	W10702080	Black
	W10702081	White

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

POWER CORD KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis