



FOUR DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:


WRX735SDHW00 (White)

WRX735SDHB00 (Black)

WRX735SDHV00 (Black Stainless)

WRX735SDHZ00 (Monochromatic Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	13	W10316403	Wedge, Spacer (Left Hand & Right Hand)	23	W10296541	Lid, HV Control Box
	W10873263	Tech Sheet	14	12992403	Screw	24	W10316401	Wedge, Spacer (Left Hand & Right Hand)
	W10422734	Use & Care Guide	15		Hinge, Center	25	12990702	Screw
	W10920569	Energy Guide			Left Hand	26		Cabinet (Not A Servicable Part)
2	12961401	Tube, Water		W10740148	White	27	W10867574	Control, Electronic
3	12698403	Plate, Pivot		W10740149	Black	28	12990302	Screw
4	B5759655	Gasket		W10740150	Grey	29	W10914798	Gasket, Control Box
5		Cover, Top Hinge			Right Hand	30	W10270394	Cover, Unit
		Left Hand		W10740144	White	31	W10141622	Brake, Roller
	W10337634	White		W10740145	Black	32	M0104106	Clip, Cord
	W10337647	Black		W10740146	Grey	33		Assembly, Roller
	W10337648	Grey	16	W10367522	Slide, Mullion Vent		W10515763	Left Hand
		Right Hand	17		Cover, Corner		W10515762	Right Hand
	12962302W	White		12587703W	White	34		Assembly, Secondary Mullion
	12962302B	Black		12587703B	Black		W10902088	White
	12962302AP	Grey		12587703AP	Grey		W10902087	Black
6		Cover, Fill Tube	18	W10827867	Knob, Vent Slide		W10902089	Grey
	12981401W	White	19		Plug, Button	35	W10843353	Assembly, LED Light Module
	12981401B	Black		A3076901	Black	36	W10820998	Housing, Module
	12981401AP	Grey	20	W10709365	Screw	37	W10492234	Brace, Mullion
7	12961602	Cover, Control Box	21		Shim, Top Hinge	38	W10311721	Mullion, Secondary
8	M0108107	Clamp, Tube		12999501	Left Hand			
9	12992602	Screw		12999502	Right Hand			
10		Hinge, Top	22		Grille, Toe			
	12963204ED	Left Hand		W10534154	White			
	12963205ED	Right Hand		W10534153	Black			
11	489470	Screw		W10534155	Grey			
12	12990511	Screw						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	9	W10118193	Enclosure, Water Valve Connector	17	W10334463	Bracket, Water Tank and Valve
2	3400065	Screw (Stainless)	10	W10444033	Tube, Water	18	W10657242	Assembly, Water Tank and Head (Includes Bypass Cartridge)
3	W10311756	Lens, Refrigerator LED	11	12960101	Cover, Upper Water Tank	19	12664501SP	Cartridge, Bypass
4	W10866538	Module, LED Light	12	12960301	Cover, Filter	20	W10913947	Valve, Water Inlet
5	W10555984	Assembly, Air Grille	13	12960001	Cover, Lower Water Tank			
6	12466103	Switch, Rocker	14	W10735404	Filter, Water			
7	W10118194	Lid, Enclosure	15	12955901	Bracket, Filter Base			
8	W10632157	Housing, Refrigerator LED	16	W10309869	Cover, Wiring			


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	13		Bracket, Door Slide	22	12959901	Grille, Air
2	A3189392	Gasket, Foam		W10330991	Left Hand	23	12951401	Shroud, Evaporator
3	12002497	Gear		W10330993	Right Hand	24	12986101	Blade, Fan
4	12990501	Screw	14	W10315248	Module, Light	25	12951101	Grommet, Fan Motor
5	W10802332	Shaft, Rack	15	12956601	Clip, Fan Motor	26	W10252866	Motor, Evaporator
6	12570701	Socket, Light	16	12466111SP	Switch, Light	27	W10662407	Assembly, Drain Funnel
7	12815301	Cover, Thermistor	17	12990504	Screw	28	M0500703	Seal
8	12990521	Screw	18	B8381501	Gasket, Drain	29	12791417SP	Thermistor
9	W10805744	Lamp, Led	19	W10120018	Slide, Door			
10	W10277466	Foil, Housing	20	A3189396	Gasket			
11	W10308421	Cover, Evaporator	21		Adapter, Side			
12	12990511	Screw		W10284682	Left Hand			
				W10284683	Right Hand			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	5	W10355264	Bucket, Gallon	12	W10287601	Seal, Ice Chute
		Left Hand	6	12990513	Screw	13		Mullion, Door
	13107323W	White	7	W10460893	Screw		W10311759	White
	W10861096	Black	8		Gasket, Door		W10311758	Black
	W11022747	Black Stainless		W10830276	White		W10311757	Grey
	W11022772	Stainless		W10830277	Black	14		Closure, Door
		Right Hand		W10830274	Grey		12028505W	White
	13107319W	White	9		Handle, Door		12028505B	Black
	W10861098	Black		W10887621	White		12028505AP	Grey
	W11022757	Black Stainless		W10887620	Black	15		Stop, Door
	W11022776	Stainless		W10918272	Black Stainless		12968202W	White
2	W10355269	Bucket, Upper		W10874805	Stainless		12968202B	Black
3	W10355270	Bucket, Small	10	W10884773	Badge		12968202AP	Grey
4	12990521	Screw	11	W10511930	Waterline, Door	16	12996601	Clip, Bushing


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer	5	W10348249	Basket, Upper	10		Bracket, Door Slide
	W11023065	White	6	W10146439	Divider, Upper Basket		W10330991	Left Hand
	W11023033	Black	7		Gear		W10330993	Right Hand
	W10920749	Black Stainless		W10474716	Left Hand	11		Handle, Door
	W11022780	Stainless		W10474715	Right Hand		W10887633	White
2		Gasket, Door	8		Rack, Side		W10887632	Black
	W10443321	White		W10516603	Left Hand		W11024145	Black Stainless
	W10436253	Black		W10516602	Right Hand		W10874811	Stainless
	W10714545	Grey	9		Mount, Gear	12	W10460893	Screw
3	W10293682	Bin, Lower		W10348259	Left Hand			
4	W10802333	Shaft, Rack		W10348260	Right Hand			


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	16	12992101	Screw	32	W10350564	Capacitor
2	12825803	Blade, Fan	17	W10806346	Grommet, Compressor	33	W10236396	Strap, Compressor
3	W10480111	Basepan	18	W10346415	Condenser	34	W10334458	Connector, Water Tube
4	12990511	Screw	19	W10281329	Clip, Drier	35	W10815863	Clip, Condenser
5	2319835	Grommet, Condenser	20	W10292803	Tray, Drip	36	2169104	Sealer, Insulation
6	W10795418	Tube, Discharge	21	12990702	Screw			
7	W10276647	Motor, Evaporator (Includes Heater Harness, Defrost Thermostat and Thermistor)	22	W10313899	Evaporator			FOLLOWING PARTS NOT ILLUSTRATED
8	W10655368	Pan, Drain	23	A3189397	Gasket, Foam	978025		Valve, Access
9	W10622701	Screw	24	W10609117	Motor, Condenser Fan	978026		Valve, Access
10	12729123	Heater, Defrost	25	10428101	Clip, Heater	978027		Valve, Access
11	W10798748	Device, Start	26	W10679214	Harness, Unit (Includes Power Cord)	978028		Valve, Access
12	W10216075	Strap, Bale	27	W10177049	Drier	978029		Valve, Access
13	W10137529	Grommet, Condenser	28	W10775170	Compressor	978030		Valve, Access
14	W10622099	Extension, Drain Tube	29	10623002	Clip, Evaporator	876764		Valve, Access
15	12477102	Roller	30	12477202	Axle, Roller			REFRIGERANT CHARGE
			31	W10189184	Shroud, Condenser Fan			4.50 oz. (R-134A)

SHELF PARTS




SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10345310	Assembly, Shelf and Roller
2		Runner, Roller
	W10346891	Left Hand
	W10346890	Right Hand
3	8281136	Screw
4	W10366647	Pan, Deli
5	W10818645	Divider, Sliding
6	W10329926	Shelf, Mini
7		Door, Pantry
	W11023061	White
	W10921835	Black
	W10920753	Black Stainless
	W11022766	Stainless
8		Gasket, Pantry
	W10443325	White
	W10436255	Black
	W10443326	Grey
9	W10329925	Shelf, Stationary
10		Adapter, Pantry
	W10666362	Left Hand
	W10666363	Right Hand

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10277360	Gear, Spur
12		Cover, Gear
	W10284709	Left Hand
	W10294414	Right Hand
13	W10272364	Screw
14	W10460893	Screw
15	W10802341	Shaft, Rack
16		Ladder, Side
	W10251968	Left Hand
	W10251965	Right Hand
17	W10277361	Collar, Gear
18	W10801677	Pan, Pantry
19	W10273464	Ladder, Center
20		Handle, Door
	W10887633	White
	W10887632	Black
	W11024145	Black Stainless
	W10874811	Stainless
21	12990513	Screw
22	12990512	Screw
23	W10818644	Divider, Pantry
24	W10296571	Glass, Pantry Shelf

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
25	12466104	Switch, Rocker
26		Rail, Pantry
	W10311723	Left Hand
	W10311726	Right Hand
27	W10385043	Runner, Channel
28	W10331298	Rail, Rear Pantry
29	12990521	Screw
30		Cover, Pantry Rail
	W10311725	Left Hand
31	W10396909	Front, Deli Pan


DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	4		Assembly, Pad (Includes Blue Light)	9		Dispenser, Tray
							W10267869	White
2		Assembly, User Interface		W10353846	White		W10267870	Black
				W10353847	Black		W10299895	Nickel
	W10887493	Silver		W10353848	Grey	10		Tray, Dispenser Slide
3		Wall, Dispenser False	5	W10238083	Assembly, LED		W10267860	White
	W10215699	White	6	W10353552	Assembly, Seperator		W10267861	Black
	W10233560	Black	7	2316647	Assembly, Spigot Body		W10267863	Grey
	W10299897	Grey				11	W10254277	Cover, Board
			8	W10339578	Guide, Ice			

ICEMAKER & ICE CONTAINER PARTS



ICEMAKER & ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10562191	Assembly, Ice Bin	10	W10309868	Motor, Auger	19	W10300024	Assembly, Icemaker (Complete)
2	W10121282	Inlet, Blower	11	W10196393	Damper, Control	20	W10175514	Arm, Shutoff
3	W10309863	Scroll, Blower	12	W10309866	Assembly, Solenoid	21	W10351019	Extension, Shutoff Arm
4	W10308033	Motor, Fan	13	W10118612	Liner, Divider	22	W10290556	Cover
5	W10123444	Wheel, Blower	14	12990511	Screw	23	W10826037	Harness, Icemaker
6	12956603	Clip, Fan Motor	15	W10346971	Bracket, Solenoid			
7	W10151687	Grommet, Fan Motor	16	W10465946	Washer			
8	W10309864	Divider, Ice Box	17	63052A001	Yoke, Ice Dispenser			
9	12920001	Gasket, Damper	18	W10312691	Assembly, Impinger			

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key