



BOTTOM MOUNT FRENCH DOOR REFRIGERATOR

MODELS:


WRF535SWHW00 (White)

WRF535SWHB00 (Black)

WRF535SWHV00 (Black Stainless)

WRF535SWHZ00 (Monochromatic Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	10463203	Elbow, Fill Tube	21	W10211855	Cover, Unit
	W10597594	Use and Care Guide	11	12990101	Screw	22		Grille, Toe
	W10920562	Energy Guide	12	12698403	Plate, Pivot		W10534154	White
	W10517966N	Tech Sheet	13	12726003	Cover, Water Line		W10534153	Black
2		Cabinet (Not a Servicable Part)	14	12992403	Screw		W10534155	Grey
3		Cover, Top Hinge	15		Hinge, Center	23	12990302	Screw
		Left Hand			Left Hand	24	M0108107	Clamp, Tube
	W10337634	White		W10740148	White	25	12990511	Screw
	W10337647	Black		W10740149	Black	26	B5705333	Tubing, Plastic
	W10337648	Grey		W10740150	Grey	27	12990504	Screw
		Right Hand			Right Hand	28		Shim, Top Hinge
	12962302W	White		W10740144	White		12999501	Left Hand
	12962302B	Black		W10740145	Black		12999502	Right Hand
	12962302AP	Grey		W10740146	Grey	29	M0114003	Clip, Speed
4	B5759655	Gasket	16	A3223101	Insert, Tube	30	W10420083	Valve, Water Inlet
5	W10208593	Guard, Dual Water Valve	17		Cover, Corner			
				12587703W	White			
				12587703B	Black			
				12587703AP	Grey			
6	W10141622	Brake, Roller	18	W10658542	Block, Fill Tube			
7		Hinge, Top	19		Assembly, Roller			
	12963204ED	Left Hand		W10515763	Left Hand			
	12963205ED	Right Hand		W10515762	Right Hand			
8	W10528513	Sweep, Dual Tube	20	W10709365	Screw			
9	12992602	Screw						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	15	W10594330	Damper, Control	28	12707206	Guide, Waterline
2	W10464764	Module, Light	16	W10735404	Filter, Water	29	12251001	Clip, Water Tube
3	W10613576	Overlay, Control	17	12861601	Switch, Energy Saver	30	W10117358	Insulation, Water Tank
4	W10464775	Module, Control	18	61006182	Union, Water	31	B8390302	Clip, Facade
5	W10503278	Control, Electronic	19	12706112	Tank, Water	32	12707005	Facade, Dispenser (Top)
6	C3680310V	Switch, Light	20	12990513	Screw	33	10685510	Gasket, Seal
7	12806501	Cover, Light	21	12664501SP	Cartridge, Bypass			FOLLOWING PARTS NOT ILLUSTRATED
8	W10443023	Housing, Light	22	12704801	Plate, Filter			
9	W10805744	Lamp, Led	23	W10609243	Head, Water Filter (Includes Bypass Cartridge)	W10389967		Harness, Controls (Refrigerator)
10	12570701V	Socket, Light						
11	12806801	Insert, Damper Cover	24	12568001	Cover, Filter			
12	12990604	Screw	25	12575501	Switch, Limit			
13	12806701	Cover, Damper	26	W10585703	Facade, Dispenser			
14	13012402	Insulation, Damper	27	W10585699	Plate, Dispenser			


FREEZER LINER AND ICEMAKER PARTS



FREEZER LINER AND ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	16	12466105	Switch, Light	26	12990521	Screw
2	A3189392	Gasket, Foam	17		Rail, Side	27	W10202524	Arm, Shut Off
3	12932103	Guide, Fill Tube		W10516603	Left Hand	28	W10120018	Slide, Door
4	W10157765	Diverter, Air		W10516602	Right Hand	29		Adapter, Slide
5	W10128551	Motor, Evaporator	18	W10662407	Assembly, Drain Funnel		W10284684	Left Hand
6	12570701	Socket, Light	19	M0500703	Seal		W10284685	Right Hand
7	12002497	Gear	20	A3189396	Gasket	30	12990501	Screw
8	12815301	Cover, Thermistor	21	B8381501	Gasket, Drain	31	W10802332	Shaft, Rack
9	W10805744	Lamp, Led	22	13024803	Grille, Freezer Air	32	12791409SP	Thermistor
10	W10277466	Foil, Housing	23	13057901	Shroud, Evaporator Fan	33	W10445790	Cover, Ice maker
11	W10308416	Cover, Evaporator	24	2169142	Blade, Fan	34	W10793621	Harness, Ice maker Wire
12	12990511	Screw	25		Bracket, Door	35	W10171529N	Pan, Ice
13	W10121318	Grommet		W10330991	Left Hand	36	W10793298	Assembly, Ice maker (Complete)
14	W10277025	Module, Light		W10330993	Right Hand			
15	13058002	Clip, Evaporator Motor						


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	4	W10460893	Screw	10	12990504	Screw
		Left Hand	5	W10371194	Bucket, Medium	11		Stop, Door
	13107888W	White	6		Mullion, Door		12968202W	White
	W10861180	Black		12722803W	White		12968202B	Black
	W10879200	Black Stainless		12722803BN	Black		12968202AP	Grey
	W10890275	Stainless		12722803APN..Grey		12	W10884773	Badge
		Right Hand	7	12990204	Screw	13	12996601	Clip, Bushing
	13107887W	White	8		Gasket, Door			
	W10861182	Black		W10830189	White			
	W10879190	Black Stainless		W10830206	Black			
	W10890281	Stainless		W10830162	Grey			
2	W10289497	Bucket, Gallon	9		Handle, Door			
3		Closure, Door		W10887612	White			
	12028505W	White		W10887611	Black			
	12028505B	Black		W10917722	Black Stainless			
	12028505AP	Grey		W10874799	Stainless			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer	2		Handle, Door	3		Gasket, Door
	12977879W	White		W10887633	White		W10443319	White
	W10861085	Black		W10887632	Black		W10436252	Black
	W10879185	Black Stainless		W11024145	Black Stainless		W10443320	Grey
	W10890615	Stainless		W10874811	Stainless	4	W10460893	Screw


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	18	W10346415	Condenser	34	A3189397	Gasket, Foam
2	12825803	Blade, Fan	19	W10281329	Clip, Drier	35	W10815863	Clip, Condenser
3	W10480111	Basepan	20	W10292803	Tray, Drip			FOLLOWING PARTS NOT ILLUSTRATED
4	12990511	Screw	21	12990701	Screw			
5	W10350564	Capacitor	22	W10669255	Evaporator		978025	Valve, Access
6	W10233569	Tube, Discharge	23	2169104	Sealer, Insulation		978026	Valve, Access
7	W10292244	Harness, Evaporator (Includes Heater)	24	W10609117	Motor, Condenser Fan		978027	Valve, Access
8	W10655368	Pan, Drain	25	10428101	Clip, Heater		978028	Valve, Access
9	W10622701	Screw	26	W10679216	Harness, Unit (Includes Power Cord)		978029	Valve, Access
10	12729123	Heater, Defrost	27	W10177049	Drier		978030	Valve, Access
11	W10216075	Strap, Bale	28	W10485433	Compressor		876764	Valve, Access
12	W10796752	Device, Start	29	10623002	Clip, Evaporator			REFRIGERANT CHARGE
13	W10137529	Grommet, Condenser	30	12477202	Axle, Roller			5.00 oz. (R-134A)
14	W10236396	Strap, Compressor	31	W10189184	Shroud, Condenser Fan			
15	12477102	Roller	32	W10622099	Extension, Drain Tube			
16	12992101	Screw	33	2319835	Grommet, Condenser			
17	10835903	Grommet						

SHELF PARTS



SHELF PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10893772	Glass, Shelf
2	W10596756	Assembly, Produce Preserver
3	W10149389N	Lift, Bail Arm
4	W10528935	Trim, Pantry Glass
5	12227305WH	Brace, Pantry
6	12531901	Track, Deli Drawer
7	W10171558	Divider, Basket (Upper)
8	W10241046	Divider, Basket (Upper)
9	12656901	Gasket, Pantry
10	12656202	Housing, Control
11	W10739590	Assembly, Fixed Shelf
12	12655402	Slide, Temperature Control
13	12990512	Screw
14	W10235370	Glide, Pantry

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	12990513	Screw
16		Endcap, Pantry
	W10845509	Left Hand
	W10845508	Right Hand
17	12804601SP	Pan, Crisper
18	12642303WD	Brace, Crisper Cover
19	W10231345N	Trim, Crisper
20	W10329866	Frame, Crisper
21	12204824N	Glass, Shelf
22	W10273463	Ladder, Center
23	W10569182	Ladder, Side
24	12990513	Screw
25	W10215666	Screw
26	12990504	Screw
27	12530805SP	Slide, Humidity Control
28	12655304	Bar, Control
29	12731302	Drawer, Pantry
30	12655204	Knob, Temperature Control

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
31	12656813	Lid, Pantry
32	W10293682	Bin, Lower
33	13062602	Support, Crisper Frame
34	W10348246	Basket, Freezer (Upper)
35		Gear, Spur
	W10474716	Left Hand
	W10474715	Right Hand
36	W10326469N	Rail, Center Crisper
37	W10802333	Shaft, Rack
38		Mount, Gear
	W10348259	Left Hand
	W10348260	Right Hand
39	12802602SP	Front, Crisper Pan

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key