


ASSEMBLY INSTRUCTION

DE - MONTAGEANWEISUNG
 FR - INSTRUCTIONS DE MONTAGE
 DK - MONTAGEVEJLEDNING
 CZ - NÁVOD K MONTÁŽI
 ES - INSTRUCCIONES DE MONTAJE
 FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU
 SE - MONTERINGSANVISNING
 SI - NAVODILA ZA MONTAŽO
 TR - MONTAJ TALIMATI
 NO - MONTASJEANVISNING
 IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
 NL - MONTAGE INSTRUCTIE
 PT - INSTRUÇÕES DE MONTAGEM
 PL - INSTRUKCJA MONTAŻU
 HU - SZERELÉSI UTASÍTÁS



30 min

0 cm
1
2
3
4
5
6
7
8
9
10
11
12
13
14

1



x 04

HW-ST-02-023
(6x30)

2



x 36

HW-ST-07-115
(6.5x14x2)


3



x 18

HW-ST-03-004
(6x5)

4



x 2

HW-ST-02-256
(6x125)


5



x 12

HW-ST-02-029
(6x40)


6



x 2



HW-ST-18-001
(4x98)


7




x 2

HW-ST-18-009
(10x76)







Ⓐ x 1
SU-SC-SP-0034




Ⓒ x 1
SU-SC-LF-0267



Ⓓ x 1
SU-SC-LF-0268



Ⓑ x 1
SU-SC-ST-0205



Ⓔ x 1
SU-SC-BF-0188

