

---

## Table of Contents

Kenmore Elite Warranty .....	2	General Care & Cleaning .....	11-13
IMPORTANT SAFETY INSTRUCTIONS .....	3-4	Cleaning Various Parts of Your Cooktop .....	11
Product Record .....	5	Porcelain Enamel Cooktop Cleaning Instructions .....	11
Serial Plate Location .....	5	Cleaning the Burner Grates .....	12
Grounding Instructions .....	5	Cleaning the Burner Caps .....	12
Liquefied Petroleum (Propane) Gas Conversion .....	5	Cleaning the Burner Heads .....	12
Setting Surface Controls .....	6-7	Cleaning the Vent Grate .....	13
Surface Cooking .....	8	Cleaning the Vent Grate Seal .....	13
Setting the Downdraft Vent System .....	9	Cleaning the Grease Filter .....	13
Setting Surface Burner Controls .....	9-10	Cleaning the Vent Chamber .....	13
		Before You Call .....	14
		Protection Agreements .....	15
		Sears Service .....	Back Cover

---

### Kenmore Elite Warranty

When installed, operated and maintained according to all instructions supplied with the product, if this appliance fails due to a defect in material and workmanship within one year from the date of purchase, call 1-800-4-MY-HOME® to arrange for free repair.

This warranty applies for only 90 days from the date of purchase if this appliance is ever used for other than private family purposes.

**This warranty covers only defects in material and workmanship. Sears will NOT pay for:**

1. Cracks in a ceramic glass cooktop that are not a result of thermal shock.
2. Stains and scratches on a ceramic glass cooktop resulting from accident or improper operation or maintenance.
3. Expendable items that can wear out from normal use, including but not limited to filters, belts, light bulbs, and bags.
4. A service technician to instruct the user in correct product installation, operation or maintenance.
5. A service technician to clean or maintain this product.
6. Damage to or failure of this product if it is not installed, operated or maintained according to the all instructions supplied with the product.
7. Damage to or failure of this product resulting from accident, abuse, misuse or use for other than its intended purpose.
8. Damage to or failure of this product caused by the use of detergents, cleaners, chemicals or utensils other than those recommended in all instructions supplied with the product.
9. Damage to or failure of parts or systems resulting from unauthorized modifications made to this product.

**Disclaimer of implied warranties; limitation of remedies**

Customer's sole and exclusive remedy under this limited warranty shall be product repair as provided herein. Implied warranties, including warranties of merchantability or fitness for a particular purpose, are limited to one year or the shortest period allowed by law. Sears shall not be liable for incidental or consequential damages. Some states and provinces **DO NOT** allow the exclusion or limitation of incidental or consequential damages, or limitation on the duration of implied warranties of merchantability or fitness, so these exclusions or limitations may not apply to you.

This warranty applies only while this appliance is used in the United States or Canada.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**Sears Brands Management Corporation, Hoffman Estates, IL 60179 - Sears Canada Inc., Toronto, Ontario, Canada M5B 2C3**