



Installation Instructions/Warranty Information



1. Remove old showerhead with wrench. Clean threads of shower arm.



2. Apply 2 revolutions of thread tape to threads of shower arm. Make sure the tape is applied tightly in a clockwise direction.



3. Position screen washer into showerhead and attach showerhead to shower arm. Hand tighten only (do not over-tighten). Turn on water and check for leaks.

NOTE:

To change the spray settings, position hand on face of showerhead and rotate by pressing finger against tab.

Limited Lifetime Warranty

This Body Moods® product is warranted to be free from defects in material and workmanship for limited lifetime. The Waxman Consumer Group will replace FREE OF CHARGE, under the warranty conditions, the entire unit or any part (at our option) which proves defective under normal installation, use and service. This warranty is limited to defective parts as stated. Additional labor charges and/or damage incurred in installation, repair or replacement, as well as incidental and consequential damages, therewith are excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Any damage to this product as a result of misuse, abuse, neglect, accident, improper installation, or any use violating instructions furnished by us WILL VOID THIS WARRANTY. Problems associated with hardwater buildup and/or water supply sediment are not covered under this warranty. To obtain warranty service, send product to: The Waxman Consumer Group, 24455 Aurora Road, Bedford Heights, Ohio 44146

For additional assistance or service call 1-800-531-3342

Meets A112.18.1M Requirements 2.5 gpm (9.5 L/min) Max



Made in China www.waxmancpg.com © 2012 Waxman Consumer Products Group