CONVENIENCE CONCEPTS

French Country Hall Table



Item No. 6042188 6042188BL M6042189

HARDWARE LIST

PARTS LIST

Q'TY

1PC

1PC

4PCS


CODE	NAME	FIGURE	Q'TY	CODE	NAME	FIGURE
A	CAM LOCKS (Ø15x9mm)		4PCS	1	TOP PANEL	
В	CAM BOLTS (Ø6.5x35mm)		4PCS	2	BOTTOM PANEL	
С	RAIL SCREW (Φ1/4"*51mm)		8PCS	3	LEG	
D	SPRING WASHER (Φ1/4")	G	8PCS			
E	FLAT WASHER (Φ1/4"*16mm)	0	8PCS			
F	ALLEN WRENCH		1PC			
G	HANDLE SCREW (22mm)		1PCS			
Н	HANDLE		1PCS			




Please do not return to the store

- . Broken or Missing Parts?
- . Need help with Assembly?

If you have any questions just call 1-800-468-6447 or email us parts@convenience-concepts.com




1.) Screw Cambolts (B) into Legs (3).



2.) Insert Legs into Bottom Panel (2) and Lock into position by turning Cam Locks (A) Clockwise. ***Turn only 1/4 of the way for lock position.***

STEP 3

1.) Place Leg Assembly onto Top Panel (1).





STEP 4

 $C \times 8pcs$ $D \times 8pcs$ $E \times 8pcs$ $F \times 1pc$

1.) Assemble Rails Screws (C) with Spring Washer (D) and Flat Washer (E) in order as shown.

2.) Using Allen Wrench (F), fasten Rail Screw Assembly to secure Top Panel (1) to Leg Assembly.





STEP 5

 $\begin{aligned} \mathbf{G} \times \mathbf{1pcs} \\ \mathbf{H} \times \mathbf{1pcs} \end{aligned}$

1.) Secure Drawer Handle (H) using Handle Screw (G) as shown.



Enjoy your new quality piece of furniture for years to come!

