


CONVENIENCE CONCEPTS

YUKON END TABLE

171145



ASSEMBLY INSTRUCTIONS

We have designed our furniture with you , the customer in mind . Our clear , easy to follow , step by step instructions will guide you through the project from start to finish . Feel confident that this will be a fun and rewarding project . The final product will be a quality piece of furniture that will go together smoothly and give years of enjoyment .



Please do not return to the store

Broken or missing parts?


Need help with assembly?

If you have any questions just call 1-800-468-6447 or email us at parts@convenience-concepts.com

Hardware List


A	B	C	D	E
				
Large bolt (8pcs)	Small bolt (8pcs)	Spring Washer(16pcs)	Washer (16pcs)	Allen Key(1pc)

Panel List



Please count and verify all parts before assembly.

Exploded Views





***Assemble unit on carpet or flat surface.**

***Do not fully tighten the bolts until unit is completely assembled**



Step 1

1. Connect bottom support (4) to side frame (3) using small bolt (B), spring washer (C), washer (D) and allen key (E) as shown.



Step 2

1. Attach shelf panel (2) to assembly using small bolt (B), spring washer (C), washer (D) and allen key (E) as shown.





Step 3

*Do not fully tighten bolts in top panel ① until all bolts have been started

1. Place top panel ① facedown on a clean soft surface. then connect assembly to top panel ① using large bolt (A), spring washer (C), washer (D) and allen key (E) as shown .

2. Fully tighten all bolts.



Step 4

1. Finish and enjoy.

