

# SNOWJOE®

## SHOVELUTION™ 18" CLEAR SNOW SHOVEL ASSEMBLY INSTRUCTIONS

Model SJ-SHLV02

A Division of Snow Joe®, LLC

© 2017 by Snow Joe®, LLC  
All rights reserved. Original instructions.

### CAUTION!

**HANDLE IS SPRING LOADED UNDER HEAVY TENSION.**

To avoid injury, securely grasp handle before cutting zip ties.  
Then, remove retaining strap and save for later storage.

#### **TO ASSEMBLE:**

1. Depress the small button at the end of the lower pole, push and insert the lower pole into the poly blade unit until it snaps securely into place.
2. Remove the knob and the bolt from the upper pole.
3. Insert the top of the lower pole into the upper pole.
4. Align bolt holes, insert the bolt into the square hole, through pole.
5. Tighten with the knob.

#### **TO DISASSEMBLE:**

Follow instructions above in reverse order.

#### **FOR STORAGE:**

Make a loop with the retaining strap around the spring-loaded handle, and with the other end, secure to knob on the upper pole.

**NOTE:** If you have further questions, please contact the Snow Joe® + Sun Joe® customer service center at 1-866-SNOWJOE (1-866-766-9563).

# SNOWJOE®

## PELLE À NEIGE TRANSPARENTE SHOVELUTION<sup>MC</sup> 46 cm (18 po) INSTRUCTIONS D'ASSEMBLAGE

Modèle SJ-SHLV02

A Division of Snow Joe®, LLC

© 2017 by Snow Joe®, LLC  
Tous droits réservés. Instructions d'origine.

### MISE EN GARDE!

**UN RESSORT EXERCE UNE FORTE TENSION SUR LE MANCHE.**

Pour éviter de vous blesser, tenez fermement le manche avant de couper les liens qui l'attachent. Retirez ensuite la sangle de retenue et mettez-la de côté pour l'utiliser quand vous remiserez l'outil.

### POUR ASSEMBLER :

1. Enfoncez le petit bouton à l'extrémité du manche inférieur, poussez-le et insérez-le dans la lame en polyester jusqu'à ce qu'il s'enclenche pour se mettre en place.
2. Retirez le bouton et le boulon du manche supérieur.
3. Insérez le haut du manche inférieur dans le manche supérieur.
4. Alignez les trous des boulons; insérez le boulon dans le trou carré, à travers le manche.
5. Serrez à l'aide du bouton.

### POUR DÉMONTER :

Suivez les instructions ci-dessus en ordre inverse.

### POUR LE REMISAGE :

Avec la sangle de retenue, faites une boucle que vous passerez autour du manche à ressort et attachez l'autre extrémité au bouton sur le manche supérieur.

**REMARQUE :** si vous avez la moindre question, veuillez communiquer avec le service clientèle Snow Joe® + Sun Joe® au 1-866-SNOWJOE (1-866-766-9563).