

QUICK START GUIDE

2043 SERIES




POWERGLIDE® LIFT-OFF PET UPRIGHT VACUUM




WARNING

Refer to the enclosed user guide for complete instructions and important safety notices.


Assembly Instructions




1. Slide handle into vacuum base and attach with the screw that is taped to the handle.




2. Attach hose by lining the tabs on the cuff with the notches on the back of vacuum. Twist clockwise to lock hose into place.



3. Push handle end into base of vacuum on opposite side.




4. Slide the Pet TurboEraser® Tool holder down on the top back of the base.



5. Slide the Crevice Tool/Extension Wand holder down onto the middle of the back of base. Store both tools in the holder.


PARTS INCLUDED



Upper Handle



Base Unit



Hose



Pet TurboEraser® Tool Holder



Pet TurboEraser® Tool



Pet Hair Eraser® Tool (only available select models)



Crevice Tool/Extension Wand Holder




Combination Dusting/Crevice Tool




Extension Wand

Optional Febreze® Filter



1. To use your optional Febreze® filter (included), press the tank release button and pull dirt tank away from vacuum.




2. Remove the black/yellow foam filter and replace with the black Febreze® filter. Be sure to place the Febreze® filter last, covering the mesh filter. Place dirt container back on vacuum.


Cleaning Filters



1. With vacuum unplugged, remove the tank and lift up on the tab attached to the filter cover. There are 2 filters here; one foam filter on top and a thinner fiber filter; both are washable.



2. Remove post-motor filter located on the front of the vacuum underneath the filter cover. If it appears dirty, remove the filter and gently tap the filter on the edge of a waste basket. This filter is not washable.



3. Replace the post-motor filter by pushing it straight back, clicking each side.