

# **ASSEMBLY INSTRUCTIONS**

## CAMERON KITCHEN CART GRANITE TOP # 464809BLK01U



## We are here to help!


We do our best to insure that your furniture arrives in excellent condition. In the event that a part is damaged or missing, Linon Home Decor will be happy to provide you with replacement parts, at no charge, within 30 days of purchase, providing the parts are available in our warehouse and the item purchased is part of our current inventory. In order to receive spare parts, at no charge, you must provide proof of purchase within 30 days.

If you need assistance with assembly or replacement parts, please call Linon Customer Service, prior to returning the item to the store.

Our office is open Monday – Friday 9AM – 5PM, Eastern Standard Time.


Our toll free customer service number is: 1-800-262-1852.

Or visit our web site <u>www.Linon.com</u> to order spare parts and for care instructions on your newly purchased furniture.





# PARTS IDENTIFICATION



If any parts are missing or damaged in this package, Linon Home Decor will be happy to provide you with replacement parts, at no charge, within 30 days of purchase, providing the parts are available in our warehouse and the item purchased is part of our current inventory. In order to receive spare parts, at no charge, you must provide proof of purchase within 30 days.

Call us toll free at 1-800-262-1852. Or visit our web site <u>www.Linon.com</u> to order spare parts and for care instructions on your newly purchased furniture.



# PARTS IDENTIFICATION

DESCRIPTION	QTY
TOP PANEL	01
BLOCK	02
BAR	01
LEFT FRAME	01
RIGHT FRAME	01
FRONT RAIL	01
BACK RAIL	01
FRONT CROSS BAR	01
BACK CROSS BAR	01
BACK PANEL	01
FIXED SHELF	01
LOWER CROSS BAR	01
BOTTOM RAIL	01
BACK RAIL	01
LEFT DOOR	01
BACK PANEL	01
LEFT DRAWER SIDE	01
RIGHT DRAWER SIDE	01
DRAWER BACK	01
DRAWER FRONT	01
DRAWER BOTTOM	01
RIGHT DOOR	01
TUBE	01
	TOP PANEL BLOCK BAR LEFT FRAME RIGHT FRAME FRONT RAIL BACK RAIL FRONT CROSS BAR BACK CROSS BAR BACK PANEL FIXED SHELF LOWER CROSS BAR BOTTOM RAIL BACK RAIL LEFT DOOR BACK PANEL LEFT DRAWER SIDE RIGHT DRAWER SIDE DRAWER BACK DRAWER BOTTOM RIGHT DOOR

If any parts are missing or damaged in this package, Linon Home Decor will be happy to provide you with replacement parts, at no charge, within 30 days of purchase, providing the parts are available in our warehouse and the item purchased is part of our current inventory. In order to receive spare parts, at no charge, you must provide proof of purchase within 30 days.

Call us toll free at 1-800-262-1852. Or visit our web site <u>www.Linon.com</u> to order spare parts and for care instructions on your newly purchased furniture.



### HARDWARE IDENTIFICATION

Please line up the hardware with the correct full size image to make sure you are installing the hardware correctly.

ITEM	PICTURE	DESCRIPTION	QTY	
A		(Ø5mm x 55mm) Not to Scale	SCREW	18
В		(Ø8mm x 30mm) Full size	WOODEN DOWEL	12
С		(45mm) Not to Scale	MAGNET DOOR STOP	01
D		(Ø3mm x 14mm) Full size	SCREW	02
E		Not to Scale	HINGE	04
F		(Ø3mm x 12mm) Full size	SCREW	19
G		Not to Scale	METAL PLATE	02
н		Not to Scale	HANDLE	03
I		(Ø4mm x 10mm) Full size	BOLT	02
J		Not to Scale	CASTER WITHOUT BRAKE	02
K		Not to Scale	CASTER WITH BRAKE	02

If any parts are missing or damaged in this package, Linon Home Decor will be happy to provide you with replacement parts, at no charge, within 30 days of purchase, providing the parts are available in our warehouse and the item purchased is part of our current inventory. In order to receive spare parts, at no charge, you must provide proof of purchase within 30 days.

Call us toll free at 1-800-262-1852. Or visit our web site <u>www.Linon.com</u> to order spare parts and for care instructions on your newly purchased furniture.



## HARDWARE IDENTIFICATION


Please line up the hardware with the correct full size image to make sure you are installing the hardware correctly.

ITEM	PICTURE		DESCRIPTION	QTY
J		(Ø4mm x 30mm) Full size	SCREW	10
K		(Ø3.5mm x 12mm) Full size	SCREW	04
L	<u> </u>	Not to Scale	SLIDE	01
M		Not to Scale	SLIDE	01
N		(Ø8mm x 20mm) Full size	WOODEN DOWEL	02
O		Not to Scale	ALLEN WRENCH	01
Р		Not to Scale	CASTER WITHOUT BRAKE	02
Q		Not to Scale	CASTER WITH BRAKE	02
R		(Ø4mm x16mm) Full size	BOLT	04
S		Not to Scale	WOODEN PLUS	14

Call us toll free at 1-800-262-1852. Or visit our web site <a href="www.Linon.com">www.Linon.com</a> to order spare parts and for care instructions on your newly purchased furniture.

If any parts are missing or damaged in this package, Linon Home Decor will be happy to provide you with replacement parts, at no charge, within 30 days of purchase, providing the parts are available in our warehouse and the item purchased is part of our current inventory. In order to receive spare parts, at no charge, you must provide proof of purchase within 30 days.







- 1. DO NOT TIGHTEN BOLTS COMPLETELY UNTIL ALL BOLTS ARE COMPLETELY LINED UP AND INSERTED INTO HOLES / NUTS.
- 2. DO NOT OVER TIGHTEN SCREWS AND BOLTS TO AVOID STRIPPING.









STEP 4.




























# LIMITED 6 MONTHS WARRANTY WHAT IS COVERED

This product is covered under our manufacturer's 6 months limited warranty (Linon Home Décor Products). To ensure your complete satisfaction, this warrants to the original purchaser that the Linon supplied item is free from defects in material and workmanship, as of the date of purchase, and that it will, under normal use and proper care, remain so for six months after the date of purchase.

Replacement of missing or initially defective parts will be sent, at no charge, for a period of 30 days from the date of purchase with valid proof of purchase providing the parts are available in our warehouse and the item purchased is part of our current inventory.

### WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from the customer service center. Labor and material charges to remove or replace parts under this warranty are not covered.

This warranty does not cover: Furniture used for commercial purposes, failures caused by improper installation assembly or by improper care, unreasonable or abusive use, freeze damage, acts of God, rust, purchased parts or return freight and packaging charges. Proof of purchase (dated register receipt) is required for warranty claims.

#### **HOW TO OBTAIN SERVICE**

For further information, please contact our customer service department, c/o Linon Home Décor Products, Inc., between 9:00 AM and 5:00 PM Eastern Standard Time, Monday through Friday:

LINON HOME DÉCOR PRODUCTS, INC., CUSTOMER SERVICE DEPARTMENT

- 1) Email address: consumersupport@linon.com
- 2) Toll free number : 1 800 262 1852
- 3) Visit our web site <u>www.Linon.com</u> to order spare parts and for care instructions on your newly purchased furniture.