
UNDERCOUNTER DISHWASHER

MODELS:

66514749N510 (Black)
66514742N510 (White)
66514743N510 (Stainless)

© 2015 Sears Brands, LLC
Part No. W10801476 Rev. A


DOOR PANEL PARTS



DOOR PANEL PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W10747788	Installation Instructions
	W10772269	Energy Guide
	W10772237	Use & Care Guide
	W10751166	Tech Sheet, English
	W10751168	Tech Sheet, French
2		Arm, Hinge
	8534854	Left Hand
	8534853	Right Hand
3	W10735304	Insulation, Four Layer
4		Front Panel (Includes Items 7 & 12)
	W10481038	Black
	W10481039	White
	W10481041	Stainless
5		Panel, Access
	W10195777	Black
	W10195778	White
6	W10463662	Spacer, Control Bracket
7		Panel Pocket, Handle
	W10195243	Black
	W10195318	White
	W10563340	Silver
8		Screw
	302868	Black
	3400836	White
9	304392	Screw
10	3400071	Screw
11	W10073520	Insulation, Door
12		Nameplate
	W10403223	Black
	W10403222	White
	W10403224	Stainless
13	W10641745	Bracket, Control
14		Toe Panel
	W10737729	Black
	W10751505	White
15	8269016	Clip, Ground
16	W10321448	Barrier, Vapor


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

Illus. No.	Part No.	Description
1		Console Assembly
	W10732048	Black
	W10732049	White
	W10732050	Stainless
2	W10653840	Latch Assembly (Includes Switch)
3	W10756253	Box, Connector
4	W10194937	Brace, Connector
5	W10348408	Screw
6	W10669965	Control, Electronic
7	W10195237	Clip, Control
8	W10528492	Jumper, 4 Wire
9	W10194912	Handle Pocket


INNER DOOR PARTS



INNER DOOR PARTS

Illus. No.	Part No.	Description
1	W10348409	Screw
2	8281217	Screw
3	W10712597	Inner Door
4	W10667473	Seal, Door Bottom
5	W10620297	Dispenser Assembly
6	W10718986	Wiring Harness
7	W10195007	Seal, Console/Door


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

Illus. No.	Part No.	Description
1	W10195037	Lever, Overfill Switch
2	8531412	Hose
3	W10584470	Inlet, Water (Also Order Item 4)
4	8531323	Gasket
5	W10213825	Nut, Water Inlet (Also Order Item 4)
6	371505	Clamp, Hose
7	W10327249	Fill Valve Assembly
8	304231	Screw
9	W10195039	Switch, Overfill Control
10	W10647205	Housing, Overfill (Also Order Item 11)
11	8531743	Gasket, Flat
12	W10195038	Nut, Standpipe
13	W10195036	Float & Retainer Assembly
14	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
15	370445	Clamp, Hose
16	W10545278	Drain Loop with Check Valve Asembly
17	W10772907	Vent Hose
18	W10653312	Outlet, Air Assembly
19	W10653310	Seal, Rubber
20	W10653319	Nut, Air Assembly
21	W10673168	Blower Assembly
22	W10653323	Nozzle, Airduct
23	W10770367	Tube, Exhaust
24	W10653320	Clip, Retainer


TUB AND FRAME PARTS



TUB AND FRAME PARTS

Illus. No.	Part No.	Description
1	W10681498	Tub Assembly
2	W10078083	Wheel And Mount Assembly
3	W10179427	Seal, Cabinet
4	W10623354	Plug, Tub
5	W10696509	Heater Element Assembly (Includes Heater Washer & Nut)
6	W10300924	Gasket, Tub
7	W10292870	Shield, Thermostat
8	W10084086	Door Balance Assembly
9	8269145	Bracket, Undercounter
10	3367670	Screw
11	3400074	Screw
12	W10348411	Screw
13	W10190778	Wheel Leg
14	W10619352	Leveler, Leg
15	3400014	Screw, Grounding
16	8270020	Spring, Door Balance
17	3378128	Washer, Pronged Cup
18	3400892	Screw
19	W10653292	Cover, Terminal Box
20	W10158291	Cable, Door
21	W10681564	Support Assembly, Rear
22	W10544004	Strike, Latch
23	W10300703	Bracket, Thermostat
24	W10195091	Thermostat
25	9743002	Gasket, Mounting Bracket
26	8573240	Shield, Tub Sound
27	W10713315	Assembly, Terminal Box
28		Spacer, Tub/Brace
	W10195630	Left Hand
	W10195631	Right Hand


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

Illus. No.	Part No.	Description
1	W10455272	Cover, Outlet
2	W10605058	Sump & Motor Assembly
3	W10195643	Sump With Seal (Also Order Items 14 & 19)
4	W10348407	Screw
5	W10769129	Sprayarm, Lower
6	W10372113	Tab, Sump
7	W10693534	Filter Cup Assembly
8	W10348269	Pump, Drain
9	8269144	Hose, Drain
10	W10476222	Motor, Diverter
11	370445	Clamp, Hose
12	W10476221	Disc, Diverter
13	W10723295	Indicator, Optical Wash
14	W10538166	Grommet
15	W10169167	Clamp, Hose
16	W10195086	Motor, Isolator
17	W10529163	Motor (Also Order Items 14 & 19)
18	9741232	Screw
19	W10445975	Hose Assembly (Includes 2 Clamps)
20	W10195360	Screen
21	W10300776	Damper, Sump Assembly


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

Illus. No.	Part No.	Description
1	W10340745	Feed Tube Assembly (Includes Items 2 & 3)
2	W10327455	Sprayarm, Third Level
3	3400918	Retainer
4	W10340542	Manifold
5	W10376692	Sprayarm, Upper
6	W10462375	Manifold, Turbozone
7	W10195690	Bracket, Feed Tube


UPPER RACK AND TRACK PARTS




UPPER RACK AND TRACK PARTS

Illus. No.	Part No.	Description
1	W10462394	Dishrack, Upper
2	W10380200	Handle, Dishrack Front (Includes Nameplate)
3	W10462400	Handle, Dishrack Rear
4	W10082821	Tine Row
5	W10082853	Clip, Pivot
6	W10077840	Positioner, Dual
7	8565925	Stop, Track (Non-Removable)
8	3385089	Track, Dishrack
9	W10195840	Positioner, Adjuster
10	W10350375	Adjuster, Arm Assembly
11		Adjuster, Housing Assembly
	W10195372	Left Hand
	W10195373	Right Hand
12	W10250162	Cover, Adjuster
13	W10195839	Strap, Tether Adjuster
14	W10082861	Stop, Track (Removable)
15	W10158385	Clip, Stemware
16	W10250160	Clip, Adjuster
17	W10752617	Clip, Dispenser Guard
18	W10309090	Screw

LOWER RACK PARTS





LOWER RACK PARTS

Illus. No.	Part No.	Description
1	W10525645	Dishrack, Lower
2	W10195417	Wheel & Transport Assembly
3	W10756125	Silverware Basket
4	W10082852	Lid, Center
5	W10082907	Tine Row, Fold Down
6	W10107150	Retainer, Tine Row (Combo)
7	W10756122	Basket, Silverware Side

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

Illus. No.	Part No.	Description
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.
		Handle Assembly
	W10702080	Black
	W10702081	White

PAINT, TOUCH-UP (1/2OZ.)

Illus. No.	Part No.	Description
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus. No.	Part No.	Description
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

Illus. No.	Part No.	Description
	799344	White (Uncut)
	4392900	Biscuit/Bisque

POWER CORD KIT

Illus. No.	Part No.	Description
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

Illus. No.	Part No.	Description
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

Illus. No.	Part No.	Description
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis