

# Kenmore**smart**

**connect now.**  
for smarter living.




quick start guide  
**SMART WASHER** or **DRYER**



MFL67731052

# it all happens in the app





## customize your clean

Download new wash and dry cycles



## alerts you when it's done

Check washer or dryer status and get alerts when loads finish.



## wash around your schedule

Start a load from your phone or preset a start/end time.



## make maintenance easy

Track usage and receive maintenance alerts.



Visit [Kenmore.com/smart](http://Kenmore.com/smart) for additional details.

# discover new cycles now available in the app


## wash cycles

Small Load (Default)  
Color Care  
Beachwear  
New Clothes  
Denim  
Sportswear  
Baby Wear  
Swimwear  
Rainy Day  
Gym Clothes  
Blankets  
Sweat Stains  
Single Garments  
Clean Washer

## dry cycles

Super Dry  
Denim  
Kids' Clothes  
Small Load (Default)  
Ultra Delicate  
Freshen up  
Gym Clothes  
Blankets  
Blanket Refresh  
Rainy Day  
Deodorization  
Lingerie  
Socks  
Overnight Dry  
Bedding/Curtains  
Kids' Gym Clothes

download the FREE Kenmore Smart™ app now



Apple, the Apple logo and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries.  
App Store is a service mark of Apple Inc. Google Play and Android are trademarks of Google Inc.  
Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

To **get started**,  
all you need is your  
Kenmore Elite<sup>®</sup> Smart Washer or Dryer,  
a router with working internet connection and  
a smartphone.

**It's easy!**

• • • •

## 1 prepare to connect.

1. Washer or dryer is installed. ✓
2. Washer or dryer is powered. ✓
3. Home Wi-Fi® is working. ✓
4. You have your Wi-Fi® password. ✓
5. Smartphone Bluetooth® is turned on. ✓

## 2 download the app.



Download the free Kenmore Smart™ app to your smartphone.



Wi-Fi is a registered trademark of Wi-Fi Alliance Corporation.



Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

Apple, the Apple logo and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Google Play is a trademark of Google Inc.

### 3 connect now.

1. Launch the app on your smartphone.
2. Set up an account or log into your existing account.
3. Click to add a product.
4. Select Front Load Washer or Dryer from the available products in the menu.
5. Follow the additional instructions within the app to connect your smart washer or dryer.
6. You will need the QR codes at the following locations to complete the registration and connection process.



Enjoy your new Kenmore Elite® Smart laundry appliance  
and all the smart benefits.

Kenmore®  
*Be Amazing*™