



WELCOME.

LG Dryer Quick-Start Guide



NEED HELP? Call an LG Support Representative at 800.243.0000 or visit lg.com for online support.




This guide shows you how to quickly download the free LG SmartThinQ® app to your Android or iOS device and connect your LG Dryer

Now, you can control key LG Dryer features from your smartphone!




REMOTE START AND STOP

Start the laundry while you're out shopping so it's done when you return.



KEEP WRINKLES AT BAY

Monitor the remaining cycle time from your smartphone.



REDUCE TIME BETWEEN LOADS

Get automatic smartphone alerts the moment clothes are dry.



DOWNLOAD THE SMARTTHINQ® APP

01

DOWNLOAD

Download the SmartThinQ® app from [Google Play](#) or the [Apple Store](#).



02

START

Launch the SmartThinQ® app and press **start**. Press **create account** and follow the on-screen instructions. Enter your account information and verify your e-mail.



SELECT YOUR PRODUCT

03


SIGN IN

Click **agree** to accept Terms of Use. Press **sign in** and enter your e-mail ID and password.

04

SELECT

Tap on the **+** at the top of the screen to register your product. **Select Dryer** from the menu.






CONNECT YOUR PRODUCT

05 (ANDROID)


CONNECT PRODUCT & WI-FI

Connect SmartThinQ® to the LG Network by following the on-screen prompts below.

1. After selecting Dryer, follow the on-screen prompts to verify your appliance type. **Note: Certain prompts only apply to select dryers.**




3. On the next screen, select the name of your wi-fi network, enter a valid password and press **connect**. **Please note: Only a 2.4 Ghz wi-fi connection is supported.**



2. Once finished with appliance type verification, **press and hold** the **Wi-Fi** button on the Dryer for **3 seconds** until the wi-fi LED light starts to blink.



4. It may take up to 2 minutes to connect to your selected wi-fi network and completely register your Dryer. Once finished, your product will be listed on the main dashboard.






CONNECT YOUR PRODUCT

05 (iOS)


CONNECT PRODUCT & WI-FI

Connect SmartThinQ® to the LG Network by following the on-screen prompts below.

1. After selecting Dryer, follow the on-screen prompts to verify your appliance type. **Note: Certain prompts only apply to select dryers.**




3. Return to the SmartThinQ® app and press the ">" button. On the next screen, press **verify connection**. Select the name of your wi-fi network to connect. **Please note: Only a 2.4 Ghz wi-fi connection is supported.**




2. Once finished with appliance type verification, **press and hold the Wi-Fi button on the Dryer for 3 seconds** until the wi-fi LED light starts to blink. Press the ">" button to continue.

On your phone, go to settings and press **Wi-Fi**. On the list of options, select **LG_Smart_Dryer**. **Note: If prompted for a password, enter the last 4 digits twice from the wi-fi name.**



4. Enter the password for the wi-fi network you have chosen and press **connect**. It may take up to 1 minute to completely register your Dryer. Once finished, your product will be listed on the main dashboard.





CONNECT YOUR SMART SPEAKER




06 (GOOGLE HOME)


CONNECT

Connect your Dryer and enable use with Google Home by following the steps below.


1. Open the Google Home app on your smartphone. Go to the menu and press **explore**. Search **LG SmartThinQ** and press **control home electronics** after searching has completed.



3. Select **LG SmartThinQ** from the available menu. Sign in to your LG SmartThinQ® account and then press **done** in the upper right corner. You are now connected!



2. Press **set up** from the next screen. From the Home Control screen, press the menu in the upper corner and select **manage accounts**.



07

COMMAND

Talk to your Google Home and say: **“Hey Google, talk to LG.”** The Google Home will then say: **“Welcome to LG. How can I help you?”** Once connected, try these sample commands with your Google Home. Enjoy!



“Hey Google, start the dryer.”

“Hey Google, how much time is left on the dryer cycle?”



CONNECT YOUR SMART SPEAKER




06 (ALEXA)

CONNECT

Connect your Dryer and enable use with Alexa by following the steps below.

1. Open the Alexa app on your smartphone. Go to the menu and press **skills**. Search **LG SmartThinQ** and press **LG SmartThinQ – Complete (Smart Appliance and TV)** after searching has completed.



07

COMMAND


Talk to Alexa and say: **“Alexa, talk to LG.”** Alexa will then say: **“Welcome to LG. How can I help you?”** Once connected, tell Alexa a command for your product. Enjoy!



“Alexa, ask LG to start the dryer.”

“Alexa, ask LG to tell me the remaining time of dryer.”

2. Press **enable** from the next screen. Sign in to your LG SmartThinQ® account. You are now connected!





REGISTER YOUR PRODUCT

08


FOR PRIORITY SERVICE

Thank you for purchasing an LG product. We hope you're enjoying it! Now it's important to register your product—a quick, simple process with many benefits:

- Verification of Ownership
- More Efficient Warranty Service
- Access to Exclusive Information on New Products, Offers and Promotions

Register Easily with Your Phone

- 1 Take a photo of the camera icon below
- 2 Text the photo to 77228



NEED HELP?

Visit photoregister.com/help or text HELP to 77228.

- > Or visit us online at www.lgusa.com/register



Your new investment only has a 1 year limited warranty. An LG Premium Care* plan can keep it protected for 1-3 years after the manufacturer's warranty expires. It's simple, call or go online today!

Call or Go Online for a Free Quote

- > Call: 1.866.618.5775
- > Visit: www.lg.yourserviceplan.com