



WELCOME.


LG Washer Quick-Start Guide








This guide shows you how to quickly download the free LG SmartThinQ® app to your Android or iOS device and connect your LG Washer

Now, you can control key LG Washer features from your smartphone!











DOWNLOAD THE SMARTTHINQ® APP

<u>01</u>

DOWNLOAD

Download the SmartThinQ® app from Google Play or the Apple Store.





<u>02</u>

START

Launch the SmartThinQ® app and press start. Press create account and follow the on-screen instructions. Enter your account information and verify your e-mail.



SELECT YOUR PRODUCT

<u>03</u>


SIGN IN

Click agree to accept Terms of Use. Press sign in and enter your e-mail ID and password.

<u>04</u>

SELECT

Tap on the "+" at the top of the screen to register your product. Select your type of Washer from the menu.



05 (ANDROID)

CONNECT PRODUCT & WI-FI

Connect SmartThinQ® to the LG Network by following the on-screen prompts below.

1. After selecting your type of Washer, follow the on-screen prompts to verify your appliance type. Note: Certain prompts only apply to select washers.





3. On the next screen, select the name of your wi-fi network, enter a valid password and press connect. Please note: Only a 2.4 Ghz wi-fi connection is supported.





2. Once finished with appliance type verification, press and hold the Wi-Fi button on the Washer for 3 seconds until the wi-fi LED light starts to blink.





4. It may take up to 2 minutes to connect to your selected wi-fi network and completely register your Washer. Once finished, your product will be listed on the main dashboard.





05 (ios)

CONNECT PRODUCT & WI-FI

Connect SmartThinQ® to the LG Network by following the on-screen prompts below.

1. After selecting your type of Washer, follow the on-screen prompts to verify your appliance type. Note: Certain prompts only apply to select washers.







3. Return to the SmartThinQ* app and press the ">" button. On the next screen, press verify connection. Select the name of your wi-fi network to connect. Please note: Only a 2.4 Ghz wi-fi connection is supported.







2. Once finished with appliance type verification, press and hold the Wi-Fi button on the Washer for 3 seconds until the wi-fi LED light starts to blink. Press the ">" to continue.

On your phone, go to settings and press Wi-Fi. On the list of options, select LG_Smart_Laundry. Note: If prompted for a password, enter the last 4 digits twice from the wi-fi name.







4. Enter the password for the wi-fi network you have chosen and press connect. It may take up to 1 minute to completely register your Washer. Once finished, your product will be listed on the main dashboard.






CONNECT YOUR SMART SPEAKER

06 (GOOGLE HOME)

CONNECT

Connect your Washer and enable use with Google Home by following the steps below.

 Open the Google Home app on your smartphone. Go to the menu and press explore. Search LG SmartThinQ and press control home electronics after searching has completed.





3. Select LG SmartThinQ from the available menu. Sign in to your LG SmartThinQ® account and then press done in the upper right corner. You are now connected!





2. Press set up from the next screen. From the Home Control screen, press the menu in the upper corner and select manage accounts.





<u>07</u>

COMMAND

Talk to your Google Home and say: "Hey Google, talk to LG." The Google Home will then say: "Welcome to LG. How can I help you?" Once connected, try these sample commands with your Google Home. Enjoy!





CONNECT YOUR SMART SPEAKER




06 (ALEXA)

CONNECT


Connect your LG Washer and enable use with Alexa by following the steps below.

 Open the Alexa app on your smartphone. Go to the menu and press skills. Search LG SmartThinQ and press LG SmartThinQ – Complete (Smart Appliance and TV) after searching has completed.





2. Press enable from the next screen. Sign in to your LG SmartThinQ® account. You are now connected!





<u>07</u>

COMMAND

Talk to Alexa and say: "Alexa, talk to LG." Alexa will then say: "Welcome to LG. How can I help you?" Once connected, tell Alexa a command for your product. Enjoy!



"Alexa, ask LG to start the washer."

"Alexa, ask LG to check the remaining time of the washer."



08

FOR PRIORITY SERVICE

Thank you for purchasing an LG product. We hope you're enjoying it! Now it's important to register your product—a quick, simple process with many benefits:

- · Verification of Ownership
- More Efficient Warranty Service
- Access to Exclusive Information on New Products, Offers and Promotions

Register Easily with Your Phone


- 1) Take a photo of the camera icon below
- 2 Text the photo to 77228



NEED HELP?

Visit photoregister.com/help or text HELP to 77228.

Or visit us online at www.lgusa.com/register





Your new investment only has a 1 year limited warranty. An LG Premium Care* plan can keep it protected for 1-3 years after the manufacturer's warranty expires. It's simple, call or go online today!

Call or Go Online for a Free Quote



>> Visit: www.lg.yourserviceplan.com

©2018 LG Electronics U.S.A., Inc., Englewood Cliffs, N.J. All rights reserved. "LG Life's Good" is a registered trademark of LG Corp. All other trademarks are the property of their respective owners. *LG Premium Care plans are offered, sold and issued by Service Net Warranty, LLC, P.O. Box 928, Jeffersonville, Ind. 47131. Limitations and exclusions apply. Visit https://lgyourserviceplan.com/Vendors/LG/TandCs/TermsAndConditions.pdf to review complete terms and conditions. LG is not affiliated with Service Net Warranty, LLC, or any of their affiliates.