

F.BLÜMLEIN


JU-2500 Steam Oven Quick Start Guide

For any additional information and safety precautions, refer to the user manual or contact us:

☎ (323) 438-3334

✉ support@fblumlein.com

⌘ Control Panel



⌘ Before First Use

When using the oven for the first time, **remove all the objects including the tapes on the lower heating element**, and run it for 20-30 minutes. You may notice smoke or a burning smell when using the appliance for the first time. This is normal and not a sign that it is a defective unit.

⌘ How to Start Cooking

1. Press and hold the power button for 3 seconds to power on, and fill the tank with water.
2. Choosing a cooking mode from the list above.
3. Adjust the temperature using the (+) / (-) buttons, then press (M) to move onto the hour selection. Repeat again to set the minutes.
4. Press (▶) to begin cooking.

⌘ Cleaning the Oven

Please clean the oven after each use, or it may lead to permanent aesthetic or functional damage. Do not use harsh cleaners, abrasives or scouring pads as it may damage the surface of the oven cavity or display panel.

1. Once the oven has cooled down and is cool to touch, wipe the oven walls and bottom with a soft cloth. Use a mild detergent (e.g. baking soda) if needed.
2. Use the Bake mode to dry any remaining water if needed.