











<div data-bbox="29 20 74 51">A</div> 	<div data-bbox="458 20 503 51">B</div> 	<div data-bbox="841 20 886 51">C</div> 	<div data-bbox="1399 20 1444 51">D</div> 	<div data-bbox="1788 20 1833 51">E</div> 	<div data-bbox="2145 20 2190 51">F</div>  <div data-bbox="2351 341 2411 383">X2</div>	<div data-bbox="2453 20 2498 51">G</div>  <div data-bbox="2621 341 2681 383">X4</div>	<div data-bbox="2735 20 2780 51">H</div> 
Chair base	Backest	Left and right armrest	Power cord	Remote control	Part1	Part2	Power


STEP1




STEP2



How to recline?



How to get footrest latch down and stand?



Massage Recliner Assembly Instruction

STEP3

No.1 and No.2 wires from the backrest and chair base with same color connect together.

No.3 wire from the back connects to the wire at the bottom of the sofa.

The USB socket in the bottom of the sofa armrest.

