

User Guide

SoundMagic™ boom



BC235D

Content

Caution

Accessories

Main Features and Specifications

Main Keys

LED Light Indicators

Power On/Off

Charging

Audio Input Operation

Bluetooth Receiver Function

Bluetooth Operation

Trouble Shooting

Contact Information

Thank you for choosing this beautiful, but powerful Bluetooth speaker, Latte SoundMagic™ boom. The SoundMagic™ boom is a portable Bluetooth speaker, which can be connected to your smart phone or any Bluetooth enabled device via the latest Bluetooth Technology and play music wirelessly.

Equipped with 2 powerful speakers, SoundMagic™ boom will deliver deep and powerful, but balanced sound with Latte's digital signal processing technology. It is small enough to carry around and powerful enough to impress your friends at parties.

Thank you again for purchasing SoundMagic™ boom. We sincerely hope you will enjoy SoundMagic™ boom anywhere you go.

Please read the manual carefully before use.

⚠ **Caution**

- Do not use the product in extremely hot, cold, dusty or damp environments.
- The product contains a lithium battery and should be kept away from fire or extremely high temperature environments to avoid explosion.
- Do not disassemble, repair, or modify the product arbitrarily. These actions will void the manufacturer's standard warranty.
- Please charge the unit fully before you start using the product for the first time.
- If the product has not been in use for an extended time, please make sure you charge the unit fully before you start using it again.
- The product specifications and design may be changed without prior notice.


1. Accessories

- Bluetooth speaker ×1
- User Guide ×1
- Micro USB charge cable ×1
- AUX line-in Cable (3.5mm Jack) ×1


2. Main features and Specifications

- Music Play via Bluetooth V3.0+EDR
- Handsfree Function (Built-in Microphone)
- Φ 3.5mm Audio Input Interface
- RMS Output Power: 2 X 2W
- Speaker: 2 X 38mm/4 Ω /3W
- Frequency Response: 100Hz-20kHz
- Supported Profiles: A2DP, AVRCP, GAVDP, AVDTP
- Run Time : 8+ hours at 60% volume
- Built-in 600mAh rechargeable Lithium battery
- Power Source: Via Micro USB Cable. DC 5V Micro USB Power Adapter (sold separate)
- Charging Time : Approx. 3 hours
- Dimensions: 6 X 2.12 X 2.2 (in)
- Weight: Approx. 0.55lb

3. Main Keys



- 1: Microphone
- 2: Press ◀️ shortly to select the previous song. Press and hold ◀️ to lower the volume.
- 3: In the Bluetooth search mode, press and hold ▶️/⏸️ for about 3 seconds to enter the pairing mode. In the music play mode, press ▶️/⏸️ shortly to pause and play music. When there is an incoming call, press ▶️/⏸️ shortly to answer the call. During the call, press ▶️/⏸️ shortly to end the call
- 4: Press ▶️ shortly to select the next song. Press and hold ▶️ to increase the volume.



- 1: LINE OUT: Connect to external speaker
- 2: AUX IN: Connect to external audio player (3.5mm)
- 3: LED light for charging indication
- 4: Micro USB jack for charging
- 5: Power Switch

4. LED Light Indicator

- **Front LED (Blue):** Power on and Bluetooth not connected. The blue light will flash.
- **Front LED (Blue):** Power on and Bluetooth connected. The blue light will be on.
- **Front LED (Red):** The Aux line-in cable connected. The red light will be on
- **Back LED (Red):** The red light will be on when the speaker is being charged. The red light will be off when the speaker is charged fully.

5. Power On/Off

- **Power On:** Slide the power switch located on the back of the speaker to "On" position.
- **Power Off:** Slide the power switch located on the back of the speaker to "Off" position.

6. Charging

Plug one end of the Micro USB charging cable to the computer and the other end to the Micro USB DC 5V jack of the speaker (4) to charge the speaker. When the speaker is being charged, the red light is on. The red light will turn off when the speaker is fully charged.

NOTE:

When you charge the speaker while you are playing music, the sound might not be stable because the current consumption during charging is high. If that happens, please charge the speaker fully first and then start playing music again.




7. Audio Input Operation

When the speaker is on, please insert the AUX line-in (3.5mm) to the speaker and into the Audio player. Once connected, the front LED indicator light will change from blue to red.

8. Bluetooth Receiver Function

If you have an extra speaker without Bluetooth capability, but want to use it wirelessly, SoundMagic boom will serve as a bluetooth Receiver. Simply connect SoundMagic boom to your speaker via Line Out located on the back of the speaker. Music will start playing from another speaker, not from your SoundMagic boom.

9. Bluetooth Operation

- Slide the power switch on the back of speaker to "ON" position. The blue light will turn on and flash.
- Go to "Setting" on your cell phone or Bluetooth enabled device and activate the "Bluetooth" function. Scan for available Bluetooth devices nearby.
- When "**SoundMagic boom**" appears on the available Bluetooth device list, select "**SoundMagic boom**" to establish connection (if asked for a passcode, enter "0000"). When the connection is successfully established, it produces a connection tone, and the blue light will be on without flashing.
- During the music play, the music play will stop when you receive a call. You can do one of the following.
 - **Answer the call:** Press  key shortly to answer the call
 - **End the call:** Press  key shortly to end the call. The music will resume automatically
 - **Reject the call:** Press  key for about 3 seconds to reject the call

Note:

- When the number of the previously paired devices with the speaker exceeds the maximum capacity (4 units), the speaker will automatically clear the first device paired in its memory.
- When the speaker is currently connected to a Bluetooth device and you want to pair a different Bluetooth device, please disconnect the currently paired device before you attempt to pair a new device.

10. Troubleshooting

Issue	Solutions
Bluetooth pairing cannot be established	<ol style="list-style-type: none">1. Low battery. Please charge the product fully before you start using the speaker again2. Please check if other phone or Bluetooth device is already paired and connected to the speaker. The speaker can only be connected to one Bluetooth device at a time. In this case, please disconnected the currently connected device and pair the device you are trying to connect again.3. Move the speaker closer to your phone or Bluetooth device4. Please check if your phone is connected to "SoundMagic boom" in your phone's Bluetooth setting.
Power is on, but the blue light is off. Cannot pair.	The speaker has entered the sleeping mode due to prolonged non-operation. Press and hold the pairing key on speaker to wake it up.
The sound from the speaker is too low or has no sound.	<ol style="list-style-type: none">1. When your phone is connected to the speaker, the Bluetooth volume of your phone is not turned up enough or muted. Please turn up the Bluetooth volume of your phone.2. The output volume of your phone is too low. Please try to test it with different Bluetooth device to check if the issue is with the speaker or the Bluetooth device
The Bluetooth connection range is too short	Please check if there are any obstacles between your Bluetooth device and the speaker.
Music plays normally, but with interrupted sound	<ol style="list-style-type: none">1. Please check if there are any obstacles between your Bluetooth device and the speaker.2. Check if the distance between your Bluetooth device and the speaker exceeds the connection range (33ft). Please shorten the distance between your Bluetooth device and the speaker.3. Low battery. Please charge the product fully before you start using the speaker again4. Please lower the volume a little bit.
Bluetooth cannot connect to other Bluetooth devices	If the speaker is currently paired with one Bluetooth device, you cannot pair other Bluetooth devices. To pair another device, disable the current connection and try to pair the new connection with a different Bluetooth device..

Note: If the problem still cannot be solved, please contact technical support or our customer service.

◁ Contact Information

- **Technical Support:**

Telephone: 408-946-8789 (M-F, 9 A.M - 5 P.M PST)

Email: support@latteglobal.com

Online: support.lattezone.com

Facebook Support: www.facebook.com/lattestyle

- **RMA inquiry:**

RMA@latteglobal.com or visit support.lattezone.com

- **Genuine Accessories Purchase:**

Please visit www.lattezone.com

- **Facebook:** www.facebook.com/lattestyle

- **Twitter:** www.twitter.com/lattestyle

- **Address:**

Latte Communications Inc.

1622 Centre Pointe Dr

Milpitas CA 95035

