






Assembly Instruction



- 1**  F-screw 6x30-T30, GS x 8 PCS
SEM201424
- 2**  F-screw 6x40-T30, GS x 6 PCS
SEM201425
- 3**  Washer 31x60x3, GS x 2 PCS
SEM201048
- 4**  Wheel cap w/ hole, SB x 2 PCS
SEM201214
- 5**  Wooden part wheel Ø21x2cm, TEA x 2 PCS
+ Rubber ring wheel Ø21x2cm, R (black) x 2 PCS
SEM201538 + SEM201539
- 6**  Torx key T30, GS x 1 PCS
SEM201430

WINDU CHAISE LOUNGE, W/ TRAY, TEA
SEM102925