




ASSEMBLY INSTRUCTION

DE - MONTAGEANWEISUNG
FR - INSTRUCTIONS DE MONTAGE
DK - MONTAGEVEJLEDNING
CZ - NÁVOD K MONTÁŽI
ES - INSTRUCCIONES DE MONTAJE
FI - ASENNUSOHJE



HR - UPUTE ZA MONTAŽU
SE - MONTERINGSANVISNING
SI - NAVODILA ZA MONTAŽO
TR - MONTAJ TALIMATI
NO - MONTASJEANVISNING
IT - ISTRUZIONI DI MONTAGGIO



GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
NL - MONTAGE INSTRUCTIE
PT - INSTRUÇÕES DE MONTAGEM
PL - INSTRUKCJA MONTAŻU
HU - SZERELÉSI UTASÍTÁS




 x 8 HW-ST-01-078 (7 x 120)	 x 2 HW-ST-01-046 (7 x 90)	 x 3 HW-ST-01-043 (7 x 65)	 x 4 HW-ST-01-040 (7 x 50)	 x 4 HW-WD-17-011 (10x40)	 x 1 HW-ST-18-001 (4 x 98)
--------------------------------------	-------------------------------------	-------------------------------------	-------------------------------------	------------------------------------	-------------------------------------

 x 1 SU-TB-AS-0250	 x 2 SU-TB-LF-0844	 x 2 C-W-TB-SU-0216	 x 1 C-W-TB-FP-0059	 x 1 C-W-TB-SU-0218
--------------------------	--------------------------	---------------------------	---------------------------	---------------------------







4/4

