

USE & CARE GUIDE

Nichols 5pc Mixed Media Seating w/pull out Ottomans

Product Code: 06526058-0

UPC Code: 8-48681-03017-2

Date of Purchase: ____ / ____ / ____

Thank you for your purchase

Thank you for your purchase!

We are pleased that you have chosen Sears for your outdoor furniture purchase. We hope that you enjoy the unmatched quality, comfort, and style of your new patio set. Every piece is meticulously considered all the way down to the smallest details, exclusively for you, by our world class design team. We know you have a choice when it comes to your patio furniture needs, so from our team to yours, thank you for letting us be a part of your outdoors.

Table of Contents

Table of Contents	2
Safety information	3
Furniture Set Up	3
Examine Your Furniture	3
Warranty	3
What is Covered	3
What is Not Covered.....	3
Care and Maintenance	4
Pre- Assembly	5
Planning Assembly	5
Hardware Included	5
Weight Limit	5
Package Contents	6
Assembly Instruction	7
Chair	7
Side Table.....	10
Customer Service	13

Safety Information

Furniture Set Up

- Ensure that all parts are assembled properly and fully tightened as per the instructions.
- When placing in the desired location, ensure that all legs are resting on the same surface. You may adjust the legs levelers as required to ensure that the item stands in a rigid position.

Examine Your Furniture

- Examine occasionally to ensure that there are no loose parts. If loose parts are found, they must be retightened fully before additional use.

Warranty

1 YEAR WARRANTY FOR FRAME, RESIN WICKER AND CUSHION

WHAT IS COVERED

We warrant to the original purchaser for one year, from the date of purchase, that the frame resin wicker and cushion will be free from manufacturing defects. This warrant also covers peeling, crackling, blistering, discoloration, or fading for this one year period.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, acts of nature, fire, freezing, and abusive use. Discoloration or fading of the finish or fabrics as a result of chemicals or spills is not covered. Glass tabletop breakage and corrosion or rusting of hardware are not covered. In addition, purchased parts are not covered under this warranty. Proof of purchase (dated register receipt) is required for warranty claims. We reserve the right to make substitutions with similar merchandise, if the model is no longer in production. Warranty is to the original purchaser and is not transferable. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

WARRANTY

This limited warranty is extended to the original purchaser and applies to defects in material and workmanship of your Patio furniture, provided your furniture is maintained with care and used only for personal, residential purposes.

Warranty

Cushions are covered for a period of one (1) year against defects in material or workmanship.

Frames are warranted to be free from defects in material or workmanship for a period of one (1) year.

Exclusions: items used for commercial, contract, or other non- residential purposes, or items damaged due to acts of Nature, vandalism, misuse, or improper assembly is not covered. Discoloration and fading of the finish or fabrics as a result of chemicals or spills are not covered. Glass table top breakage and corrosion or rusting of hardware is not covered. If, within the stated warranty period, this product is found to be defective in material or workmanship, the Purchaser must contact the customer service department at 1-866-905-4107. The manufacturer, at its option, will repair Or replace the defective part(s). Proof of purchase (date register receipt) is required for warranty claims. It remains The customer's responsibility to pay for freight and packing charges to and from the service center. Warranty is to The Original Purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

Care Instructions: Protecting your furniture from the elements when not in use is highly recommended. Wipe frame with a lightly damp cloth and dry completely. Customer service 1-866-905-4107

Care and Maintenance

- ☐ Wipe the frame lightly with a mild solution of soap and water, rinse with clean water, and dry thoroughly.
- ☐ Cushions may also be cleaned by hand with a mild solution of soap and water. Rinse the cushion cover thoroughly and allow to drip dry. The back cushion should be spot cleaned with a soft cloth. Do not machine wash or tumble dry, as cushions may shrink. Do not use bleach or solvents on fabrics. Never use cleaners that contain acid or abrasive materials.
- ☐ Use and operation: To improve the lifespan of this furniture cover when not in use and store in a cool dry place during the off season.

Pre-Assembly

PLANING ASSEMBLY

To prevent damage, place all parts on a soft surface during assembly. Remove all protective caps before beginning assembly. It takes about 90 minutes for two person to complete all the assembly.

WEIGHT LIMIT

The recommended weight limit for the following products are listed below:

- ☐ Chair: 200 lbs
- ☐ Ottomans: 200 lbs
- ☐ Side Table: 50 lbs



CAUTION: Furniture overload may cause injuries.


HARDWARE INCLUDED

CHAIR:



Part	Description	Size	QTY.
AA	SCREW-1	(M6x18mm)	4
BB	SCREW-2	(M6x28mm)	8
CC	SCREW-3	(M6x40mm)	8
DD	WASHER	M6	20
EE	HEX WRENCH		1





SIDE TABLE:



Part	Description	Size	QTY.
AA	SCREW	(M6x15mm)	8
BB	WASHER	M6	8
CC	HEX WRENCH		1

Pre-Assembly (continued)


Package Contents



PART	DESCRIPTION	QUANTITY
A	BACKREST	1
B	SEAT	1
C	LEFT ARM	1
D	RIGHT ARM	1



Safety Information







1. EVERY SCREW NEEDS TO BE USED WITH A WASHER.
2. DO NOT FULLY TIGHTEN SCREWS UNTIL INDICATED IN STEP 3.

Assembly Instruction

1 Connecting the seat to the backrest




- CONNECT THE SEAT "B" TO THE BACKREST "A" USING SCREW-2 "BB" AND WASHER "DD". LOOSELY TIGHTEN ALL SCREWS USING THE HEX WRENCH "EE".



Assembly Instruction (continued)

2 Attaching the left arm to the backrest and the seat

- ATTACH THE LEFT ARM "C" TO THE BACKREST "A" USING SCREW-3 "CC" AND WASHER "DD".
- ATTACH THE LEFT ARM "C" TO THE SEAT "B" USING SCREW-1 "AA", SCREW "BB"-2 AND WASHER "DD"
- LOOSELY TIGHTEN ALL SCREWS USING THE HEX WRENCH "EE".
- REPEAT STEPS 1 AND 2 FOR THE RIGHT ARM "D".






Assembly Instruction (continued)

3 Tightening all the screws

- ONCE ALL THE SCREWS ARE IN PLACE. FULLY TIGHTEN ALL SCREWS. AND TURN THE CHAIR RIGHT SIDE UP AND ENSURE THAT ALL CONNECTIONS ARE SECURED BEFORE USE.
- PLACE CUSHIONS ON CHAIR.




X1



Pre-Assembly


Package Contents



PART	DESCRIPTION	QUANTITY
A	TABLE TOP	1
B	TABLE LEG	4
C	CENTRE RING	1



Safety Information







1. EVERY SCREW NEEDS TO BE USED WITH A WASHER.
2. DO NOT FULLY TIGHTEN SCREWS UNTIL INDICATED IN STEP 2.

Assembly Instruction

1 Inserting the four legs to the table top and center ring





- INSERT THE FOUR TABLE LEGS “B” TO THE TABLE TOP “A”.
- ATTACH THE FOUR TABLE LEGS “B” TO THE CENTER RING “C” USING SCREW “AA” AND WASHER “BB”. LOOSELY TIGHTEN ALL SCREWS USING THE HEX WRENCH “CC”.



Assembly Instruction (continued)

2 Tightening all screws

- ONCE ALL SCREWS ARE IN PLACE FULLY TIGHTEN ALL THE SCREWS USING THE HEX WRENCH “CC”.
- TURN TABLE RIGHT SIDE UP AND ENSURE THAT ALL CONNECTIONS ARE SECURE BEFORE USE.





HOME OFFICE: 1100 Coiner Ct., City of Industry, CA 91748

FAX: 1-626-269-6399

CUSTOMER SERVICE HOT LINE: 1-866-905-4107

SEVICE HOURS: MONDAY-FRIDAY 8:30 AM TO 5:00 PM PST
/ 11:30 AM TO 8:00PM EST

E-MAIL: customerservice@yotrious.com

sears

Please refer to part numbers when reordering

For questions or comments about product:

Email: customerservice@yotrious.com or Call toll-free: 1-866-905-4107

Made in CHINA / Hecho en CHINA

Distributed by Sears, Roebuck and Co., Hoffman Estates, IL 60179

See our extensive assortment of outdoor living products
on-line at www.sears.com and www.kmart.com