

SAFETY STEP

USER INSTRUCTIONS

CLIMB ON

PROPER CARE AND STORAGE

- Store in a safe and dry place out of the weather.
- Keep clean and free of all foreign material.
- Examine all working parts for any damaged, worn, or missing parts.
- Keep steps dry and clean.

Watch for electrical wires. This Safety Step conducts electricity. Never allow yourself or the Safety Step to come in contact with live circuits.

INSPECTION

- Inspect upon receipt and before each use. Never climb a damaged, bent, or broken Safety Step; all parts must be in good working order.
- Make sure all rivets are tight and function properly.
- Keep your Safety Step clean and free from wet paint, mud, snow, grease, oil, and other slippery materials. Keep your shoes clean.
- Replace damaged, worn, or missing rubber feet and step tread as required to ensure safety.
- Never make temporary repairs of damaged or missing Safety Step parts.

READ ALL WARNING AND SAFETY LABELS

- Do not over-reach. Keep your body centered between both side rails. Do not lean sideways. Move Safety Step as needed.
- Face your Safety Step when climbing up or down.
- Open Safety Step fully before climbing.
- Wear slip-resistant shoes.
- Place your Safety Step on firm, level surface.
- The Safety Step is designed for one person use including materials or tools. Not to exceed 300 lbs.
- To protect children, do not leave Safety Step set up and unattended.
- Do not use the Safety Step if you tire easily or are subject to fainting spells, are using medicine, alcohol or drugs, or are physically handicapped.
- Do not use on ice, snow, or slippery surfaces without non-skid devices.
- Do not place your Safety Step on unstable surface or on scaffolding to gain additional height.
- Do not place in front of door opening that would swing toward Safety Step.
- Fully lock the handrail in the base hinge when the handrail is in the upright position. Keep your hands and fingers away from the hinge joint when locking.
- Manufacturer disclaims any liability or responsibility for damage or injury caused as a result of misuse of the Safety Step.
- If a leg or step is broken, if it doesn't function properly, or is exposed to fire or chemical corrosion, destroy the Safety Step.
- Read, understand, and comply with all supplied instructions before using this Safety Step.

300 lbs WORKING LOAD

MODEL #	DISCRIPTION	TOP STEP HEIGHT	STORAGE HEIGHT	WEIGHT	STORAGE WIDTH
10210B	2 Step with Bar	18" / 45 cm	31.5" / 80 cm	14.5 lbs / 6.6 kg	5" / 13 cm
10310B	3 Step with Bar & Tray	26.5" / 67 cm	43" / 109 cm	21 lbs / 9.5 kg	5" / 13 cm
10410B	4 Step with Bar & Tray	35" / 89 cm	55" / 139.5 cm	26.5 lbs / 12.1 kg	5" / 13 cm

ONE YEAR WARRANTY

Little Giant Ladder Systems
1198 N. Spring Creek Place, Springville, UT 84663 / Phone: 800-453-1192
www.littlegiantladders.com

©2011 Little Giant Ladder Systems 56428 v2 9.11

TO OPEN

OPEN THE SAFETY STEP BY TILTING THE TOP STEP.



WARNING: Handrail must be down to open the Safety Step.

TO CLOSE

CLOSE THE SAFETY STEP BY TILTING THE TOP STEP.



WARNING: Handrail must be closed before the Safety Step can be placed in the storage position. Failure to do so may result in damage.

LITTLE GIANT SAFETY STEP WARRANTY

Wing Enterprises, Inc., warrants each new ladder, to the original purchaser thereof, to be free from defects in workmanship and materials when operated under normal conditions and maintained properly. This warranty covers all parts of the ladder, including hinges and lock assemblies.

This warranty shall be in effect for a period of One (1) year from date of purchase. This shall be in lieu of any other warranty expressed or implied, including, but not limited to, an implied warranty of merchantability or fitness for a particular purpose. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Wing Enterprises, Inc., will repair or replace, at its option and without cost to the original purchase, any ladder which has been found to be defective and is within the period of warranty. All freight to and from the factory is to be paid by the customer. The factory address is: Wing Enterprises, Inc., 1198 N. Spring Creek Place, Springville, Utah 84663.

The liability of Wing Enterprises, Inc., under this warranty shall be limited solely to repair or replacement of the ladder within the warranty period; and Wing Enterprises, Inc., shall not be liable, under any circumstances, for consequential or incidental damages, including, but not limited to, personal injury or labor costs. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives the original purchaser specific legal rights and you may also have other rights which vary from state to state.

Under no circumstances will Wing Enterprises, Inc., be responsible for any expense in connection with any repairs made by anyone other than the factory or authorized service provider unless such repairs have been specifically authorized in writing by Wing Enterprises, Inc.

This warranty is void if the enclosed Warranty Registration Card is not completed and returned to Wing Enterprises, Inc., within 30 days after receipt of product. **Mail Warranty Card to Wing Enterprises, Inc., 1198 N. Spring Creek Place, Springville, Utah 84663.**

SCAN THE CODE TO VIEW
INSTRUCTION & SAFETY VIDEO

