




Step 1:

Locate the filter housing (Located on the upper left side)




Step 2:

Remove the cover by sliding it toward yourself




Step 3:

Remove the old filter by simply pulling it out



Step 4:
Push in the new filter (you might hear it click)



Step 5:

Replace the cover of the compartment by sliding it back on