



SWASH™

quick start guide

For a digital version,
including video instructions,
visit SWASH.COM/SETUP



W10526489A

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance.
Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING." These words mean:

 **DANGER**

You could be killed or seriously injured if you don't immediately follow instructions.

 **WARNING**

You can be killed or seriously injured if you don't follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

STATE OF CALIFORNIA PROPOSITION 65 WARNINGS:

WARNING: This product contains one or more chemicals known to the State of California to cause cancer.

WARNING: This product contains one or more chemicals known to the State of California to cause birth defects or other reproductive harm.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury to persons when using the SWASH™ system, follow basic precautions, including the following:

- / Read all instructions before using the SWASH™ system.
- / Use the SWASH™ system only for its intended use.
- / To reduce the risk of electric shock, do not immerse any part of SWASH™ system in water or other liquids.
- / Never yank cord to disconnect from outlet; instead, grasp plug and pull to disconnect.
- / Do not allow cord to touch hot surfaces. Let SWASH™ system cool completely before putting away. Loop cord loosely around SWASH™ system when storing.
- / Always disconnect SWASH™ system from electrical outlet when not in use, or when cleaning SWASH™ system.
- / Do not operate SWASH™ system with a damaged cord, or if it has been dropped or damaged. To reduce the risk of electric shock, do not disassemble or attempt to repair SWASH™ system. Contact a qualified service person for examination and repair. Incorrect reassembly or repair could cause a risk of fire, electric shock, or injury to persons when SWASH™ system is used.
- / Close supervision is necessary for any appliance being used near children.
- / Use care when interrupting a cycle; interior surfaces may be hot if SWASH™ system is opened when in use.
- / To reduce the likelihood of circuit overload, do not operate other high-wattage hardware (i.e. refrigeration, air conditioner, etc) on the same circuit.
- / The SWASH™ system is intended for household use only. Do not use outdoors.
- / Do not use in garages or near any flammable liquids.
- / Do not use an extension cord.
- / The use of accessories other than those supplied with the SWASH™ system is not recommended and may cause injury.
- / Use and store SWASH™ system out of regularly traveled paths to reduce the possibility of tip-over.
- / Keep the area clear around the base of SWASH™ system to make sure ventilation openings in the bottom of SWASH™ system are not blocked.
- / Do not modify SWASH PODS™ cups or use any alternate formulas. The SWASH™ system was designed to work safely using only the unique SWASH PODS™ cups. Any modifications could reduce user safety.
- / Burns could occur from touching hot metal parts.

SAVE THESE INSTRUCTIONS

Welcome to Life Unhindered™

Congratulations on your purchase of SWASH™ system. Use this QUICK START GUIDE to get to know your SWASH™ system. For a digital version, including video instructions, visit SWASH.COM/SETUP

SWASH™ system kit includes the following:

- SWASH™ adjustable hanger
- SWASH PODS™ cups multipack
- SWASH™ pocket smoother

SWASH PODS™ CUPS



RESERVOIR



Register your SWASH™ system and receive a coupon code for 2 additional hangers.* Register online: SWASH.COM/REGISTER or text 'SWASH' to 71403.**

*while supplies last **standard text messages and data rates may apply

⚠ WARNING

Excessive Weight Hazard

Use two or more people to move SWASH unit.

Failure to do so can result in back or other injury.

⚠ WARNING



Electrical Shock Hazard

Plug into a grounded 3 prong outlet.

Do not remove ground prong.

Do not use an adapter.

Do not use an extension cord.

Failure to follow these instructions can result in death, fire, or electrical shock.


CONNECTING YOUR SWASH™ SYSTEM

Plug your SWASH™ system into a standard grounded electrical outlet (120v).

No plumbing, pipes, or vents needed.



/ Please dispose of/recycle all packaging materials.



X BUTTON
cancels your cycle

10 MINUTE BUTTON
(STANDARD CYCLE)
use for most clothing

15 MINUTE BUTTON
(EXTENDED CYCLE)
extends drying time for
your heavier clothing

buttons

status lights

● BLUE LIGHT
turns on when your
cycle is finished

● WHITE LIGHTS
counts down the
minutes remaining

● ORANGE LIGHT
flashes if you try to start
without a cup or the door
is not completely closed

(if other lights are on with the
orange light, see page 13 for
troubleshooting)

How to use your SWASH™ system

1 / hang

Pull out the door /
hang your clothes.
(see pages 8–9 for tips)

2 / load

Load a new cup /
close door firmly.
Only use SWASH PODS™ cups.


3 / start

Touch 10 or 15 to start your cycle.
White lights will count down the minutes
remaining / a blue light will let you know
when cycle is done.




Hanging your clothes

Visit swash.com/setup for video demonstrations on how to hang various articles of clothing.



Smoothing clips aren't needed for refreshing. You can get great results with minimal effort. For smoothing wrinkles, try experimenting with a few clips.

IMPORTANT: The SWASH™ system is not recommended for silk, leather, velvet, suede, and fur. Some temporary spots may occur. If this happens, clean per clothing manufacturer's instructions.




BUTTON DOWN SHIRT

Place sleeves through sleeve wraps and clip. Use the remaining 4 clips to pull flat and hold tight to get maximum wrinkle release. Finally, put pocket smoother in pocket.



PANTS OR JEANS

Hang legs over the top of hanger first and then clip. Pull waist down and clip to get the most area exposed to the SWASH PODS™ formula.



SHORTS OR SKIRTS


Pull a couple of smoothing clips through the hanger for shorts and skirts.

How does it work?

The SWASH™ system works with a few key technologies. A superfine mist of the SWASH PODS™ formula is sprayed onto both sides of the hanging clothes. The smoothing clips (optional) pull clothes tight, and heat is circulated.

SUPERFINE MIST

WARM AIR CIRCULATION



Color enhanced for demonstration purposes.

Emptying the reservoir

Your SWASH™ system is designed to collect any excess mist for easy disposal. If the orange and blue lights are both flashing, you will need to empty the reservoir that collects the excess mist.



● BLUE + ● ORANGE FLASHING:

- 1/ Locate reservoir at rear base of SWASH™ system. Remove reservoir and take to sink.
- 2/ Pull plug and empty out liquid in sink.
- 3/ Replace plug and insert reservoir back into the SWASH™ system.

/ Ensure the reservoir is emptied by an adult and keep the liquid away from children and pets. Wash hands after emptying.

Tips

Visit swash.com/setup for additional information and video demonstrations.

Multiple clothing items

The SWASH™ system works best on one item. If refreshing 2 items at a time, hang them back-to-back for best results. Additional SWASH™ hanger required. You can order additional hangers at SWASH.COM

Reducing wrinkles

To maximize wrinkle release, button or zip up your clothing. Use the smoothing clips for non-stretchy fabrics. Make sure your clothes are tight and smooth.

Smoothing Clips

Experiment with the smoothing clips to find what gives you the best results for your clothes. You may not need all of the provided smoothing clips to get great results.

Temperature use

If your SWASH™ system or SWASH PODS™ cups have just come inside from very cold weather, allow them to sit for a while to get to room temperature before using.

Cleaning the SWASH™ system

Use a soft, damp cloth or sponge to wipe your SWASH™ system to help keep it looking new.

Wash hands after cleaning

If eye contact occurs, rinse well with water. If irritation persists, get medical attention.

Dimensions

When door is closed, the dimensions of the device are 51" tall x 16.5" wide x 30" deep .

Troubleshooting

Nothing happens when you push the 10 or 15 minute button

- / Check to make sure the SWASH™ system is plugged into a power outlet.
- / If SWASH™ system is plugged in, unplug it and plug it back in to reset.

SWASH™ system does not work as well as expected

- / Select the recommended cycle based on your clothing type.
- / Keep longer clothes from laying on the bottom of the device.
- / SWASH™ system is only recommended for 2 lightweight items. For best results, refresh only one item at a time.
- / Do not operate, install, or store the SWASH™ system where it will be exposed to water, weather, or at temperatures below 50° F (10° C). Let the SWASH™ system and SWASH PODS™ cups warm up to room temperature before use.

You have a spot on your clothing after a cycle

- / The SWASH PODS™ formula may leave a spot on some fabrics. These spots are easily removed when clothes are washed or dry-cleaned according to clothing manufacturer's care label.

For any other issues, please call us on 1.866.333.4195



1. **Orange light is blinking - SWASH™ system will not start**
 - / Make sure door is closed properly.
 - / Make sure cup is loaded in bay. If cup is empty or missing, replace with new cup. Use only SWASH PODS™ cups in your SWASH™ system.



2. **Orange and blue lights are blinking**
 - / The reservoir is full and needs to be emptied, or is missing and needs to be replaced. See emptying the reservoir on page 11.



3. **Orange light blinking and white lights on**
 - / If orange light is blinking and at least two white lights are solid, SWASH™ system is not working. Call for service: 1.866.333.4195



4. **Orange and white lights on**
 - / If orange and time remaining lights are solid, SWASH™ system is paused. Close door and cycle will resume.

LIMITED WARRANTY

ONE YEAR LIMITED WARRANTY

ATTACH YOUR RECEIPT HERE. PROOF OF PURCHASE IS REQUIRED TO OBTAIN WARRANTY SERVICE.

Please have the following information available when you call the CUSTOMER EXPERIENCE CENTER:

- / Name, address, and telephone number
- / Model number and serial number
- / A clear, detailed description of the problem
- / Proof of purchase including dealer or retailer name and address

WHAT IS COVERED

For one year from the date of purchase, when this major appliance is installed, operated, and maintained according to instructions attached to or furnished with the product, Go Unlimited, LLC (hereafter Go Unlimited) will pay for Factory Specified Replacement Parts and repair labor to correct defects in materials or workmanship that existed when this major appliance was purchased. In the event of product replacement, your appliance will be covered by the remaining term of the original unit's warranty period. YOUR SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR AS PROVIDED HEREIN. Service must be provided by a Go Unlimited designated service company. This limited warranty is valid only in the United States or Canada and applies only when the major appliance purchased in the U.S.A. This limited warranty is effective from the date of original consumer purchase. Proof of original purchase date is required to obtain service under this limited warranty.

WHAT IS NOT COVERED

1. Commercial, non-residential, multiple-family use, or use inconsistent with published user, operator, or installation instructions.
2. In-home instruction on how to use your product.
3. Service to correct improper product maintenance or installation, installation not in accordance with electrical or plumbing codes, or correction of household electrical or plumbing (i.e. house wiring, fuses, or water inlet hoses).
4. Consumable parts (i.e. light bulbs, batteries, air or water filters, etc.).
5. Conversion of your product from natural gas or L.P. gas or reversal of appliance doors.
6. Damage from accident, misuse, abuse, fire, floods, acts of God, or use with products not approved by Go Unlimited.
7. Repairs to parts or systems to correct product damage or defects caused by unauthorized service, alteration, or modification of the appliance.
8. Cosmetic damage including scratches, dents, chips, and other damage to appliance finishes unless such damage results from defects in materials and workmanship and is reported to Go Unlimited within 30 days.
9. Discoloration, rust, or oxidation of surfaces resulting from caustic or corrosive environments, including but not limited to, high salt concentrations, high moisture or humidity, or exposure to chemicals.
10. Pick-up or delivery. This product is intended for in-home repair.
11. Travel or transportation expenses for service in remote locations where an authorized Go Unlimited servicer is not available.
12. Removal or reinstallation of inaccessible appliances or built-in fixtures (i.e. trim, decorative panels, flooring, cabinetry, islands, countertops, drywall, etc.) that interfere with servicing, removal, or replacement of the product.
13. Service or parts for appliances with original model/serial numbers removed, altered, or not easily determined.

DISCLAIMER OF IMPLIED WARRANTIES

IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR OR THE SHORTEST PERIOD ALLOWED BY LAW. Some states and provinces do not allow limitations on the duration of implied warranties of merchantability or fitness, so this limitation may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state or province to province.

DISCLAIMER OF REPRESENTATIONS OUTSIDE OF WARRANTY

Go Unlimited makes no representations about the quality, durability, or need for service or repair of this major appliance other than the representations contained in this Warranty. If you want a longer or more comprehensive warranty than the limited warranty that comes with this major appliance, you should ask Go Unlimited or your retailer about buying an extended warranty.

LIMITATION OF REMEDIES; EXCLUSION OF INCIDENTAL AND CONSEQUENTIAL DAMAGES

YOUR SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR AS PROVIDED HEREIN. GO UNLIMITED SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, so these limitations and exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state or province to province.

IF YOU NEED SERVICE:

1. Before contacting us to arrange service, please determine whether your product requires repair. Some questions can be addressed without service. Please take a few minutes to review the Troubleshooting section or visit SWASH.COM
2. All warranty service is provided exclusively by our authorized Go Unlimited Service Providers. In the U.S. direct all requests for warranty service to:

GO UNLIMITED CUSTOMER EXPERIENCE CENTER

In the U.S.A. call: 1.866.333.4195

If outside the 50 United States, contact your authorized Go Unlimited dealer to determine if another warranty applies.

2014.05.14



SWASH™
life unhampered™

Whirlpool®/™ is a trademark of Whirlpool U.S.A. Tide®/™ is a trademark of The Procter & Gamble Company. Swash®/™ is a trademark of Go Unlimited LLC. © 2014. All Rights Reserved. The WHIRLPOOL and TIDE trademarks are used by Go Unlimited LLC under license. Product manufactured under license for and warranty provided by Go Unlimited LLC, Cincinnati, OH 45202.

2014.05.14 Printed in USA W10526488A

For questions visit SWASH.COM
or call 1-866-333-4195