

# USE & CARE GUIDE

## Music Umbrella with Bluetooth

Product Code: D71 M20513

KSN: 08769305-7

UPC Code: 749241315152

Date of purchase: \_\_\_\_/\_\_\_\_/\_\_\_\_



# Thank you for your purchase

## Thank you for your purchase!

We are pleased that you have chosen Sears for your outdoor furniture purchase. We hope that you enjoy the unmatched quality, comfort, and style of your new patio set. Every piece is meticulously considered all the way down to the smallest details, exclusively for you, by our world class design team. We know you have a choice when it comes to your patio furniture needs, so from our team to yours, thank you for letting us be a part of your outdoors.

# Table of contents

**Table of Contents** .....2

**Safety Information** .....3

    Set Up our Shelter Properly .....3

    Examine your Shelter .....3

**Warranty** .....3

    Excluded .....3

    Service Center .....3

**Care and Maintenance** .....4

**Pre-Assembly** .....5

    Package Contents .....5

**Assembly Instructions** .....6

**Customer Service** .....8

## Safety Information

---

### SET UP YOUR SHELTER PROPERLY

- ☐ Please read and understand this entire manual before attempt to assemble, operate, or install the product.
- ☐ If any part is missing or damaged. Do not attempt to assemble the product.
- ☐ Do not use the structure as support.
- ☐ Keep instructions for future use.

### EXAMINE YOUR SHELTER

- ☐ Examine occasionally to ensure there are no loose parts. If loose parts are found, they should be retightened fully immediately.

## Warranty

---

### 1 YEAR WARRANTY FOR FRAME AND FABRIC

Limited warranty is applicable on parts only. Warranty extends solely to the original purchaser who must offer original sales receipt for record.

#### WHAT IS COVERED

Limited parts warranty covers original purchaser from date of purchase for one year. Warranty ensures umbrella fabric cover and umbrella with bluetooth speaker and bottom tube will be free from manufacturing defects.

#### WHAT IS NOT COVERED

Product used for commercial, contract, or other non-residential purposes, or damage due to acts of nature, vandalism, misuse, or improper assembly is not covered. Corrosion or rusting of hardware is not covered. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued.

### SERVICE CENTER

The purchaser must contact our customer service center directly if this product is found to be defect in material or workmanship. The manufacturer, as its option, will repair or replace the defectives parts.

Please contact us via 1-800-961-9838, 9AM-5PM, Pacific Time Zone, Monday-Friday, or [customerservice@bondvast.com](mailto:customerservice@bondvast.com)

## Care and Maintenance

---

- For cleaning, use a mild detergent solution and rinse with water. Do not use acetone abrasive or others special detergents to clean and air dry only.
- Due to the nature of aluminum, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.

## FCC ID: 2AC7TMUBE06W

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## Pre-Assembly

---

### PLANNING ASSEMBLY



To prevent damage, place all parts on a soft surface during assembly.

Do not leave it unattended if not fully assembled even if bolted to the ground.



## Pre-Assembly

---


### Part content

PART	DESCRIPTION	PICTURE	QTY.
A	Umbrella with Bluetooth Speaker		1
B	Bottom Tube		1

## Assembly Instructions



Step 1:  
Insert umbrella (A)  
into bottom tube (B).  
Then secure bottom tube to  
umbrella base.  
Umbrella base sold separately.




Step 2:  
Turn the crank in clockwise  
to unfold the umbrella.

## Assembly Instructions

### Step 3:

Push down the battery cover then place 3 AA batteries (not included).

Do not mix old and new batteries. Do not mix alkaline, standard (Carbon - zinc), or rechargeable (Nickel - cadmium) batteries.



## Assembly Instructions

Step 4:



Turn on unit by pushing the black ON/Off Button, (a 2 rings will sound), the Red LED light will blink (untill you connect your wireless device).

On your device, turn Bluetooth on. Set your device to search for "MUSIC UMBRELLA". Select "MUSIC UMBRELLA" to pair your device. The Red LED light will turn solid once you are connected.

When you play music the Red LED light will continue to blink.




**Warning:** This speaker is design for this product only.  
Do not replace or modify this product.



## Assembly Instructions

### Step 5:

Press the button on the upper portion of the umbrella tube to tilt.



### Warning:

To avoid damage to your table: An umbrella base must be used at all time. The umbrella should be removed and stored in the event of wind, rain, hail, sleet, snow, or any other inclement weather.

## Solutions to Common Speaker

Phenomenon Problems	Solutions
Several unsuccessful connection attempts	<ol style="list-style-type: none"> <li>1. Ensure the speakers is in standby mode and turn off connection with all Bluetooth devices.</li> <li>2. Or restart.</li> </ol>
Volume too low or sound distorted	<ol style="list-style-type: none"> <li>1. Or reboot change to Turn off the power for 10 seconds</li> <li>2. Or restart.</li> </ol>
Discontinuous sound for music playing	Move the speaker closer or remove obstacles between speaker and your music playing device, make sure the distance in between umbrella and device within 10m.
Indicator light not working	<ol style="list-style-type: none"> <li>1. Check batteries.</li> <li>2. Or restart.</li> </ol>

## Important Notes

Read all of the instructions carefully.

Comply with all of the instructions.

Clean the product with a dry cloth.

Do not place the product in a humid environment.



Do not place the product in any liquid.

Do not install the product near a heat source, such as radiator, heater, furnace, or other heating equipment.

Remove batteries when not in use for extended periods of time.

Do not attempt to modify the product in any way.

### Works with ANY device with Bluetooth connectivity



\*Batteries sold separately





## BOND VAST INDUSTRIAL LIMITED

---



No. 174 Ding Tan Pi Tan Vill Lutsao Hsiang, Chla Yi Hsien, Tai Wan, ROC

FAX: 886-5-3651 522

CUSTOMER SERVICE HOT LINE: 1-800-961-9838

SERVICE HOURS: MONDAY - FRIDAY 9:00AM - 5:00PM (PACIFIC TIME)

E-MAIL: [CUSTOMERSERVICE@BONDVAST.COM](mailto:CUSTOMERSERVICE@BONDVAST.COM)

sears

Please refer to part numbers when reordering

For questions or comments about product:

Email: [customerservice@bondvast.com](mailto:customerservice@bondvast.com) or Call toll-free: 1-800-961-9838

Made in / Hecho en CHINA

Distributed by Sears, Roebuck and Co., Hoffman Estates, IL 60179

[sears.com](http://sears.com)

See our extensive assortment of outdoor living products  
on-line at [www.sears.com](http://www.sears.com) and [www.kmart.com](http://www.kmart.com)