

Auto-iQ™

XSK2424



NUTRI NINJA® GO-COMBO

www.ninjakitchen.com

IMPORTANT SAFEGUARDS






For Household Use Only

Before using the Nutri Ninja® Cups, read the instruction manual of the appliance it is being used with.

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

WARNING

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:

- 1  **WARNING:** Never leave the appliance unattended while in use.
- 2  **CAUTION:** Blade assembly is sharp. When handling the blade assembly, always hold by the base of the blade assembly.
- 3  **CAUTION:** DO NOT BLEND HOT FOODS OR HOT LIQUIDS.
- 4  **CAUTION:** DO NOT process dry ingredients without adding liquid to the cup. This product is not intended for dry blending.
- 5  **CAUTION:** Never attempt to remove the cup while the appliance is still running.
- 6 **DO NOT** allow young children to operate the appliance or use as a toy. Close supervision is necessary when any appliance is used by or near children.
- 7 Always use the appliance on a dry, level surface.
- 8 Keep hands, hair, clothing, as well as utensils out of cup while processing to reduce the risk of severe injury to persons or damage to the appliance. A scraper may be used but **ONLY** when the appliance is not running.
- 9 Avoid contact with moving parts.
- 10 **DO NOT** attempt to sharpen blade assemblies.
- 11 **DO NOT** use the appliance if the blade assembly is bent or damaged.

Euro-Pro Operating LLC

US: Newton, MA 02459

CAN: Ville St-Laurent, QC H4S 1A7

1-877-646-5288

www.ninjakitchen.com

PRINTED IN CHINA

© 2015 EURO-PRO Operating LLC

Illustrations may differ from actual product. We are constantly striving to improve our products, therefore the specifications contained herein are subject to change without notice.

- 12 To reduce risk of injury, never place the blade assembly on the motor base without the proper container.
- 13 To reduce the risk of injury, **NEVER** operate the appliance without the blade assembly in place. **DO NOT** try to defeat the interlock mechanism; make sure that the appliance is properly installed before operating the appliance.
- 14 **DO NOT** expose cups to extreme temperature changes.
- 15 **DO NOT** overfill.
- 16 **DO NOT** operate the appliance empty.
- 17 This product is intended for household use only. **DO NOT** use this appliance for anything other than its intended use. **DO NOT** use outdoors.
- 18 Nutri Ninja® Cups are **NOT** intended to be used in the microwave. **DO NOT** place the cups in the microwave as it may result in damage to the accessories or the microwave.

SAVE THESE INSTRUCTIONS

THIS ACCESSORY IS COMPATIBLE WITH THE FOLLOWING MODELS:

BL480 series
BL490 series
BL640 series
BL680 series

Nutri Ninja® Cup Capacity: 24 ounces (3 cups)
 22 MAX liquid ounces (2.75 cups)

Sip & Seal, Pro Extractor Blades, Euro-Pro, Nutri Ninja and Ninja are registered trademarks of Euro-Pro Operating LLC.

Complete Extraction System is a trademark of Euro-Pro Operating LLC.

Using the Nutri Ninja® Cup

- ⚠ WARNING: NEVER LEAVE THE APPLIANCE UNATTENDED WHILE IN USE. NO LIGHTS WILL TURN ON.**
- ⚠ CAUTION: USE CAUTION WHEN HANDLING THE BLADE ASSEMBLIES AS THE BLADES ARE VERY SHARP.**
- ⚠ CAUTION: DO NOT BLEND HOT FOODS OR HOT LIQUIDS IN THE NUTRI NINJA® CUP.**



This accessory pack includes two Nutri Ninja® Cups and 2 Sip & Seal® lids and is to be used with your Pro Extractor Blades® that came with your blender. Motor base may vary depending on unit purchased.

IMPORTANT: DO NOT OVERFILL! TO AVOID SPILLING, DO NOT ADD INGREDIENTS PAST THE “MAX FILL” LINE.

- 1 Remove all packaging material and labels from the cups.
- 2 Wash the lids and the cups assembly in warm, soapy water with a soft cloth.
- ⚠ CAUTION: Handle the blade assembly with care when washing as the blades are very sharp.**
- 3 Rinse and dry thoroughly.
- 4 The cups, lids and blade assembly are all dishwasher safe. It is recommended that the Sip & Seal® lids, cups and blade assembly be placed on the top rack. Ensure that the blade assembly is removed from the cup before placing in the dishwasher.

IMPORTANT: Place the motor base of the main unit used on a clean, dry, level surface such as a counter or table top.

- 5 Add ingredients to the cup, starting with fresh items and placing frozen items closest to the blades. For best results, use at least 1/2 cup liquid.



Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5

- 6 Place the blade assembly onto the cup and twist it on tightly, clockwise, until you have a good seal. **(Fig. 1)**
- 7 Turn the cup upside down and place it onto the motor base, aligning the tabs on the cup with the motor base. Turn it clockwise, until it “clicks” into place. **(Fig. 2)**
- 8 Follow the operation instructions from the main instruction manual of the base being used. Press one of the appropriate buttons to start. **(Fig. 3)**
- 9 To remove the cup, ensure that the motor has stopped running. Then turn the cup counter clockwise **(Fig. 4)** and pull straight up to remove. **(Fig. 5)**
- 10 Turn the cup upright and remove the blade assembly by twisting the blade assembly counter clockwise. Be sure to store the blade assembly attached to an empty cup when not in use.
- 11 Twist the Sip & Seal® lid onto the cup to enjoy your drink on the go. Press flip top cap firmly into the opening to get the best seal. The flip top cap locks open when pressed backward.
- 12 Make sure that the motor base is unplugged when not in use.

Care & Maintenance

CLEANING:

- ⚠ CAUTION: MAKE SURE THAT THE MOTOR BASE IS UNPLUGGED FROM THE POWER SOURCE BEFORE INSERTING OR REMOVING ANY ATTACHMENT AND BEFORE CLEANING.**
- ⚠ CAUTION: DO NOT IMMERSE THE MOTOR BASE INTO WATER OR ANY OTHER LIQUID.**
- ⚠ CAUTION: HANDLE THE BLADE ASSEMBLIES CAREFULLY AS THE BLADES ARE VERY SHARP!**

- 1 Separate/remove all parts from each other.
- 2 Clean the motor base with a damp cloth and wipe dry.
- 3 Place the cup, lid and blade assembly in the top rack of the dishwasher.

STORING:

- 1 Store the Nutri Ninja® cups, the Sip & Seal® lids and blade assembly where they will not be damaged and won't cause a hazard.

Troubleshooting

Unit doesn't turn on:

- Make sure the unit is plugged in.
- Insert and rotate cup clockwise in the base until it "clicks".

Unit doesn't turn off:

- Remove cup from base by rotating cup counterclockwise and lifting out. Display should turn off. Unplug the power cord from the outlet.

Lid/blade assembly hard to assemble:

- Do not overfill the cup with solid ingredients.
- Set the cup on a level surface. Place the lid or blade assembly on the top of the cup and align the threads so that the lid/blades sit flat on the cup. Twist clockwise so that the lid/blades evenly align to the cup until you have a tight seal.

Doesn't mix well, food gets stuck:

- Pulses and pauses allow the food to settle towards the blade. If food is routinely getting stuck adding some liquid will usually help.
- When loading the cup, start with fresh items, followed by frozen items or ice. Add dry or sticky ingredients such as powders or syrups last. For best results, use at least 1/2 cup liquid.
- For best results, use Auto-iQ™ programs. Pulses and pauses allow the food to settle towards the blades. If ingredients are routinely getting stuck, add additional liquid or reduce the amount of hard or frozen ingredients in the cup.

ONE (1) YEAR LIMITED WARRANTY

EURO-PRO Operating LLC warrants this product to be free from material defects and workmanship for a period of one (1) year from the date of purchase when utilized for normal household use, subject to the following conditions, exclusions and exceptions.

The liability of **EURO-PRO Operating LLC** is limited solely to the cost of the repair or replacement of the unit at our option. This Limited Warranty does not cover normal wear of parts and does not apply to any unit that has been tampered with or used for commercial purposes. This Limited Warranty does not cover damage caused by misuse, abuse, negligent handling or damage due to faulty packaging or mishandling in transit. This Limited Warranty does not cover damage or defects caused by or resulting from damages from shipping or repairs, service or alteration to the product or any of its parts, which have been performed by a repair person not authorized by **EURO-PRO Operating LLC**.

If your appliance fails to operate properly while in use under normal household conditions within the warranty period, return the complete appliance and accessories, freight prepaid. For assistance with warranty service options or customer support, please call our customer care and product specialists at , call 1 (877) 646-5288 or visit our website www.ninjakitchen.com.

If the appliance is found to be defective in material or workmanship, **EURO-PRO Operating LLC** will repair or replace it free of charge. Proof of purchase is required and a fee of \$19.95 will apply to cover the cost of return freight. *

This Limited Warranty is extended to the original purchaser of the unit and excludes all other legal, implied and/or conventional warranties. The responsibility of **EURO-PRO Operating LLC** if any, is limited to the specific obligations expressly assumed by it under the terms of this Limited Warranty. In no event is **EURO-PRO Operating LLC** liable for incidental or consequential damages to anyone of any nature whatsoever. Some states do not permit the exclusion or limitation of incidental or consequential damages, so the above may not apply to you.

This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from state to state or from province to province.

***IMPORTANT: Carefully pack item to avoid damage in shipping. Be sure to include proof of purchase date and to attach tag to item before packing with your name, complete address and phone number with a note giving purchase information, model number and what you believe is the problem with the item. We recommend you insure the package (as damage in shipping is not covered by your Limited Warranty). Mark the outside of your package "ATTENTION CUSTOMER SERVICE".**

Product Registration

Please visit www.ninjakitchen.com or call 1-877-646-5288 to register your new Ninja® product within ten (10) days of purchase. You will be asked to provide the store name, date of purchase and model number along with your name and address. The registration will enable us to contact you in the unlikely event of a product safety notification. By registering you acknowledge to have read and understood the instructions for use, and warnings set forth in the accompanying instructions.



NINJA[®]

Thank you for purchasing
your new Ninja[®]!

If you have any questions, we are here to help!

CALL US

Toll Free: **1-877-646-5288**

Our team is available:

Mon-Sat, 7am - 11pm EST &

Sun, 9am - 8pm EST

ONLINE

Visit us online at **www.ninjakitchen.com**.

Or find us on Facebook: **fb.me/ninjakitchen**



For product demos visit our YouTube channel
at: **www.youtube.com/EPNinjaKitchen**.

