




**Portable Evaporative Air Cooler**  
for Indoor Use

**Evaporativo Portátil Enfriador De Aire**  
para uso En El Interior

**Portatif Évaporatif Refroidisseur D'air**  
pour Usage Intérieur



## **OWNER'S MANUAL**

Read and save these instructions before use

## **MANUAL DEL PROPIETARIO**

Lea y guarde estas instrucciones antes de usar la unidad

## **MANUEL DU PROPRIÉTAIRE**

Lire et conserver ces instructions avant utilisation

**Model / Modelo / Modèle: CS10XE**

**Power rating / Potencia / Puissance nominale: 102W**  
**Voltage rating / Tensión / Tension nominale: 120V ~ 60Hz**

For product inquiries or support / Para consultas del producto o soporte /  
Pour les questions sur les produits ou pour du soutien:  
[www.honeywellaircoolers.com](http://www.honeywellaircoolers.com)

# QUICK START GUIDE

1



Fill with water and plug into a standard power outlet.

Note: Please make sure the household power voltage matches the product specifications.

2



Place near an open door or window.

Note : Evaporative air cooler requires cross ventilation.

3



Turn ON and enjoy the cooling breeze.

Note: Start with LOW speed and gradually increase to higher speed for optimum cooling performance.

Read all instructions carefully before setting up and operating the unit, and please keep this instruction manual for future reference. This manual is designed to provide you with important information needed to setup, operate, maintain, and troubleshoot your cooler. Failure to follow these instructions may damage and/or impair its operation and void the warranty.

SECTION	PAGE
1. THANK YOU .....	2
2. USER TIPS .....	3
3. SAFETY .....	5
4. PARTS DESCRIPTION .....	7
5. USE & OPERATION .....	8
Control Panel .....	8
Function Buttons .....	9
Low Water Alarm Function .....	11
Remote Control .....	12
Filling with Water .....	13
6. CLEANING & MAINTENANCE .....	14
7. TROUBLESHOOTING GUIDE .....	16
8. TECHNICAL SPECIFICATIONS .....	18
9. ELECTRICAL WIRING DIAGRAM .....	18
10. SERVICE AND WARRANTY .....	19

# THANK YOU

Congratulations on your purchase of this versatile Honeywell Evaporative Air Cooler. For optimum cooling from your cooler, fill the water tank to maximum level and load ice inside the ice compartment before you turn on your air cooler.

## Cooler Location - Indoors (Important - Please Read!)



Place the cooler in front of an open door or window. Ensure that there is adequate cross - ventilation in the room by leaving a door or window open opposite the cooler. Following these guidelines will ensure your cooler will work as effectively as possible.

## Not an Air Conditioner (Important - Please Read!)

The evaporative air cooler is not an air conditioner as it does not use a compressor or refrigerant gas. It should not be expected to cool as efficiently as a refrigerated air conditioner.

## Energy Efficient, No Compressor

Honeywell Evaporative Air Coolers are built to maximize energy efficiency and keep costs low. Warm air is drawn into the cooler through a dust and odor-reducing carbon filter and enters the Honeycomb Cooling Media. Water pumped from the tank pours over the honeycomb media. As the warm air passes through the media, the water absorbs the heat, naturally cooling and humidifying the air. A fan propels the cooled air out into the room. This no-compressor system cools naturally, efficiently and inexpensively.



## USER TIPS

The recommended maximum relative humidity level is 60% or less, which allows a noticeable temperature decrease. The temperature decrease will be greater in drier climates because higher evaporation occurs when the humidity is low.

The evaporative air cooler should not be used in enclosed spaces. It must be kept level and there must be water in the water tank. The room should have doors and windows opened to allow free air flow. The evaporative air cooler works best when placed near an open window, so that outside air is drawn into the evaporative air cooler, circulates in the room, then exits via the door. The maximum cooling effect is felt when a person is in the flow of air coming out of the evaporative air cooler.

The evaporative air cooler can also be used to humidify dry air during cool weather. To be used for humidification the windows and doors should be closed to allow the humidified air to accumulate.



Room with open windows & door  
(RECOMMENDED)



Room with closed windows & door  
(NOT-RECOMMENDED)

## NOTE

When the product is used for the first time the Honeycomb Cooling Media will have an odor which will dissipate in a few hours or so of initial use.



**READ AND SAVE THESE INSTRUCTIONS:**

When using electrical appliances, basic safety precautions should always be followed:

- Your cooler runs on 120 Volt AC, 60 Hz current. Check the household voltage to ensure it matches the appliance's rate specification.
- Before operating the product remove it from its packaging and check that it is in good condition.
- **DO NOT** operate any product with a damaged cord or plug. We recommend not using an extension cord with this appliance.
- **DO NOT** run power cord under carpeting, or cover it with rugs or runners. Keep the cord away from areas where it may be tripped over.
- Always unplug the product before refilling the water tank.
- Always unplug the appliance from the power source before cleaning, servicing or relocating the unit.
- Remove the power cord from the electrical receptacle by grasping and pulling on the power cord plug-end only, never pull the cord.
- **DO NOT** use the product in areas where gasoline, paint or other flammable goods and objects are stored.
- When using the **COOL** setting, check the water tank to ensure that it is full. Operation of this cooler on the **COOL** setting with an empty tank may result in damage to the water pump.
- **WARNING:** To reduce the risk of fire or electric shock, do not use this appliance with any solid state speed control device.




120V AC 60Hz

SHOCK HAZARD






WATER LEVEL INDICATOR





# SAFETY

- DO NOT attempt to repair or adjust any electrical or mechanical functions of the cooler, as this may void the warranty.
- DO NOT cover the air inlet or outlet on the appliance as this may cause motor damage.
- DO NOT insert or allow objects to enter any ventilation or exhaust opening as this may damage the product and could cause electrical shock or fire.
- DO NOT operate with the Honeycomb Cooling Media removed as this will overload and damage the motor.
- DO NOT leave the operating appliance unattended for any extended period of time.
- DO NOT let children play with this appliance, packaging or plastic bags.
- If the unit is damaged or it malfunctions, do not continue to operate it. Refer to the troubleshooting section and seek professional advice.
- Place the unit on a level floor.
- This product is not intended for use in wet or damp locations.
- DO NOT use in bathrooms. Never locate the product where it may fall into a bathtub or other water container.
- Store in a dry area when not in use.
- This appliance is not intended for use by persons (including children or elderly) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning the use of the appliance by a person responsible for their safety.
- Always grip the side handles to move the cooler.








- 1 Display Screen
- 2 Control Panel
- 3 Louvers
- 4 Front Grill
- 5 Front Castors

- 6 Handle
- 7 Remote Control
- 8 Honeycomb Cooling Media
- 9 Rear Grill
- 10 Water Fill Tray
- 11 Water Tank
- 12 Rear Wheels
- 13 Carbon Filter
- 14 Water Level Indicator
- 15 Water Tank Lock Clip
- 16 Power Cord & Plug

## ACCESSORIES:

Remote Control with 1pc CR2032 (1 x 3V) coin type battery.

## CONTROL PANEL



### Icons on LED

	Cool		Swing
	Low speed	0.5	
	Medium speed	1  4	Time delay set
	High speed	2	
			Power ON / OFF

## FUNCTION BUTTONS

## POWER

Press the POWER button to turn the unit on. To turn the unit off, press the button again. The cooler will start automatically at medium speed. After a few seconds the speed will switch to low.



## SPEED


Press the SPEED button repeatedly to change the speed between H - M - L. The indicator light will show the selected speed:

High (H) ↔ Medium (M) ↔ Low (L)



## TIMER

Press the TIMER button until the indicator light moves to your desired time setting. Once the set time has passed, the unit will automatically shut off. The Timer function allows you to program the unit for up to 7.5 hours of use.



# USE & OPERATION

## SWING


Press the SWING button. The indicator light will come on and the louvers will begin to move from right to left automatically. Manually adjust the horizontal louvers to change vertical airflow.



## UP-DOWN AIR FLOW

To adjust the vertical direction of air flow, adjust the horizontal louvers located behind the front grill manually.

LOUVER MOVEMENT




## COOL


When the COOL function is not activated while the unit is ON, the unit functions as a normal fan without the evaporative cooling function.



## LOW WATER ALARM FUNCTION


The unit is equipped with a low water sensor. When water in the tank is below the minimum level, you will hear 10 beeps and the  LED indicator will flash continuously. At the same time the power to the pump inside the unit will be cut off to protect the life of the pump.

To disengage the alarm function, turn off and unplug the unit from the power outlet. Fill the tank with water above the minimum level.

To turn off the Low Water Alarm and continue to use the unit as a normal fan, without evaporative cooling function, turn the unit off, then on again. If the  is pressed again without filling the tank with water, the Low Water Alarm will activate again.

## REMOTE CONTROL

Power:	On / Off
Speed:	Low / Medium / High
Cool:	Controls cooling
Swing:	Controls the motion of the louvers
Timer:	Controls timer function for automatic shut off



## NOTE


- The remote control for your air cooler already has its battery installed.
- The remote control requires a CR2032(1 x 3V) coin type or equivalent battery for replacement.
- Open the battery compartment at the back of the remote control and insert a CR2032(1 x 3V) coin type or equivalent battery. Care must be taken to insert the batteries according to the correct polarity (+ / -) markings shown inside the battery compartment.
- Always point the remote control signal transmitter towards the unit when operating.
- Make sure that the signal path is not obstructed.
- Remove the batteries if the unit is not going to be used for an extended period of time.
- Do not drop the remote control.
- Do not mix different types of batteries such as alkaline, carbon-zinc, or rechargeable batteries.
- Do not mix old and new batteries.
- Exhausted batteries are to be removed from the product.



## FILLING WITH WATER

Open the Water Fill Tray located at the back of the unit. The water tank of the unit holds up to 2.6 Gallons of water.

The Water Level display window is located on the front of the unit. Refill the water tank when water level is low. Do not fill water above the Max water level mark. Check water level in the tank before running the COOL function. Please be sure water in the tank is always above the minimum water level mark. Running the unit with inadequate water may cause pump failure. If ice is available you may add ice in the top compartment to enhance the cooling performance.



## CAUTION

Unplug from power when refilling.



## WARNING


- Before cleaning the unit, switch it to the OFF position and remove the plug from the power socket.
- To clean the outside, use a damp cloth to remove dirt and dust.
- Never use corrosive elements or any chemicals to clean this product.
- When the product is not in use, store the unit in a dry place out of direct sunlight.



## CLEANING & DRAINING THE WATER TANK:

- Turn the power OFF and disconnect the air cooler from the power supply.
  - Move the unit to a location where it can be drained. Remove the cap from the drainage tube and allow the tank to empty (see parts description on page 7).
  - Once the tank is empty, unlock the latches on both sides and lift off the cooler top section as shown in the figure and place it vertically on the floor. Be careful not to bend the water pickup tube that hangs below the unit.
  - Refill the water tank with clean water and drain it completely. Clean the water tank with detergent or a damp cloth and
  - rinse it thoroughly.
- Place the unit top carefully on the tank and lock the latches.
- Refill the water tank with clean water, up to the maximum level. The air cooler is now ready to be used. This cleaning process should be repeated weekly to maintain the integrity of the unit and to remove particles filtered from the air.

Water Pick Up Tube





Detached Water Tank



## CLEANING THE CARBON FILTER AND HONEYCOMB

- The appliance is supplied with Carbon Filter & Honeycomb Cooling Media.
- Always keep the Carbon Filter clean. You can wash the Carbon Filter at least twice a year or whenever you feel necessary.
- The Carbon Filter and Honeycomb Cooling Media are located inside the back panel. Open the back panel by pulling out the back grill to clean or replace the Carbon Filter or Honeycomb Cooling Media. It is recommended that the Carbon Filter and Honeycomb Cooling Media be replaced every year, depending on use and environment.
- Draining the water reservoir and refilling with fresh water at least once a week will greatly reduce mineral deposits in the pads and help to extend the life of Honeycomb Cooling Media.
- Do not run the unit in COOL mode with stale water in the tank. You must empty the water tank and refill with fresh water, especially if the tank has not been cleaned in a long time.
- The cleaning frequency for the Honeycomb media depends on local air and water conditions. In areas where the mineral content of water is high, mineral deposits may build up on the Honeycomb Cooling Media and restrict air flow. Draining the water reservoir and refilling with fresh water at least once a week will help reduce mineral deposits. If mineral deposits remain on the Honeycomb media, the media should be removed and washed under fresh water. The media should be cleaned every two months or sooner, depending on your needs.
- For best results allow the Honeycomb Cooling Media to dry after each use by turning off the cool function 15 minutes before turning the unit off.



# TROUBLESHOOTING GUIDE

PROBLEM	POSSIBLE CAUSE	SOLUTION
No discharge of air	Cord is not plugged in.	Make sure power cord is plugged in and the supply switch is ON.
	Power is not ON.	Turn the unit ON by pressing button on the control panel or remote control.
Not Cooling / Unit is making noise	Pump is not turned ON.	Turn on COOL function from remote or control panel.
	Low or no water in tank, when COOL is selected.	Refill water tank.
	Damaged Pump or Calcium deposits on blower.	Contact Customer Service Center.
Odors	When the Cooler is new.	When the unit is used for the first time, the Honeycomb Cooling Media will have an odor, which will dissipate within a few hours of initial use.
	If the Cooler has been used.	There may be an algae issue. Replace the Honeycomb Cooling Media.

Customer Support: 1-800-474-2147

PROBLEM	POSSIBLE CAUSE	SOLUTION
The unit does not respond	Remote control batteries.	Check batteries. Replace if needed. Try to operate using the control panel.
	Damaged Control Panel on unit.	Try to activate the unit with the Remote Control. If the unit responds, then the Control Panel on the unit may be experiencing problems - contact the Customer Service Center.
		If neither the Remote Control or the Control Panel is working, contact the Customer Service Center.

Customer Support: 1-800-474-2147

# TECHNICAL SPECIFICATIONS

## MODEL NO.

CS10XE

Voltage	120V
Frequency	60Hz
Ampere	0.85A
Wattage	102 Watts
Water Tank Capacity	2.6 Gallons
Cooling Media	Honeycomb
Product Dimension	13.5 (W) x 15.7(D) x31.5(H) inch
Net Weight	18.5 lbs

## ELECTRICAL WIRING DIAGRAM

