


PRESSURE ACTIVATED DOOR STOP ALARM

Indoor Use Only

- Great travel alarm - Hotel rooms, apartments
- 120dB alarm sounds when alarm is activated
- On-Off switch activates and deactivates alarm
- Low-battery indicator light



BATTERY INSTALLATION


The door stop alarm requires one 9V battery. When the Low-Battery Indicator illuminates, batteries need replacing.

1. Toggle On/Off switch to the 'OFF' position to prevent unintentional triggering.
2. Remove screw on the bottom of the door stop and battery compartment cover.
3. Fit 9V battery to the connecting lead, making sure the terminal polarities are correct.
4. Replace cover.

IMPORTANT: Remove batteries before storing the alarm for extended periods. Batteries corrode over time and may cause permanent damage to the unit. Depleted batteries should be removed from the unit and disposed of properly.

TESTING THE ALARM

1. Toggle the On/Off switch to 'ON'.
2. Quickly but firmly tap down and release the metal on the cover unit. A quick siren chirp indicates proper operation. **NOTE:** The palm of your hand can be used to cover the alarm to reduce risk of hearing damage.
3. Toggle the On/Off switch to 'OFF'.



INSTALLATION: Insert door wedge at the base of the door as shown in the diagram, with the pointed edge under the door gap. The alarm is properly installed if the alarm sounds and the metal contact plate is depressed when the door is opened. Make sure the non-skid pads on the bottom of the alarm are in firm contact with the floor.

OPERATION

1. Toggle the On/Off switch to 'ON' to activate alarm.
2. Toggle the On/Off switch to 'OFF' to deactivate alarm.